JIT Implementation Manual

The Complete Guide to Just-in-Time Manufacturing Second Edition

Volume 1

The Just-in-Time Production System

HIROYUKI HIRANO



JIT Implementation Manual

The Complete Guide to Just-in-Time Manufacturing Second Edition

JIT Implementation Manual

The Complete Guide to Just-in-Time Manufacturing

Second Edition

Volume 1

The Just-in-Time Production System

HIROYUKI HIRANO



CRC Press is an imprint of the Taylor & Francis Group, an **informa** business A PRODUCTIVITY PRESS BOOK Originally published as Jyasuto in taimu seisan kakumei shido manyuaru copyright © 1989 by JIT Management Laboratory Company, Ltd., Tokyo, Japan.

English translation copyright © 1990, 2009 Productivity Press.

CRC Press Taylor & Francis Group 6000 Broken Sound Parkway NW, Suite 300 Boca Raton, FL 33487-2742

© 2009 by Taylor & Francis Group, LLC CRC Press is an imprint of Taylor & Francis Group, an Informa business

No claim to original U.S. Government works Printed in the United States of America on acid-free paper 10 9 8 7 6 5 4 3 2 1

International Standard Book Number-13: 978-1-4200-9016-1 (Softcover)

This book contains information obtained from authentic and highly regarded sources. Reasonable efforts have been made to publish reliable data and information, but the author and publisher cannot assume responsibility for the validity of all materials or the consequences of their use. The authors and publishers have attempted to trace the copyright holders of all material reproduced in this publication and apologize to copyright holders if permission to publish in this form has not been obtained. If any copyright material has not been acknowledged please write and let us know so we may rectify in any future reprint.

Except as permitted under U.S. Copyright Law, no part of this book may be reprinted, reproduced, transmitted, or utilized in any form by any electronic, mechanical, or other means, now known or hereafter invented, including photocopying, microfilming, and recording, or in any information storage or retrieval system, without written permission from the publishers.

For permission to photocopy or use material electronically from this work, please access www.copyright.com (http://www.copyright.com/) or contact the Copyright Clearance Center, Inc. (CCC), 222 Rosewood Drive, Danvers, MA 01923, 978-750-8400. CCC is a not-for-profit organization that provides licenses and registration for a variety of users. For organizations that have been granted a photocopy license by the CCC, a separate system of payment has been arranged.

Trademark Notice: Product or corporate names may be trademarks or registered trademarks, and are used only for identification and explanation without intent to infringe.

Visit the Taylor & Francis Web site at http://www.taylorandfrancis.com

and the CRC Press Web site at http://www.crcpress.com

Contents

Pul	blisher's Message	ix
For	eword to the Original English Edition	xi
Int	roduction to the Original English Edition	xiii
Vol	ume 1	
1	Production Management and JIT Production Managemen	nt 1
	Approach to Production Management	
	Overview of the JIT Production System	7
	Introduction of the JIT Production System	12
2	Destroying Factory Myths: A Revolutionary Approach	35
	Relations among Sales Price, Cost, and Profit	35
	Ten Arguments against the JIT Production Revolution	40
	Approach to Production as a Whole	44
Ind	lex	I-1
Abo	out the Author	I-31
Vol	ume 2	

3	"Wastology": The Total Elimination of Waste	145
	Why Does Waste Occur?	
	Types of Waste	
	How to Discover Waste	
	How to Remove Waste	
	Secrets for Not Creating Waste	
4	The "5S" Approach	237
	What Are the 5S's?	
	Red Tags and Signboards: Proper Arrangement and	
	Orderliness Made Visible	

The Red Tag Strategy for Visual Control	268
The Signboard Strategy: Visual Orderliness	293
Orderliness Applied to Jigs and Tools	307

5	Flow Production	321
	Why Inventory Is Bad	. 321
	What Is Flow Production?	.328
	Flow Production within and between Factories	. 332
6	Multi-Process Operations	387
	Multi-Process Operations: A Wellspring for Humanity on the Job	.387
	The Difference between Horizontal Multi-Unit Operations and	
	Vertical Multi-Process Operations	.388
	Questions and Key Points about Multi-Process Operations	. 393
	Precautions and Procedures for Developing Multi-Process	
	Operations	.404
7	Labor Cost Reduction	.415
	What Is Labor Cost Reduction?	. 415
	Labor Cost Reduction Steps	. 419
	Points for Achieving Labor Cost Reduction	.422
	Visible Labor Cost Reduction	.432
8	Kanban	435
	Differences between the Kanban System and Conventional Systems	.435
	Functions and Rules of <i>Kanban</i>	.440
	How to Determine the Variety and Quantity of Kanban	.442
	Administration of Kanban	.447
9	Visual Control	453
	What Is Visual Control?	. 453
	Case Study: Visual Orderliness (Seiton)	. 459
	Standing Signboards	.462
	Andon: Illuminating Problems in the Factory	.464
	Production Management Boards: At-a-Glance Supervision	.470
	Relationship between Visual Control and Kaizen	. 471

Volume 4

10	Leveling	475
	What Is Level Production?	475
	Various Ways to Create Production Schedules	477
	Differences between Shish-Kabob Production and Level Production	482
	Leveling Techniques	485
	Realizing Production Leveling	492
11	Changeover	. 497
	Why Is Changeover Improvement (<i>Kaizen</i>) Necessary?	497
	What Is Changeover?	498
	Procedure for Changeover Improvement	500
	Seven Rules for Improving Changeover	532
12	Quality Assurance	. 541
	Quality Assurance: The Starting Point in Building Products	541
	Structures that Help Identify Defects	546
	Overall Plan for Achieving Zero Defects	561
	The <i>Poka-Yoke</i> System	566
	Poka-Yoke Case Studies for Various Defects	586
	How to Use Poka-Yoke and Zero Defects Checklists	616

13	Standard Operations	623
	Overview of Standard Operations	623
	How to Establish Standard Operations	628
	How to Make Combination Charts and Standard Operations Charts	630
	Standard Operations and Operation Improvements	638
	How to Preserve Standard Operations	650
14	Jidoka: Human Automation	655
	Steps toward <i>Jidoka</i>	655
	The Difference between Automation and <i>Jidoka</i>	657
	The Three Functions of <i>Jidoka</i>	658
	Separating Workers: Separating Human Work from Machine Work	660
	Ways to Prevent Defects	672
	Extension of <i>Jidoka</i> to the Assembly Line	676

15	Maintenance and Safety	683
	Existing Maintenance Conditions on the Factory Floor	
	What Is Maintenance?	684
	CCO: Three Lessons in Maintenance	689
	Preventing Breakdowns	
	Why Do Injuries Occur?	685
	What Is Safety?	688
	Strategies for Zero Injuries and Zero Accidents	689

JIT Forms	711
Overall Management	
Waste-Related Forms	730
5S-Related Forms	
Engineering-Related Forms	777
JIT Introduction-Related Forms	
	JIT Forms Overall Management Waste-Related Forms 5S-Related Forms Engineering-Related Forms JIT Introduction-Related Forms

Publisher's Message

Hiroyuki Hirano's *JIT Implementation Manual* was first published in Japan in 1989, and Productivity Press published the English translation the following year. In his Foreword to the original English edition, Norman Bodek refers to the book as a "masterpiece," and it has certainly stood the test of time and proven itself during the past twenty years.

This was the first work of its kind to provide, in such great detail, a structured approach to the implementation of what was commonly referred to as "just-in-time" manufacturing, and to cover so many of the concepts that are core to what we now call "lean manufacturing"—identification and elimination of waste, visual management, the 5S's, flow production, *kanban*, cellular manufacturing, leveling, quick changeover, poka-yoke, standard work, *jidoka*, and so much more.

Mr. Hirano refers to 1989 and 1990 as pivotal years in the transformation of Japan's industrial structure, and what better time than the economic transition we are experiencing in 2009 to re-release this classic work.

The first edition, now out of print, comprised two binders in a slipcase. In this new edition, prompted by many requests from long-time users of the original volumes, we provide the same information in a more accessible format. These six paperback volumes contain all the original, unedited material from the original edition, divided into logical sections that follow the steps Mr. Hirano details for establishing a JIT production system (see Figure 1.6 in Volume 1, Chapter 1):

Volume 1 Step 1 – Awareness Revolution
Volume 2 Step 2 – The 5S's for factory improvement
Volume 3 Step 3 – Flow manufacturing
Volume 4 Step 4 - Leveling
Volume 5 Step 5 - Standardized operations
Volume 6 The JIT forms

In addition, we have included a CD containing PDFs of all the forms in Volume 6 so readers can easily print the individual forms in multiples, or use them as models for creating custom forms. Of course, the point of the forms is to promote engagement of all team members and focus on improvement activities – not to complete them in isolation and house them in a cabinet or on a hard drive! We have also added a detailed index for the entire set of six volumes. For your convenience, the complete index is included in each volume.

We hope that students, those interested in the roots of lean, and those many practitioners who have requested that this information be brought back into print will benefit from this new release.

> Maura May Publisher

Foreword to the Original English Edition

A year ago Productivity Press published what we considered to be the best introduction for all employees to Just-In-Time (JIT)—a picture book entitled *JIT Factory Revolution: A Pictorial Guide to Factory Design of the Future* by Hiroyuki Hirano, a top international consultant. I am now proud to offer you its counterpart—the most comprehensive and detailed manual in the world today for setting up a complete JIT program. *JIT Implementation Manual: The Complete Guide to Just-In-Time Manufacturing* is also written by Mr. Hirano, who is really making his genius accessible for the first time. At last we have a place to go to get answers to virtually every JIT problem.

One evening in January 1990, I had dinner with Mr. Hirano and his wife at a very lovely French restaurant in Tokyo. I told him how pleased I was with his work and then asked him to explain exactly what he does in his consulting practice. He started off by showing how he uses one of his forms. He gathers his client's conversion team and reviews the homework left from his last visit. Each member explains the improvements made within the plant. Afterwards, carrying a pad of these forms, each person follows him around the plant, where up to 100 problems are identified, indicated by type (for instance, the 5S's, one-piece flow, visual management, multi-process workers, *jidoka*, leveling, work standardization), and recorded on the forms. The forms are then posted on bulletin boards and become homework for his next visit. This is the simple, but very powerful, Hirano method of focusing on improvement activities. And his manual is filled with similar practical examples from his own highly successful consulting practice.

In an extremely well-written and articulate presentation, this manual provides a clear structure that enables readers to easily ferret out vital information. The material is addressed in three sections: JIT concepts, JIT techniques, and actual tools for putting JIT into practice. Based on his vast experience in factories throughout Asia and the West, Mr. Hirano explains in detail over 200 illustrations, charts, checklists, diagrams, and sample JIT management forms that he uses to implement "JIT Awareness Revolutions" wherever he goes. This massive handbook contains answers to virtually every problem a JIT professional will face, as well as multiple options for every stage of JIT implementation.

If I sound effusive, please understand that I have been searching for such a resource to offer Productivity Press readers for years. In fact, throughout the 1980s, Productivity's industrial study missions to Japan revolved around my personal quest to find the best source materials for implementing JIT. And while we have come across numerous consultants and engineers and translated many superb books and materials, I have waited a long time for a handbook of the caliber of Hiroyuki Hirano's *JIT Implementation Manual*.

This is Productivity Press's most ambitious publishing project to date. Known as the "JIT Bible" in Japan, Mr. Hirano's *JIT Implementation Manual* is encyclopedic in scope and provides unparalleled information on every aspect of JIT, from its philosophical underpinnings to the myriad systems, techniques, and tools for virtually every factory setting.

To produce this massive project as quickly as possible, many fine people both Productivity staff and freelance professionals—were employed. In particular, I wish to acknowledge the efforts of: Bruce Talbot for his splendid translation and writing; Cheryl Berling Rosen for her editorial and content supervision; David Lennon and Esme McTighe for their production management; Sally Schwager for her bilingual handling of the numerous queries between Mr. Hirano and the Productivity staff; Tim Sandler for his copyediting; and Micki Amick of Amick Communications for the manual's design, page makeup, art production, and project management.

Our mission at Productivity is to publish and distribute the best materials on productivity, quality improvement, and employee involvement for business and industry, academia, and the general public. Many of our products, like the Hirano manual, are direct source materials from Japan that we have translated into English for the first time. It is with great anticipation that I present this work to our readers. I thank Mr. Hiroyuki Hirano for granting us the opportunity to produce this masterpiece in English.

> Norman Bodek Publisher

Introduction to the Original English Edition

In the future, I think we shall look back upon 1989 and 1990 as pivotal years in the transformation of Japan's industrial structure.

During these years, abiding yen appreciation and trade friction will continue to devalue the advantages of Japanese domestic production. As a result, we will see more and more Japanese automakers, electronics firms, and other manufacturers shifting their production overseas.

Japan's large "parent" companies are heading overseas in droves, leaving behind their "child" subcontractors. It would be nice if the parent companies could take their children with them, but the children generally lack the money, staff, technology, and marketing power to make the move. So the children are left behind to fend for themselves. They are entering a bitter battle for survival, in which many must enter into new industrial fields to pull through.

The high yen and the search for lower costs has also boosted the flow of Japan's imports from the Asian NIES (Newly Industrialized Economic Societies) and the ASEAN countries. These parts and products are generally characterized by large volumes, unhurried schedules for production and delivery, and relatively lenient quality standards. By the same token, the goods that are still produced in Japan tend to have the opposite characteristics small volumes, tight production and delivery schedules, top-notch quality, and marketable prices.

Japan's ongoing trend toward market diversification has further fueled the demands for wide-variety, small-lot production with speedy delivery. Let it be understood at the outset that JIT production is neither one automaker's production system nor is it the subcontractor's curse. Instead, JIT consists of *ideas and techniques for the complete elimination of waste*.

In a sense, JIT production is a new field of industrial engineering (IE), one that thoroughly eliminates the waste that runs rampant in most factories while helping to build products that serve client needs. JIT production is also the kind of market-oriented or "market-in" production system that is increasingly needed in today's fast-changing global marketplace.

This book is a compendium of the experiences and knowledge I have gained during many years of enthusiastic work in battling waste in factories and promoting the development of JIT production. As such, this is a manual for professional consultants. It enables them to tell the plain truth and to overcome vexing problems.

This book is not for sale to the general public. I would not want it to be sold that way. It is a book for manufacturing companies that are fighting desperately for survival and that will go to any length to improve their factories and overcome the obstacles to success. One could even call this book a "bible" for corporate survival.

Accordingly, this book is intended for only three types of readers: leading strategists for corporate survival, including top management; in-house JIT leaders; and professional JIT consultants.

Chapters 1 and 2 describe the JIT production approach and its underlying concepts. As you will see, the JIT approach casts off old concepts and introduces a revolutionary way of thinking.

Chapter 3 looks into the nature of waste and tells how we can scientifically identify waste and take comprehensive steps to remove it.

Chapter 4 takes up the 5S's, which make up the foundation for making improvements in factories. This chapter will pay special attention to red-tagging and *kanban* techniques as devices for visual control and regulation of the factory.

Chapters 5 to 15 present explanations, backed by many case studies, of JIT techniques centered on flow manufacturing.

Finally, Chapter 16 includes a large selection of vouchers, lists, and other JIT-related forms, many of which can be photocopied and used as is. These forms can serve as effective tools in paving the way for JIT production.

This manual broadly falls into three parts. The first part presents JIT concepts, the middle part JIT techniques, and the last part tools for putting JIT into practice.

I will conclude by asking those of you who use this manual to avoid taking a piecemeal approach, such as adopting only the *kanban* or *andon* systems or aiming at only a limited range of improvements. The overall flow is the most important aspect of production, and the key ingredient for creating a good overall flow is comprehensive improvement—in other words, factory-based innovation. If readers understand this book and find it useful as a "bible" for building better products, I will gain the satisfaction of knowing that the five years of effort and expense invested in this project since its planning stage were not just another form of waste.

Hiroyuki Hirano

February 1989

Chapter 1

Production Management and JIT Production Management

In today's world, manufacturing industries can no longer afford to remain complacent in the belief that their chief concern is to turn out products.

Things were quite different during the early postwar years, which marked the birth of Japan's modern industry. Basic materials—even for such things as shoes and clothing—were extremely scarce. Anyone who could scrape together enough materials to make a product could sell it. The successful manufacturers were simply those who had access to materials.

How things have changed. Today, clothing and shoe stores are everywhere, their shelves jam-packed with merchandise. Long gone are the days when Japan's manufacturers could sell whatever they could make. Now there are literally thousands of clothing and footwear manufacturers in Japan, and there must be hundreds of thousands worldwide.

The simple, hard-nosed approach that says, "Manufacturing is the business of making things," has grown dangerously out of date. To become a winner in today's survival game, manufacturers must make big changes in their way of thinking. For today, the key to successful factory management is the realization that *manufacturing is a service industry*. Until quite recently, the common orientation among manufacturers was, "Make good products cheaply and quickly." This approach became known as the QCD (Quality, Cost, and Delivery) approach. The QCD approach was a reliable road to success for many years, but today it takes more than these three elements to ensure a factory's survival. Three additional conditions are now evident:

1. Diversification

The growing diversity of customer needs is accelerating the trend toward greater varieties of products on the market.

2. Smaller lots

The total market pie is not growing much larger, but the variety of products are. So, naturally, these products have to be made in smaller lots.

3. Shorter delivery schedules

As the product diversification trend continues, companies will go broke if they stick to their old habit of keeping fullline inventories. But what are the alternatives? It is not easy to predict which product types will sell best and in what volumes. So companies instead try to replace warehoused products as soon as they are sold, or they switch over to special-order production with short delivery schedules.

When taken together, these three conditions call for "widevariety, small-lot production with speedy delivery."

This means adding new elements to the old tripartite QCD formula to accommodate product diversification. Today, we need to add a "P" for product diversification and an "S" for safety. The result is the PQCDS approach, a service-oriented approach attuned to current needs (Figure 1.1).

To put it another way, PQCDS is a service that manufacturers provide by making desired products (P) of high quality (Q) at low cost (C) with speedy delivery (D) and assured safety (S) from start to finish.



Figure 1.1 The PQCDS Approach.

Here we have an important transition from being a product maker to becoming a service provider. Today, manufacturers must think of themselves as service-industry companies.

Approach to Production Management

Many a factory manager has asked me: "We're using a computer-based production management system now, but for some reason we have not been able to reduce our warehouse inventories or shorter lead-times. What should we do?" (See Chapter 2 for an additional discussion of the JIT approach to warehousing and lead-times.)

For some reason, even top managers at factories seem to think of the computer as some kind of magic wand. They somehow reckon that once a computer-based system is installed, the factory will run like a finely crafted timepiece.

I always answer this question the same way: "First you have to change the president's mind!" That's all there is to it.

Let us begin by looking at the issue of lead-time. Generally, we define a product's lead-time as the period that begins when the sales department issues the production plan and ends when the planned products is shipped.

Figure 1.2 takes a somewhat closer look at the various elements within the lead-time.



Figure 1.2 Product Lead-Time.

Obviously, a factory cannot go immediately from receiving a sales plan to building products. The factory managers must first size up the production capacity situation and then begin working out a production plan proposal. Next, the production and sales departments need to meet, tailor the proposal to their specific needs, and jointly approve it.

Once the proposal has been revised and approved, it needs to be rewritten as the official production schedule, which includes delivery schedules for the assembly components and other parts and materials required by the schedule. The official production schedule also includes instructions for goods procurement and subcontractor orders.

During all of these stages, the clock is ticking but no products are being manufactured. All that has happened so far is planning, which is to say paper-shuffling and number-crunching. Still, we are obliged to include these time-consuming planning processes as part of the overall lead-time. So, before actually making anything, there is lots of paperwork, which led me to call this part of the overall lead-time the *paper lead-time*.

By contrast, three-dimensional materials really start moving once the production orders are issued and the products are shipped. First, the procurement people and the subcontractors get moving when the order book is out. Soon, deliveries of procured and subcontracted products start arriving. Then the factory gets into gear, using equipment such as cutters, presses, and lathes to process and assemble parts. Once the parts are finished, they can be assembled into finished products.

Naturally, various kinds of information have been exchanged throughout these stages, and the flow of production has been firmly centered on the work in process. The key issues invariably are: how to process the materials, which manual operations to use, and how to move things around. That is why I call this latter part of the overall lead-time the *physical lead-time*.

If we introduce computerization to shorten lead-times, what distinct effects might such a move have on the paper lead-time and the physical lead-time? Let's first look at the possible effects on the paper lead-time.

It is not difficult to imagine the kind of time and energy it takes when people get together with their calculators to work out the numbers for an efficient production schedule. To make the production schedule work efficiently, these planners have to calculate the correct amounts of various parts and materials, as well as the proper timing for their delivery.

A computer can be very helpful in facilitating and speeding these paper lead-time tasks. But just how helpful can it be in shortening the physical lead-time?

For instance, if a factory manager tells a subcontractor, "We just got a computer to help run our factory," is the subcontractor supposed to think he needs to start delivering his products to the factory in half the time? Or is the subcontractor foolish enough to think that installing a computer in his own factory will enable half-day change-over procedures to be drastically reduced?

To shorten the physical lead-time portion of the overall leadtime, we need something other than computers. Usually, we need factory-based improvements. We call the kind of factorybased improvements that result from adopting Just-In-Time "JIT improvements."

Thus, the fact is that computers mainly help shorten the paper lead-time by improving clerical processes. It is only by



Figure 1.3 **Production Management Defined.**

getting involved in making factory-based improvements that we can effectively shorten the physical lead-time. Our tactics should differ depending on which kind of lead-time we are trying to shorten.

In the factory, we are faced with a wide range of problems and issues. It is the job of production management to sort out and correct these problems according to market needs.

We should ask ourselves the simple question, "What is production management?" To answer that question, we need to return to the basics. Consider the definition of production management on Figure 1.3.

Factories should be thought of as living entities or organic systems. Within the factory's overall system are informationbased factors that are hard to see, and equipment-based factors involving the flow of goods that are easier to see.

We refer to the overall system's information-based factors as the management system and its equipment-based factors as the physical system. The management system includes such things as the factory's organization, its hierarchy or organizing framework, its clerical procedures, and other information-related aspects that readily lend themselves to improvement through computerization. By contrast, the physical system includes the plant equipment and its layout within the factory, production methods, and other equipment-related aspects. Today, factories are grappling with a common problem: how to combine the management system and physical system so that they function together in a level manner, like the two axles of an automobile, while serving current needs for wide product variety, high quality, low costs, and speedy delivery.

It is all well and good to bring computerization into the information-related aspects, but that will not do much good if the company's organization remains in the mass-production mode of decades past and the manufacturing orientation still emphasizes large lots. Conversely, companies will find themselves lagging behind the times if they concentrate solely on factory-floor improvements and ignore the advantages of computerized information management.

From a comprehensive standpoint, we can make a distinction between "JIT production management" as a program for developing production management attuned to market needs and "JIT improvements" as a program for improving efforts centered on a factory's physical system.

As the two axles of the "factory automobile," the management system and the physical system must be kept in pace with each other, with neither being pushed ahead or held back relative to the other. Otherwise, the automobile will not get to its destination of corporate success.

Overview of the JIT Production System

The JIT production system is a market-oriented production system that rests entirely on the foundation of serving client needs.

Whenever I have spoken to groups of people about the JIT production system, someone invariably remarks, "You mean the Toyota *Kanban* System, right?" I suppose that is an indication of how famous the *kanban* system has become. The fact is, though, that the *kanban* system is part—but not all—of the JIT production system. The *kanban* system can

be thought of as the conveyance system that helps make the JIT production system work. The JIT production system first gained public attention in Japan in the aftermath of the 1973 oil crisis, when market demand slacked off. A strong diversification trend was born, and Japan's economic growth slowed to a more modest rate. Amid this environment, the JIT production system gained the media notoriety as a recession-resistant production system.

The first aspect of the JIT production system to gain such attention was the *kanban* system, in which signs attached to goods replace vouchers as the medium for giving operating instructions and production orders.

JIT, or "Just-In-Time," refers to the timing of production flow; goods are delivered to the manufacturing lines just in time to be used, just in the immediately needed quantities, and just to the production processes that need them. Saying "in time" is not enough, since parts can arrive at processes a week or two prior to their use and still be there "in time."

That is why the most important word in Just-In-Time is the first word, "just." Goods need to arrive within minutes, not days or weeks, of their use on the production line. Only then can we eliminate waste in such forms as overproduction, waiting for late deliveries, and excess inventory.

Let's consider, for instance, a press operation. Imagine a big pile of cut sheet metal next to the press. All those sheets are there "in time" to be pressed. The sheet metal could have been cut yesterday and delivered "in time" to be pressed. Or it could have been cut and delivered last week or last month and still be there "in time." In any case, the sheet metal is there "in time" but not "just in time."

When the press operator is ready to press another sheet, all he needs is one sheet from the previous process. He does not need 10 or 20 of them. When he finishes pressing that one sheet, he is ready to get another one from the previous process. That is the way work-in-process should move, one at a time from the raw material stage to the finished product stage.



Figure 1.4 Overall Image of the JIT Production System.

It is helpful to picture Just-In-Time production as something like a river, in which separate workpieces float along in a level manner from station to station as they are sent downstream. Figure 1.4 presents an overall image of the JIT production system.

At first glance, the JIT production system seems simple enough, but when we begin to delve into its inner workings, we find it to be extremely complicated and full of things that cannot be well understood until they have been tried out in the factory. Factory-based improvements are not something to be talked about, written about, heard, or seen—they are something to be done. Such improvements are "hands-on" to their very core.

The following is an introduction to the types of improvements that must be made to bring about Just-In-Time production:

1. Flow manufacturing

Flow manufacturing requires the elimination, whenever possible, of pile-ups and conveyances to enable workin-process to flow in a level manner through the line. The goal is to have each workpiece move through the chain of processes so it is correctly processed within the cycle time.

2. Multi-process handling

In the conventional equipment layout scheme, where several machines having the same processing function are grouped together as a shop, one worker might be able to handle several machines, but handling several processes is out of the question. A different layout scheme, in which the machines that make up an entire sequence of processes are grouped together, would enable a single worker to move with the workpieces from process to process until the workpiece processing is finished. This latter arrangement is called multi-process handling.

3. Kanban

The *kanban* system comprises one of the tools for maintaining Just-In-Time production. *Kanban* are signs that contain operation instructions and/or parts delivery information. *Kanban* are useless in factories that still use the conventional "shish-kabob" type of production method. In fact, they tend to increase warehouse inventory levels in such situations. The factory must first switch over to flow manufacturing, and must start *pulling* workpieces from process to process rather than *pushing* them.

4. Manpower reduction

Conventionally, production lines have been organized with a view toward maintaining a steady number of workers on the line. The JIT production system rejects this way of thinking and instead organizes production using the minimum number of workers (personnel costs) required to meet the demand (fluctuation) of the next process (the market).

5. Visual control

A key method for making bold improvements is to make line failures or other factory-floor problems visible and obvious enough so that anyone can easily spot them. Various devices can be used to make production line problems more visible. *Kanban* and *andon* (line-stop alarm lights) are two such visual control devices.

6. Leveling

A little earlier, I used the term "shish-kabob" in discussing the kind of production scheme that was popular during the mass-production era. The shish-kabob image refers to the way that lots were processed in large, separate groups (the larger the better), much like the way meat and vegetables are set one by one on shish-kabob skewers. Lots were processed and then warehoused. The concept of leveling calls for product types and volumes to be spread out to produce as level a production flow as possible. Thus, leveling is fundamental to both Just-In-Time production and flow manufacturing.

7. Changeover

Here, I am using "changeover" as a broad term that covers not only the replacement of dies and blades, but also other operations, such as the revision of standards and the replacement of assembly parts and other materials. The goal of changeover improvements should be to shorten the time needed for such operations. They should make marked reductions in labor-hour requirements in order to build a strong, flexible manufacturing line that is adaptable to changes.

8. Quality assurance

Quality is not something that just happens when we have good production equipment. Likewise, having equipment operators work more cautiously does not necessarily reduce the number of defective products. Rather, quality assurance requires a comprehensive approach that addresses all production factors, including people, goods, production equipment, and production methods.

9. Standard operations

Standard operations are essential for maintaining flow manufacturing once it has been established and for keeping pace with the production schedule. In short, standard operations are the operations that have been painstakingly developed to achieve and preserve an effective combination of people, goods, and machines to produce high quality products economically, quickly, and safely.

10. Jidoka: Human automation

Jidoka is automation with a human touch, and therefore differs from automation in the ordinary sense. *Jidoka* brings humans into the automation process to ensure reliability, flexibility, and precision.

11. Maintenance and safety

In the JIT production system, the entire production flow is stopped whenever even the smallest machine breaks down. That is why the JIT production system places great value on maintenance activities that maintain high production capacity. Equal emphasis is placed on safety the first and foremost consideration in production—in order to prevent breakdowns and accidents.

Introduction of the JIT Production System

Introduction Procedure

Adopting the JIT production system entails changing current production methods into JIT production methods. We generally refer to these kinds of changes as "JIT improvements."

JIT improvements are quite different from the conventional industrial engineering (IE) type of factory improvements. The latter are usually based on analysis of current conditions. Improvement workers get out stopwatches and other instruments to measure current processes and then analyze them. Using the analysis results, they try to improve or fix the undesirable conditions.

By contrast, JIT improvements are based on ideals instead of measurements. Their purpose is to bring the entire factory



Figure 1.5 Improvement versus JIT Improvements.

into conformance with the requirements of the JIT production system. While IE improvements use an inductive approach based on statistical data, JIT improvements address a single issue—Just-In-Time production—and use a deductive approach to improve the factory (see Figure 1.5).

Rather than taking the slow plodding approach to fixing apparent problems within the current conditions, the JIT improvement approach moves by leaps and bounds to bring the factory as close as possible to the JIT model. As such, JIT improvement actually goes beyond "improvement" and into the realm of "innovation." Perhaps the term "JIT innovation" is more appropriate than "JIT improvement."

A factory cannot truly establish the JIT production system unless it successfully takes on all of the components of the overall JIT image that were shown in Figure 1.4. Figure 1.6 shows the five major steps in the upward sequence of events leading to success in establishing the JIT production system.

Step 1. The Awareness Revolution: Prerequisite for Factory Improvement

All innovation starts in the mind. Once we revolutionize our awareness of the factory situation, we will naturally want to improve the factory equipment and its layout and create better methods of operation. The JIT improvement concept does not mean going directly to the factory to make things



Figure 1.6 Steps in Establishing the JIT Production System.

better. Instead, the most important approach is to begin by revolutionizing people's awareness.

Manufacturing companies include all types of job functions, from business management to factory management, procurement, production, and so on. Production cannot proceed in a level manner unless all of these functions work well together on a day-to-day basis. And almost all of these functions are performed by people, not machines.

I am amazed at the kind of question I am asked when explaining this first step. For example, some people ask, "Who is supposed to revolutionize our awareness?" Others complain, "Hey, it's a production problem, so we've got to change the factory first."

I have even been told, "Look, the problems start with deliveries, and the buyers and subcontractors need to change first."

Right.

Obviously, it is important that everyone, including the production workers and the outside vendors, undergo the awareness revolution. But the best place to start is at the top. The reason for this is that as long as top management harbors such thoughts as, "There's no way to establish JIT with the way things are at this company," the necessary changes will not be made. You can bet on that.

When I hear such doubts coming from top managers, I always respond, "So, when are you going to get around to changing the way things are at your company?" Usually, they realize the futility of their thinking, and admit with a smile, "I guess we'll never have JIT unless we do something about it."

JIT improvement means more than changing production methods. Most companies are awash in problems arising from narrow self-interest or waste. Often, such problems have been around so long that they are unwittingly considered part of the "corporate culture."

The awareness revolution must start at the top of the company. There is no other way. Once top management people become more aware, they gain a heightened sense of what is wrong with the status quo. This sense of emergency begins to trickle down to middle management and then to the factory workers, until finally the whole company is filled with an awareness that things must change. It is this awareness that produces the energy needed to change the status quo. It creates a positive, dynamic force for change.

There are various ways to start and encourage this chainreaction, such as holding in-house seminars and starting up JIT study groups to examine JIT movements and conditions in other manufacturing companies.

If only one thing sinks into the minds of all the company employees during these awareness revolution efforts, let it be that the status quo is not enough to ensure the company's survival in the future.

Step 2. The 5S's for Factory Improvement

Throughout the great effort to render the factory into a close approximation of the JIT model, we can look to five basic underlying principles. These principles are summarized by five words that, in romanized Japanese, begin with "S," and are thus called the 5S's. The 5S's are: proper arrangement (*seiri*), orderliness (*seiton*), cleanliness (*seiso*), cleanup (*seiketsu*), and discipline (*shitsuke*).

The most fundamental of these 5S basics are proper arrangement and orderliness. The success or failure to adhere to these two basics constitutes a major fork on the road to JIT success.

You are sure to find plenty of defective products when the factory is strewn with trash, when its floors and machines are oily or dusty, or when the production workers do not mind working in old, soiled uniforms. You will find plenty of late shipments, too. And low productivity. And low morale.

In any case, such factories are nowhere near being wellorganized or well-regulated. Neither are they very neat or clean.

In Japan, about 70 percent of what we generally think of as factories are not factories. They are warehouses. The factory workers build things inside huge warehouses. They are surrounded by useless things and firmly plant themselves in front of unnecessary machines. Amid all this clutter, the workers literally go out of their way to make things. Often, workers must waste time looking for things that they need, such as parts, dies, or tools. The workers that have been there long enough to have figured out where those things are likely to be are called "veterans."

Under such conditions, there is really nowhere to begin making JIT improvements. First, we have to go back to the most basic of the 5S's, proper arrangement and orderliness. To do this, we begin figuring out exactly what and how much is really needed in the factory.

Putting up a big sign emblazoned with the words "Proper Arrangement and Orderliness" is obviously not going to do the trick if the floor is still cluttered with unnecessary parts and assorted garbage. Improvements do not come from banners. Neither do they flow from the mouths of pep-talkers. Improvements are things that get done on the spot. Two of the biggest obstacles for proper arrangement and orderliness are poor training and ignorance of proper methods. The most effective way to bring about proper arrangement and orderliness is to keep things visible. When trying out a new arrangement plan, a 5-year-old child should be able to figure out what is necessary and what is not. Once it is decided where things should go and in what quantities, any amateur—whether a company president or a visitor should be able to easily recognize the rules.

This is what is meant by "visual proper arrangement and orderliness." The strategy for bringing about visual proper arrangement is called "the red tag strategy." The strategy for establishing visual orderliness is called "the *kanban* strategy."

When carrying out the red tag strategy, the company forms red tag teams to perform company-wide red tag campaigns from two to four times over the span of a year. It is vital that the red tag strategy be maintained for at least a year, or else the company will likely slip back into its old sloppy habits.

Step 3. Flow Manufacturing

Whenever I am asked what flow manufacturing means, I always respond, "It means bringing the factory's underlying waste to the surface."

Whether the production method is shish-kabob production or one-piece flow manufacturing, the product is the same. One might think that since the end product is the same, it does not matter which method is used.

However, there is one important difference here. Shishkabob production tends to conceal waste while flow manufacturing tends to reveal it. That is the only significant difference between the two methods. For beginners looking to make JIT improvements, it is still much too early to think about what differences there are between the two methods when applying them to such matters as greatly improving productivity and more readily meeting customer needs. Shish-kabob production of large lots was fine during the bygone era of fast-expanding sales. Companies grew larger without regard to how much "fat" or waste they were accumulating. In the seller's market of those days, the manufacturer's waste-related costs could just be added into the product's marketable price.

Now it is a buyer's market. Today's buyers do not need or wish to subsidize manufacturers' waste-related costs. In fact, nowadays consumers are smart enough to lay the blame for such waste-related costs directly on the manufacturer.

Unfortunately, waste usually runs deep within any factory. And deeply embedded waste is not at all easy to discover. Such waste has, in a sense, spread roots. Like real roots, the roots of waste sometimes get severed when you try to pull them out, and you have to go deeper to get the rest of them, or they will grow back later. Waste has to be eradicated completely. Small-scale improvements will not do the job.

Now let's get on to how flow manufacturing is employed.

Manufacturing products one at a time allows us to look right into the depths of how the products are made. All of the major and minor forms of waste that had been concealed by the large-lot shish-kabob production method are now visible.

We begin to notice odd things and ask questions like:

- "Why are we conveying the workpiece from here to there?"
- "Why are the parts piling up right here?"
- "Why does changeover have to take so long?"

Setting up for flow manufacturing is a piece of cake. There are only seven requirements, as listed in Figure 1.7. If all seven are met, the factory will have bona fide flow manufacturing. It is as simple as that.

I doubt that the novice at JIT improvement would understand what any of these tersely worded requirements mean. Below is a more detailed description of each.





1. Continuous flow production line

This means arranging the production processes (and the production equipment) into a line or a U-shaped cell.

- 2. *Compact specialized and general-purpose equipment* Costs can be kept down by installing smaller, slower, and more specialized production equipment. However, some general-purpose equipment is also needed to facilitate flexible line reorganization.
- 3. One-piece flow

This means that each process should handle only one workpiece unit from the time processing of that workpiece is begun until it is finished.

4. Cycle time

This refers to the need to synchronize processes to keep pace with client needs and the needs of the next process.

5. Multi-process handling

This is a labor arrangement in which one worker moves from process to process down the line.

6. Multi-skilled workers

This entails training workers in the skills needed for multi-process handling.

7. Standing (chair-free) operations

An important improvement in work posture is changing from sitting to standing, enabling worker mobility.
Step 4. Leveling

In principle, it is best to start JIT improvements as close as possible to the client. In the factory, that would mean starting by reducing finished product warehouse inventories to zero. If we can tear down the wall of piled-up products that need to be shipped and sold, we are better able to incorporate the latest client needs into the factory. Those product "walls" protect factories from the powerful waves of changing client needs. They give the factories a false sense of security, especially today when factories need to remain in intimate touch with market trends.

It is only by tearing down those walls that factories can come face to face with the needs of today's market for greater diversification and shorter lead-times. Factories may then promptly change their production lines to reflect those needs.

Then, as the old QC saying goes, "the next process is your customer." After aiming to meet client needs for a certain product, JIT improvements move on to the product's subassembly lines, processing lines, materials processing lines, and outside orders. (See Figure 1.8.) This is called "vertical development" of JIT improvements. We call it "lateral development" when JIT improvement moves on to other products.

Therefore, as a rule, JIT improvement begins near the client and moves upstream from the "next process" to the "prior process."

To recapitulate, to start off the JIT improvement campaign, we get rid of the stacks of finished products in the warehouse and then we change the final assembly processes to suit the client's current needs. To do this, we must put an end to the factory's shish-kabob style of lot production. The factory is no longer going to turn out large lots of product A this week and large lots of product B next week. That is not the way customers buy things. It is only the way that seems most convenient for the factory.



Figure 1.8 Sequence for Introducing JIT Improvement.

Although the exact quantities of each product fluctuate a little, customers invariably buy a wide range of products. Bringing such diversity into the production system is what we mean by "production leveling."

Many people think of production leveling as leveling out two factors: capacity and load. System engineers who work with computer-based production control systems are especially quick to make this association. They think in terms of the various processes' capacities and the load that production orders impose on those processes. So when the load piles up to where it exceeds the capacity, the load "peaks" need to be leveled out.

But three things are clearly wrong about the load and capacity approaches to production leveling.

Let us address the first of this approach's problems by asking, "Who determines what a process's load is anyway?" The factory does, and usually for reasons of convenience. This is the first mistake. The factory people are saying this is their capacity, regardless of what the client requires. They need to stand that approach on its head and make the client's needs the factor that determines the capacity.

The second mistake is to break up the load of orders from customers once that load exceeds the predetermined capacity. Orders from customers should be treated with more respect than that. Instead of breaking up the load and thereby lengthening lead-time, the factory should pursue other options, such as temporary overtime work or subcontracting.

The third mistake in this approach is that it relies on people who sit at their desks with pen, paper, and calculator or computer and plan production schedules, but do not know how to make the products. It is the old ivory tower syndrome. The farther production planners are from the production line, the more impractical their planning becomes. Instead of working out uselessly detailed production plans, they need to plan directly for client needs. The simple way is the best way.

For JIT improvement, leveling means thoroughly leveling out product types and volumes in accordance with customer needs. In other words, we begin by breaking down the monthly production output into daily units. Then we compare the daily volume of products with the operating hours and calculate how many minutes it should take to turn out each product unit. We call this unit production time "cycle time." Then we figure out how many people are needed and what the capacity is (see Figure 1.9). Naturally, this requires organizing manpower based on the production lines instead of organizing production lines based on a fixed number of workers.

It is all too easy to find factories that calculate such things as production capacity and production line speed based on the equipment or the maximum number of worker hours. That approach is fundamentally wrong. It bears repeating that it is the customer—not the factory—who should determine how many products are to be made and how quickly. This fact must never be forgotten.



Figure 1.9 Estimate-Based Leveling and Reality-Based Leveling.

Step 5. Standard Operations

It so happens that many of the important elements we work with in factories begin with the letter "M": manpower, materials, machines, methods (such as work methods), and money (economics).

Standard operations are those operations which have been determined as best achieving and preserving an effective combination of people, goods, and machines in order to produce high-quality products economically, quickly, and safely.

Again, we must deal with a common misconception. Many people mistakenly think of standard operations as being the same as standard operating procedures (SOPs). The difference is that SOPs are only standards for individual operations; they are merely part of what we mean by standard operations.

Standard operations are standards that string together a series of operation-specific SOPs in a particular order to build a certain product. As such, they are more like "standard production procedures" than standard operating procedures.

In addition, standardized work procedures serve a dual purpose. They not only help standardize production, but they also help reveal current operating conditions. In view of this dual purpose, the proper way to establish standardized work procedures is to follow the steps listed below.

- *Step 1: Reveal current operating conditions.* The first thing to do is to discover and analyze the actual net time currently required for work operations and the way in which operations are really being performed.
- *Step 2: Ferret out the problems.* Use the cycle time as a standard for ferreting out problems regarding the work balance, ergonomic factors, variation, and so on.
- Step 3: Find out the real causes and plan improvement. Repeatedly ask "Why?" along with other key questions (the "5 Whys and 1 How") until you discover the real cause of the problem, then plan out an improvement to resolve it.
- Step 4: Implement the improvement. Go into the factory and implement whatever improvements are needed concerning operations, hardware, layout, and the like.
- *Step 5: Standard operations.* Once you have improved the operations, establish them officially as standardized work procedures, which will again come under scrutiny during the next improvement stage.

From Vertical Development to Horizontal Development

The first two steps in introducing the JIT production system, the awareness revolution and the 5S's, should be developed throughout the factory and/or company. Obviously, the 5S's step will not work unless the awareness revolution step has been taken. The company is not ready to begin the second step until the awareness revolution has taken root, at least to some extent.

Once the awareness revolution and the 5S's have thoroughly penetrated the factory, JIT improvements can begin. These improvements begin with what is most obvious and expand from single improvement points to "lines," and finally to "planes" and "cubes." Below are descriptions of each expansion phase.

Point Improvements

Even Just-In-Time improvements cannot begin with flow manufacturing. Instead, they must begin with a rooting out of the basic causes of workpiece pile-ups at certain processes and a change in production methods to eliminate the need for product warehouses. We must ask the basic question "Why?" at each point where workpieces are being conveyed between processes, to find out whether such conveyance can be eliminated. We must observe each worker's movements and see if they can be made simpler, more efficient, and less wasteful.

These are all "point" improvements. Like seeds planted in furrows, these small point improvements must be carried out as a foundation to support larger improvements later on. (See Figure 1.10.)



Figure 1.10 Point Improvements.

Line Improvements

After accumulating a certain amount of point improvements aimed at workpiece pile-ups, wasteful conveyance, and the like, we reach a breakthrough point where suddenly things begin to flow. Such a phenomenon indicates that enough point improvements have been made in the factory to pave the way for some line improvements. From a technical viewpoint, this is where flow manufacturing begins.



Figure 1.11 Line Improvements.

Once we start making line improvements in the factory, it is time to change the production method from "push" production to "pull" production, plan for production leveling, and develop standard operations. It is also important that we move promptly to make improvements whenever problems occur in the flow of work-in-process and that we practice "visual control." These are the kinds of activities I call "line improvements."

Line improvements always occur as the result of an accumulation of point improvements. There is no sense in trying to force a quantum jump to line improvements without any foundation. Neither is it wise to try to use rigid rules for drawing a straight line from one desired improvement to the next. But we need at least to understand the line's starting and ending points in order to know what kind of line we are drawing. This kind of drawing between points is called "vertical development." (See Figure 1.11.)

We generally use this kind of vertical development to build model lines. Model lines can be selected for a particular type of production line segment or for a particular type of product. In either case, the person in charge of the model line must be someone who is really enthusiastic and eager to do a good job.

Plane Improvements

Once we have vertically developed improvements on our model line at the selected production line segment, we are ready to display the model line to people at other processes to use as a reference for carrying out their own point and line improvements. This way, a single line improvement at



Figure 1.12 Plane Improvements.

one part of the factory floor becomes two and then three lines at various other parts until, finally, the whole factory floor has been improved. This is "plane improvement." We also call this type of follow-the-model improvement "lateral development," as illustrated in Figure 1.12.

Cube Improvements

Product manufacturing cannot be done well by a factory alone. The factory needs market information from the company's sales arm and component deliveries from buyers and outside vendors. It also needs a distribution organization to deliver the finished products to market.

Once the circle of JIT improvement has expanded to where it encloses the entire factory, it can be gradually raised to other "planes" outside of the factory. In this way, plane improvements become "cube improvements." (See Figure 1.13.)



Figure 1.13 Cube Improvements.

Organizing for JIT Introduction

JIT production is an "industrial revolution" that aids corporate survival and helps revolutionize employee awareness. This means that JIT production is a form of innovation, and innovation requires casting away fixed ideas and old habits. As such, JIT introduction is not something we can do in our spare time. It is a major undertaking, and to get substantial results it desperately needs the support of top managers cheering, "Let's get to it!" and factory floor leaders urging, "Let's move this thing forward!"

The entire company has to get behind JIT introduction as a sort of company-wide "JIT Improvement Project." Figure 1.14 illustrates the method for promoting company-wide involvement in JIT introduction.

JIT improvements are neither academic accomplishments nor problem-hunting tours of the factory by the technical staff. As shown in Figure 1.14, they are nuts-and-bolts changes that work their way through the entire production organization to improve the factory.

Such improvement organizations for JIT production cannot succeed unless everyone carries out his or her duties seriously and enthusiastically.

 The president's duties: Company-wide reinforcement of JIT production.

Just-In-Time includes more than production. JIT must also be extended to all other arms of the company, such as sales, procurement, subcontractors, distributors, and so on.

Duties of the factory superintendents, division chiefs, and department chiefs: Establishment and company-wide achievement of goals for JIT production.

Most factories run on an internal organization that has evolved and developed over many years. That is why two factories that belong to the same company may be quite different from one another. Faced with such long-cultivated traditions, JIT improvements cannot succeed unless the factory management—including the supervisor, division chiefs, and department chiefs—all get involved. It is especially important that they get involved



Figure 1.14 Promotion of Company-wide JIT Production.

in such things as improvement follow-ups and ensuring the thorough implementation of JIT production.

- Duties of department chiefs and section chiefs: Giving guidance, education and training in JIT production, and creation and management of JIT improvement teams. Even within the same factory, we often find that JIT improvements reach different degrees of advancement in different departments. When advancement is poor, much of the blame can be placed at the feet of the department chief and the section chiefs. An unenthusiastic department chief alone is often enough to slow progress. Or perhaps the section chiefs are just following orders and have no real interest in what they are doing. Successful JIT promotion groups include department and section chiefs whose enthusiasm attracts the interested participation of the foremen and equipment operators.
- Duties of section chiefs, foremen, and equipment operators: Gaining hands-on experience in JIT production and ferreting out and studying problems.

The foremen and equipment operators are the ones who best understand how the factory works. By the same token, they are the ones who tend to be most reluctant to discard the traditional way of doing things. Therefore, they need to gain a great deal of courage and fervor to overcome such reluctance. They need to be convinced that there is no use complaining about the changes. There is, on the other hand, every reason to push forward to make the improvements.

Figure 1.15 shows an example of how one company set-up its promotional organization.

How to Promote and Carry Out JIT Improvements

Once we have set-up an organization for introducing JIT production, we are ready to begin improvement activities.



Figure 1.15 Example of Promotional Organization for JIT Production.

However, these are not improvements in the ordinary sense of the word. Instead, the factory is looked at as a dynamic system, and improvements made as if to a living entity.

Conventionally, small improvements in the factory occur every day and have an accumulative effect. In factories where improvement activities are assigned only to a certain group (or even just one person), improvements can still be accumulated, but it is a very difficult task. That is why the factory needs a company-wide promotional organization.

In addition, there are five key points to observe in introducing JIT improvement activities.

Point 1. Set-Up an Improvement Promotion Office

Set aside an empty room in the factory. The room should be large enough for about ten people, or however many are on the improvement project team. This is the room where improvement teams can come to work out an agenda of problems and brainstorm corrective measures. The room should never be used as a recreation room.

The improvement teams should meet here one day a week to study improvement issues. The other days they should be busy carrying out improvements.

Point 2. Have at Least One "Improvement Day" a Week

For all improvement project members, the cycle of improvement meetings and activities should be at least weekly. Do not let people get the idea that they should only be making improvements on the day meetings are held. On nonmeetings days, people in every part of the factory should be busy carrying out improvement measures.

"Improvement Day" activities should also include progress reports on current improvement campaigns, brainstorming for new improvement points, and assignment of improvement activity duties.

Point 3. Improvement Meetings: One Hour Is Better Than Two Hours

Improvement meetings are not the goal of JIT improvements. The first and foremost goal is to make the necessary changes to create a factory that effectively responds to market needs. Just sitting at a desk and talking about improvements is not going to change anything.

Therefore, the meetings should be short and to the point. We simply figure out the key agenda items, brainstorm improvement ideas, assign improvement jobs, set a delivery deadline, then get back to the factory to start making the improvements. We should try to finish the meeting within an hour, or within two hours at the most.

When scheduling the meetings, be sure to avoid meal times when people need to eat. Eating is important to labor productivity. The best time for improvement meetings (Figure 1.16) is usually in the evening, right after work.



Figure 1.16 An Improvement Meeting.

Point 4. Create an Improvement List

During a one-hour walk through the factory, any sharp-eyed observer can usually spot ten to 15 items in need of improvement. All items should be entered on an improvement list to be used for proposing improvement ideas at weekly improvement meetings.

The items do not have to be typed. The list can be on a blackboard or poster on the wall of the improvement promotion office, where people can casually jot down things they have noticed. However, the list should contain columns with the following headings to enhance clarity:

- 1. Improvement number
- 2. Improvement item name
- 3. Description of improvement
- 4. Related section/department
- 5. Improvement leader
- 6. Delivery deadline
- 7. Result

Because this list will be used for making improvements, it is important that every column be filled in to keep the status and progress of improvements as clearly visible as possible. It is the responsibility of the improvement project leaders to check the "Result" column at each meeting to gauge the overall progress of improvement activities.

Point 5. Improvements Happen in the Factory!

Improvement meetings are basically for confirming the previous week's improvement campaigns and assigning duties for the next week's campaign. After that, it is time to get back to the factory where improvements actually happen.

Once the meeting is over, the various improvement teams such as the equipment layout team, jig redesign team, and 5S's enforcement team—should go directly to the places in the factory where the improvements are to be made. The improvement teams may be there until late in the evening, but when they finish, they will get a sense of real achievement. Making improvements cannot be done halfheartedly or left half done. A "hang in there" attitude must be maintained until the end.

Chapter 2

Destroying Factory Myths A Revolutionary Approach

Relations among Sales Price, Cost, and Profit

- 1. Costs + profits = sales price
- 2. Sales price profits = costs

What do you notice when you look at these two equations? If you get the impression that they say the same thing, you have a knack for math. Mathematically, there is no difference between the two equations. However, if you are a business manager or someone fluent in finance concepts, you would recognize the equation's algebraic similarity, but you would also insist that they are two completely different ways of thinking.

How can we explain this?

In the first equation—costs + profits = sales price—the method for determining the sales price is to add a profit margin onto costs. Specifically, we first identify and add up all the costs involved in manufacturing a planned commercial product. Then we tack on a profit margin to reach a sales price. We can call this the "cost up" method.

The second equation—*sales price* – profits = costs—sets the sales price according to the market price.

To do this, we first find out how much the planned product will likely fetch on the market and take that value as the sales price. Then we need to decide how big a profit margin is required. The total costs are what is left over when we subtract the profit from the sales (market) price.

After that, we can go on to ask questions like, "What kind of materials can we use and still keep the costs within the equation's total cost figure?" We can also work out our choices of production methods and labor resources in this way.

The *costs* + *profit* = *sales price* approach is based on predetermined costs, and is therefore a production-oriented approach. In Japan, the latest jargon describes this as the "product-out" approach.

On the other hand, the *sales price* – profit = costs approach takes the opposite direction by starting with the market as a base. It is therefore a market-oriented (or "market-in") approach.

Which approach do you think is better suited to today's highly competitive markets? In a mature market, the productoriented approach will only work for an extraordinarily popular and distinctive product. Otherwise, the product would be outsold by similar products whose prices follow downward moving market trends. In addition, we should not regard profit as a side product. Instead of being pleasantly surprised by the appearance of a profit, we should take more positive steps to ensure one.

The sales price is almost always being pushed downward by market needs. That leaves only one viable method for squeezing a profit out of the equation: lowering costs.

In recent years, the companies that have been the biggest profit-earners are the ones that have been best able to keep costs down. The losers have been those that have not been able to cut costs. You cannot blame many of the losers for not trying. Many have tried Total Quality Control (TQC), cost reduction projects, suggestion systems, small group activities, and various types of employee committees, but none of these have been thorough enough to bring real success. Many of the losers in today's tough markets have been companies that sincerely pulled together in pursuit of certain goals. The problem for them has been the same old story: the attitudes of employees, many of whom lack the confidence or courage to reach the goals. Employees who think of what they cannot do instead of simply planning the next step ahead are the root of these failures. The key word here is "innovation." Companies that forget that word are just biding their time until bankruptcy.

Another key concept is that profit is not something that "pops out" of the manufacturing and marketing processes and lands in the laps of the company employees. Rather, it is something the company has to create and earn through hard work.

Companies have to take a more positive attitude toward profit-earning. They have to be creative and come up with devices and schemes that will help create profit. The way to start is to *throw out every single conventional idea*. The factory's local mythology—the proud tales of how many years the factory has been turning out good old Product X—has to be discarded and replaced by a cold, hard look at market needs.

Some companies have been able to do this, and some have not. Some just do not have the inner strength for it. Let us briefly examine what the anatomy of an unprofitable factory might look like, as illustrated in Figure 2.1.

In this example, the company figures its sales price using the production-oriented method, and then launches its sales activities. However, the actual costs turn out to be much more than the original estimate. This shrinks the profit to a modest or very small amount. Unless the factory can recover its profitability, morale will start to sink.

Some belt-tightening is needed, and such things as R&D and improvement campaigns are the first to go. Soon the factory falls into the bad habit of slashing precisely the programs that might alleviate the problem. Such short-sightedness ends up creating a genuinely unprofitable factory.

Now let us compare this money-losing factory to the one whose anatomy is shown in Figure 2.2.



Figure 2.1 Anatomy of an Unprofitable Factory.



Figure 2.2 Anatomy of a Profitable Factory.

As can be seen, anatomically speaking, these two factories are almost complete opposites. In the latter case, the sales price is set according to the "going price" on the market.

The company's sales division is busy carrying out energetic marketing activities in sales promotion, distribution channels, and other areas. Meanwhile, all of the employees in the production division are equally busy with broad-reaching efforts to completely eliminate human errors, product defects, and waste. As a result, the company is able to maintain sales, suppress costs, and turn a good profit.

When profits rise, so does employee morale. In addition, management is more willing to underwrite such initiatives as R&D, sales promotions, plant investment, and improvement activities.

Here we have an example of a profitable factory, fueled by innovation. And remember, innovation is the key to success.

Ten Arguments against the JIT Production Revolution

People naturally tend to harbor a mild affinity toward one another. Co-workers tend to harbor a very strong affinity with their system of "the way things are done," which they have built together over the years. As far as they are concerned, no system could be better for them. They have no desire to change it. After all, their routine is leveled and is very easy to live with. Even in the finest-looking factories, life goes on in the traditional, albeit obsolete, manner.

Improvement starts at the factory:

"Hey Joey, could you roll that set of machines over here? I want to link them up with this process."

"Hey, no way. Why all the hassle?"

"Haven't you heard? We're dropping this lot production stuff and gearing up for one-piece flow."

Ten Arguments Against JIT Improvement

- **1.** JIT improvements won't do any good!
- **2.** It sounds like a good thing, but we still don't want to do it!
- 3. Looks good on paper, but ...
- **4.** Costs are already as low as that can possibly get!
- **5.** But we've already been doing things that way!
- **6.** We don't want people looking over our shoulders and telling us what to do!
- We can't lower costs any more without lowering quality!
- 8. Everything is going just fine now. Why change it!
- **9.** That's a lousy idea! We already tried that 20 years ago!
- **10.** Look, we understand this stuff better than anybody (so don't tell us what to do).

Figure 2.3 Ten Arguments against JIT Improvement.

"Do you have any idea what kind of quality problems these changes are going to create?"

"Come on, move it. I want you to have this set-up for onepiece production before I come by again."

"If you say so, but it won't work."

The three common excuses encountered at this point boil down to: "I don't want to change things," "It's too much trouble," and, "I'm afraid I'll get laid off."

Aside from these common excuses, I have been able to identify ten arguments against JIT that are often encountered on the path of JIT improvement. Figure 2.3 lists these arguments.

These are just some of the wide variety of anti-JIT arguments one runs into when trying to promote JIT improvements.

To elaborate a bit:

1. "JIT improvements won't do any good!"

Here we have a sweeping condemnation of the whole JIT improvement program.

- 2. "It sounds like a good thing, but we still don't want to do it!" and
- 3. "Looks good on paper, but..."

Here we have agreement in general and disagreement on all particulars.

- 4. "Costs are already as low as they can possibly get!" and
- 5. "We can't lower costs any more without lowering quality!"

Here the obstacle is the fixed idea that costs are already at their minimum.

- 6. "But we've already been doing things that way!"
- 7. "We don't want people looking over our shoulders and telling us what to do!" and
- 8. "Everything is going just fine now. Why change it?"

Here we have a general reluctance to change the status quo. This is very common among workers in factories that are still managing to turn some kind of profit.

- 9. "That's a lousy ideal! We already tried that 20 years ago!" and
- 10. "Look, we understand this stuff better than anybody (so don't tell us what to do)."

Finally, here we have the kind of resistance that is born out of cockiness and defensiveness.

Alas, JIT means having to deal with all kinds of people and their reluctance to change. JIT improvement has tended to stir up the same old resistance that has arisen many times in the past. Many years ago, General Electric ran into the same kind of resistance when it was making big changes with VA/VE programs. Innovations come in waves. Each time a new wave of innovation comes roaring in, the environment must be flexible enough to adapt to it. People are innately tough customers when it comes to buying ideas that threaten the status quo. And in factories, the word "change" is virtually taboo.

Nevertheless, JIT improvement requires that all fixed ideas be cast aside so a new consciousness suitable for the new environment may be cultivated. Achieving this task takes much longer than merely improving operations or equipment. It demands that the very same things be done again and again.

From the company president down to the factory workers, the subject of improvement has to be openly discussed. During such discussions, we are bound to run into negative comments, such as, "There's no way that JIT stuff is going to work in our factory."

There is also the idea that the people responsible for JIT improvement are not qualified for the job. In such cases, they can prove their point by asking the disgruntled factory people a few pointed questions, such as:

"Look at your factory. Defects are out of control, shipments are always late, and warehouse inventory seems to have no limit. What are you going to do about it? What specific plans do you have to solve these problems?"

The response to that is usually dead silence. Sometimes, you have to challenge fixed ideas directly.

People are not going to unleash themselves from their gut feelings of resistance and their fixed ideas unless they are instilled with the basic spirit of improvement. Figure 2.4 shows a policy statement illustrating this basic spirit at a kitchenware company. Figure 2.5 shows a manifestation of this spirit at a fishing equipment manufacturer.

These signboards usually measure about one square meter and are made of vellum. They can be either hung from ceilings or posted on walls. It is a good idea to display these signboards not only in management meeting rooms, but also





in factory meeting rooms and at various processes along the production lines.

This way, whenever someone starts griping, "We can't do that," we can save our breath and just point at the sign.

These signboard statements of the "basic spirit" for improvement can serve as bold reminders for workers who have forgotten what the basic spirit is all about.

If not out of sight, the "basic spirit" is less likely to be kept out of mind.

Approach to Production as a Whole

Fixed Ideas and the JIT Production Approach

In most factories, fixed ideas about how things should be manufactured are unwittingly created over the years. The fact that they get created is bad enough. Worse still is the fact that they are quickly adopted as the gospel truth.

In other words, such fixed ideas are developed into a local "mythology" at each factory, and the factory's inhabitants are



Figure 2.5 Policy Statement at a Fishing Equipment Company.

naturally suspicious of anything that threatens to desecrate such sacred lore as the following.

- "Economy means economy of scale: Lot sizes must be at least 1,000 units."
- "Fine-tuning the dies is how a die press operator shows his skill."
- "Sampling inspection is the most intelligent way to find defects."
- "Stand to work? You must be kidding! This work takes precision handwork, and you've got to sit down to do that."
- "I've been working here for 20 years and I've already figured out the best way to do this job."

I could go on for pages and pages with more of these "myths." There seems to be an inexhaustible supply of "why it's got to be done this way" myths at every factory.

The people who still subscribe to these myths have little idea how outdated they became when the "whatever you make will sell" era came to a close. They may hear consumers complain, but they don't really listen to the complaints and think about them.

It is amazing how many factories are still like that.

When visiting such factories to discuss the JIT production system, I have sometimes gotten the impression that introducing JIT improvement programs at factories so firmly rooted in shish-kabob production is like praying to a horse or giving a penny to a cat.

As I said earlier, we have to begin with the awareness revolution. It is a good idea to somehow make the need for a change in consciousness a topic on everyone's mind at both the start and end of the workday routine. It is also a good idea to make the adoption of the JIT production system a theme for QC circles and other small group activities. Another effective device is to invite outside experts to give employee seminars.

If the 5S's are the foundation for improving the factory, then we could say that the awareness revolution is the premise for JIT production. If we can change people's minds, we can do anything.

JIT production system concepts should be used to overhaul conventional thinking and cannot simply be used to supplement the old philosophy. Hard as this is, JIT awareness revolution means discarding work methods that are the result of years of study and experience, and long-accumulated know-how. It even goes beyond that and requires everyone to consider the present way of doing things as the worst possible way.

The kind of "improvements" called for by the JIT production system are not the easy kind of minor improvements that make current conditions a little bit better. JIT improvements begin in the mind, expand to every corner of the factory, and take root to radically change the factory. They do not simply make the current situation a little better. Each JIT improvement is an innovation, a revolutionary advancement that introduces a whole new concept and methodology. It is probably more correct to describe the activity of JIT improvements as "revolutionizing the factory" rather than merely improving it.

Likewise, a JIT awareness revolution does not just improve our ideas about manufacturing systems—it introduces revolutionary, boldly innovative ideas.

Lesson 1. JIT Means Innovation

"Just-In-Time"

To put it briefly, Just-In-Time means manufacturing and procuring "just what is needed, just when it is needed, and just in the amount needed." The Just-In-Time concept must be applied not only to manufacturing, but to all other aspects of the business, including subcontracting, procurement, and distribution.

As mentioned earlier, Just-In-Time tends to be interpreted as meaning "in time," which is quite wrong.

The "In Time" concept is already fairly well observed in factories everywhere. After all, a factory cannot function unless its buyers and subcontractors deliver their goods in time for them to be used in the factory. Similarly, a downstream process cannot operate on workpieces until the workpieces have been finished at the previous upstream process.

Outside vendors and subcontractors all have deadlines for the products they deliver to specific processes in the client factory. These deadlines are extended down the line as a delivery deadline for product shipment to sales firms, and then as the sales firms' delivery deadline for shipment to customers.

If we think of Just-In-Time as simply beating the delivery deadline, we understand very little of what JIT is all about. Beating the delivery deadline is what "in time" means. Just-In-Time means something quite different.

Let us suppose next Friday is our delivery deadline date. The In Time concept interprets this as meaning we need to deliver our products by next Friday. We could deliver them next Thursday if we wish. We could even deliver them on Monday. Or, if they are ready now, we could send them over immediately and not even wait for next week.

The same principle can be seen at work within factories. For instance, next to the press machine there might be a large pile of workpieces that has been sent down from the previous process. The In Time concept says that is OK. In fact, though, the workpieces are a little *too much in time*.

Compare that with an example in which the press operator calls out "Ready!" and immediately receives a single workpiece from the previous process. He presses it, then calls out "Ready!" again and receives another workpiece. Here we have a manifestation of the Just-In-Time concept.

But even when we add the term "just" to "in time," we still are not saying half of what Just-In-Time really means.

This is because the JIT production system is more than just a new production method and production system for maintaining delivery deadlines, building things in small production runs, and so on. It is also a technique for thoroughly eradicating waste by rooting out deep-seated waste wherever it exists in the company—in both factories and offices—and using JIT improvements to eliminate the waste.

Let us consider for a moment just how thorough this eradication of waste under the "Just" concept really is.

For example, if we interpret the "just" in Just-In-Time as meaning "about one month," that means the factory is allowed to operate with one month of inventory-related waste.

If we take the "just" to mean "about one day," then we will have a day's waste. We can go on to even smaller time increments, such as an hour, minute, or second, and in all of these cases we are managing the factory based on a waste measure. The JIT production system uses the "just" in Just-In-Time as a waste gauge. In this sense, this Just concept lies at the very heart of the JIT production system, and this system will not work at factories that have forgotten to eradicate waste as thoroughly as possible. Likewise, a person who doubts the need to thoroughly eliminate waste will not be able to capably carry out JIT improvements.

If the reader is such a person, I suggest he or she put down this manual, and just get back to work.

Lesson 2. Take "Just" to the Max!

Production Is Music: Help Your Factory Play a Masterpiece

I'm not really talking about inviting an orchestra into the factory to perform. But music does serve as an apt metaphor for the sweet harmony of a level-running factory. Production is a lot like music. Waste-free production is like a stirring composition, a masterpiece if you will. Music includes three essential ingredients: melody, rhythm, and harmony. In masterpieces, all three of these elements are masterfully composed and performed. Conversely, no matter how original and alluring the harmony is, if the melody is awkward or the rhythm inconsistent, the result will be less than a masterpiece.

The exact same thing goes for the hum of product-building in factories. What does the factory offer as the closest analogy for melody? On a sheet of music, the melody is usually a string of notes placed according to tone on the five-line treble clef form. I suppose the factory analogy for the melody would be the flow of workpieces from one process to the next. Sometimes this flow continues in straight lines, and at other times it makes U-turns. Sometimes the workpieces move along one at a time, and at other times they flow together in lots.

The most melodic of factory melodies is the "flow manufacturing" system.

What would serve as an analogy for rhythm? There are so many types of rhythm, from the graceful waltz to the snappy tango and the fast-paced rock 'n' roll beat. In the factory, the rhythm is the pitch of production, the rate at which work-inprocess moves through the flow of production. We also call this the cycle time. Some products can bebop through the line with a very rapid rhythm while others need to waltz along.

The rhythm of the factory must be "leveled" to keep in pace with the cycle time.

Finally, what can we call the harmony of the factory? Harmony means a concordant combination of tones, a blend that is pleasing to the ear. The factory makes harmony when its people, materials, and machines come together in a waste-free combination that unites all three in harmonic activity.

"Standard operations" are what we use to build such an efficient and harmonious combination of people, materials, and machines.

Thus, production—like music—has three essential ingredients. Flow manufacturing, leveling, and standardized operations are to production what melody, rhythm, and harmony are to music. (See Figure 2.6.)

These three elements make up the lion's share of what is needed to establish JIT production and are the mainstay for introducing the JIT production system. Please remember this as part of the procedure for introducing JIT production. And please remember that it takes much time and effort to create a factory that can delight us with masterpiece production.

Music	=	Production
Melody	=	Flow production (one-piece flow)
Rhythm	=	Leveling (cycle time)
Harmony	=	Standard operations (combination charts and operations charts)

Figure 2.6 The Three Essential Elements of Music and Production.

Lesson 3. Production Is Music

The Next Process Is Your Customer

In Japan, it is not hard to find factories that have "The Next Process Is Your Customer" signs posted here and there. Usually, this saying is understood as referring to the need to provide good quality and to prevent defects. In other words, since the next process is your customer, be sure to deliver only the best products.

However, if you have a close look at these factories, you will find that many of them operate completely under a "push" method of production. This robs some of the true meaning from "The Next Process Is Your Customer" slogan.

When looked at in terms of how goods are moved through the line, there are only two types of production methods. (See Figure 2.7.)

The first is the method in which workpieces that have been finished at one process are immediately sent on to the next process. This is what we call "push" production. Sometimes this method calls for transfer tags to be attached to each workpiece, and the tag is marked each time the workpiece is transferred downstream. In this method, the movement



Figure 2.7 Push Production and Pull Production.

of goods is not sensitive to the readiness of the receiving process. At each process, workers simply follow the production schedule in deciding what to do next. Once that is done, they send the finished workpiece along to the next process. We could say that the previous process is "forcing" the sale of its product to the customer at the next process. If the next process does not happen to be ready for the workpiece, the worker there has to say something like, "Oh, you've finished another one already. Well, just set it down over there." Soon there is a work-in-process pile.

In stark contrast to this is the "pull" production method, in which the "customer" at the downstream process goes to the previous process to get "just what is needed, just when it is needed, and in just the amount needed," which he pays for with a currency called *kanban*.

This makes the previous process a sort of "store" that the customer (next process) visits. Of course, the store is responsible for selling only high-quality merchandise to its customers.

The key difference between these two production methods is their respective proximity to the production method called for by the production schedule. In other words, it is the way they relate to the flow between information and materials.

This flow between information and materials is illustrated in Figure 2.8. In the "push" production example, the final assembly schedule (i.e., production schedule) is used as the basis for creating delivery schedules for all of the subassembly, processing, and materials processing stations. All of these stations are part of the in-house production system.

The same delivery schedule also includes delivery deadlines for parts procured from outside vendors and subcontractors. There are various names for this kind of production planning, such as "required volume planning," "parts development," or Material Requirements Planning (MRP). Note that MRP is usually a computer-based system for schedule parts and materials deliveries based on the production schedule.



Figure 2.8 Flow of Information and Materials in Push and Pull Production Systems.

Usually, the production schedule must deal with a complex array of components numbering in the hundreds, thousands, or even tens of thousands, and often a computer is brought in to assist in the scheduling tasks.

The major drawback is that the information and materials are not matched. The information is out anywhere between three days and a week before the goods. In other words, the required volume planning is completed several days before the planned products are manufactured at the factory. It is during these several days that the required goods are delivered to the factory and operator instructions are issued.

Another problem is that each process operates according to its own instructions, completely independent of other processes. We call this type of production "independent process production." Independent process production suffers from inflexibility in the face of scheduling changes. For various reasons, the production schedule might undergo one revision after another, but these changes cannot be easily carried over to the individual production processes. As a result, the first "official" delivery deadlines in the original production schedule become firmly established as each independent process's delivery deadline and are thereafter very difficult to change. The process station's workers tend to regard such last-minute changes as an intrusion and a hassle. This does not bode well for these Japanese factories in today's era of a high yen, ongoing trade friction, and diversifying customer needs.

By contrast, the "pull" production method has, in principle, no delivery schedule save for the final assembly schedule (production schedule). The main assembly processes "pull" just what they need from the subassembly processes. Since the subassembly processes use processed parts, they in turn pull just what they need from the processing line. In other words, nothing happens upstream until something has happened downstream. Since production at the previous (upstream) processes depends on production at the next (downstream) processes, we call this production method "previous processdependent production." This type of production emphasizes the true importance of the next process as the customer.

In light of these two very different types of production, we could argue that at most of the factories that display "The Next Process Is Your Customer" signs, the real meaning of the signs is "We pretend to use *kanban*." Unless the factory is actually using pull production instead of push production, its *kanban* do not amount to anything more than a "theoretical" or "decorative" improvement. Unless the factory realizes the importance of matching information with the materials and aggressively revamps its whole production system with a "proactive improvement" attitude, the waste inherent in the push production system will not be removable. Lesson 4. The Ocean Pulls the Flowing River

"Stop and Go" Production and "Process and Go" Production

A factory where the company president is cautiously watching over the machines and equipment is a tragedy. The main character in this tragedy is not the president, but rather the equipment operators who live under the president's gaze.

Imagine a factory where the company president has just had the latest, most sophisticated equipment brought in, and now stands there telling the operators, "It's your job to operate these things. Get to it!"

Imagine, in this age of diverse models and small lots, a company president having installed all sorts of machines designed for mass production and then commanding the workers, "Set the machines up for the whole range of product models and start turning out products!" Imagine the kind of agony those workers are going through in trying to use machines that are fundamentally incompatible with the factory's needs.

No doubt the company president had thought that the latest machines and equipment would readily solve his factory's various problems.

He may be proud to inform us, "This is great! This new equipment will double our production capacity!" or, "This brand new equipment will take care of our quality problems.

He might even go so far as to claim, "This new equipment will enable us to meet our client's delivery deadlines."

Let us suppose that the factory has usually been incapable of meeting its client's short delivery deadlines, and that is one big reason why the president bought the latest equipment, which is supposed to cut processing time in half. The goal here is to shorten the manufacturing lead-time.

Shortening lead-time by reducing processing time is a mighty bold and eccentric way of doing things. We can spend
a fortune on faster processing machines and still not shorten the lead-time one bit. We might succeed, however, in shortening the life of the company.

When we look at production as a flow of materials, we can recognize four main categories of components in this flow: retention, transfer, processing, and inspection. The first thing this teaches us is that making things requires much more than just processing.

As we go through the manufacturing process, imagine that you are one of the parts that has been delivered to the factory and is about to undergo the entire lead-time of the manufacturing process. To start with, you are warehoused along with the other purchased parts and materials. This falls under the "retention" category. Now, it would be nice if the processing machines could walk over to the parts warehouse, pick out the things they need, and process them, but we have not reached that day yet. So the factory needs to move you and all the other goods from the warehouse to the processing machines, a task that falls under the "transfer" category.

Next, you and the other materials that have just been delivered to the processing machines sit in a pile until the machines finish processing the previous lot of materials. This sometimes takes a long time. At last, the machines start in on the first of your lot of materials. You are the last in that lot and are still waiting. All of this waiting is part of the "retention" category.

Finally, you—the last of the lot—are picked up and, in a few brief seconds, get processed. Those fleeting seconds are in the "processing" category.

After being processed, you are plopped onto a pile of processed units. Then you go through another round of retention, transfer to the next group of process machines, more retention, and processing.

To return to our music analogy, we can say that the four parts of this manufacturing process—retention, processing,



Figure 2.9 "Stop-and-Go Production" and "Process-and-Go Production."

retention, and transfer—comprise the four-beat bar of music that most factories use to add value to materials.

Just as only one four-beat bar can hardly be called music, we need to repeat the bar a number of times to create the "music of production." In view of retention's large role in this type of production, we shall call this type "stop-and-go production." (See Figure 2.9).

Within the four-beat, stop-and-go pattern of this type of production, the beats that take up the lion's share of the manufacturing lead-time are the two "retention" beats. In the example shown in Figure 2.9, there are eight retention stages from the parts warehouse to the products warehouse. Six of these retention stages are within the factory, where they directly relate to the manufacturing lead-time. There are lots of retention points, and together they eat up a lot of time. Once a pile of workpieces is set down somewhere, it tends to stay there for half an hour, an hour, or more. Sometimes part of the pile gets left there overnight to make operations or changeover more convenient. Meanwhile, parts that have been delivered to the parts warehouse can easily wait there for a month or more. Whether the total retention time adds up to hours, days, or weeks, it still eats up a tremendous amount of lead-time. Retention is clearly the worst culprit when it comes to lead-time consumption.

Materials do not do anything but wait at retention points. Having several retention points means we must have some means of moving materials from one retention point to the next. That is where the "transfer" category comes in.

The nice thing about this category is that it never comes close to eating up as much lead-time as the "retention" category can. In most factories, each transfer takes one or two minutes. Still, outside vendors can take several hours to transfer parts and materials to the factory. In any case, out of retention, transfer, and processing, transfer is the second worst culprit.

Inspection is a separate culprit altogether and should be considered apart from the categories that make up the four-beat pattern of production.

Finally, we have the "processing" category, which eats up the least lead-time. A single workpiece's total processing time in the factory commonly adds up to a minute or two. Most individual processes take less than a minute. Some take only several seconds. Press processes usually range between one and two seconds, while drilling machines average about two or three seconds.

It should be obvious by now that bringing in the latest production equipment to shave a few seconds off of the total processing time is not going to help much in reducing the overall lead-time to enable earlier product shipments to customers. A pressing need to meet the client's short delivery deadlines is therefore not much of a reason for any company president to invest in the latest production equipment.

Obviously, the best way to shorten the manufacturing leadtime is to get rid of the worst culprit: retention. Once we do that, our stop-and-go production system can be turned into a "process-and-go" production system in which the fourbeat pattern of retention, process, retention, and transfer are replaced by the four-beat pattern of process, transfer, process, and transfer.

Today, shorter lead-times are in big demand by consumers and are also a major factor enabling the expansion of client orders. Old and worn as the expression is, it still rings quite true in the world of manufacturing: "Time Is Money."

Lesson 5. When the Flow of Goods Stops, the "Lead-Time" Clock Keeps Ticking

Approach to Efficiency: Estimated Efficiency and True Efficiency

Factories are full of talk about efficiency. Factory people are always trying to improve the equipment operators' efficiency, the equipment's own efficiency, the efficiency of the operations, and various other types of efficiency. The prevalent attitude is, "Let's try to turn out products even just a little bit better than we do now."

Different people, however, have very different understandings of this "efficiency" concept. Most people view such things as efficiency and productivity as a ratio of "output"-to-"input." In other words, people think of productivity as the value of production output divided by the cost of production input. This definition is expressed as an equation below.

$PRODUCTIVITY = \frac{PRODUCTION OUTPUT}{PRODUCTION INPUT}$

Assuming that this equation is correct, one could propose three measures for boosting productivity *Measure 1:* Increase the production output.

$PRODUCTIVITY \uparrow = \frac{PRODUCTION OUTPUT \uparrow}{PRODUCTION INPUT \rightarrow}$

In this equation, I have used arrows to indicate constant levels (\rightarrow) , increases (\uparrow) and decreases (\downarrow) . *Measure 2:* Decrease production input.

 $PRODUCTIVITY \uparrow = \frac{PRODUCTION OUTPUT \rightarrow}{PRODUCTION INPUT \downarrow}$

Here, we have kept the production output constant (\rightarrow) but have lowered (\downarrow) the production input, which raises (\uparrow) productivity.

Measure 3: Increase production output and decrease production input.

$PRODUCTIVITY \uparrow = \frac{PRODUCTION OUTPUT \uparrow}{PRODUCTION INPUT \downarrow}$

This is a combination of Measures 1 and 2, in which we raise (\uparrow) productivity by lowering (\downarrow) production input and raising (\uparrow) production output. Obviously, there are also other ways to boost productivity, and there are various ways of applying the three measures just described.

When we think of "raising" productivity or efficiency, the notion of "raising" tends to lead us first to Measure 1, in which we aim simply to raise production output.

For instance, let us consider the example shown in Figure 2.10. Here, we have a factory that is trying to boost productivity by increasing the number of product units manufactured daily by ten people from 200 units to 250 units.

According to the productivity equations illustrated, the "estimated efficiency" plan in Figure 2.10 should have worked



Figure 2.10 Estimated Efficiency and True Efficiency.

to boost productivity. However, the important thing to note here is that *no matter how much we boost the production output, there is no real gain unless the client's production orders keep pace with the increase.* Making products that are not on order with a client is simply creating waste—overproduction waste and warehouse waste.

The most important equation to remember is:

Volume of orders = Production output

If the current volume of orders and the current production output are both 200 units, there is only one measure to use to boost productivity: Measure 2 (decrease production input). Cutting the required production staff from 10 persons to 8 persons would be a true improvement in efficiency. I would like to stress that *the manpower reduction approach is an indispensable means of improving efficiency.*

Therefore, the JIT production system would have us change the productivity equation to read as follows.

VOLUME OF ORDER = PRODUCTION OUTPUT $PRODUCTIVITY = \frac{PRODUCTION OUTPUT}{PRODUCTION INPUT}$

Lesson 6. The Customer Decides How to Improve Efficiency

Manpower Reduction

As in the case of "human automation" (*jidoka*) rather than "automation," manpower reduction also has a special meaning within the JIT production system. In Japan, this particular meaning of manpower reduction was born in the 1970s, when oil crises ushered in a "stable growth" era. From about 1955 until the early 1970s, Japan enjoyed a period of rapid economic growth with fast-expanding markets which encouraged manufacturers to restrict the variety of products and maximize the output volumes. Today's commonly known concepts of "automation," "labor reduction," and "manpower reduction" have been inherited from the rapid-growth, small-variety, large-lot era.

The validity of these concepts and their methodologies has steadily diminished in recent years. Market expansion is no longer a given, and consumer needs are clearly becoming more diverse and individualized. In order to continue to provide products attuned to market trends, manufacturers are being forced to switch over to wide-variety, small-lot production.

While expanding product variety and shrinking modelspecific volumes, manufacturers must also keep their prices down to succeed in today's highly competitive markets. This difficult business environment encouraged the development of the "worker hour minimization" concept behind JIT's manpower reduction. Basically, this concept says that production should have an output matching market needs, using the minimum number of workers (minimum labor cost) to produce that output in a timely manner. (See Figure 2.11.)

We are all familiar with the popular "labor reduction" and "employee reduction" concepts. Both of these concepts remain within the framework of rigid staff assignment systems. Generally, each equipment operator is responsible for handling only certain different types of equipment. As a



Figure 2.11 Labor Reduction, Staff Reduction, and Manpower Reduction.

result, the staff assignment system is not flexible enough to accommodate suddenly lower market demand for some of the company's products.

Strictly speaking, *labor reduction* means that even when the market demand drops or automation advances, the company does not decrease the number of its workers. Instead, the company only reduces the amount of labor the workers perform. Personnel costs remain the same.

Staff reduction means reducing the number of staff when demand goes down or when automation makes workers redundant. The redundant workers are still kept within the same rigid staff assignment system. This has nothing to do with market fluctuations, but is done simply to reduce staff at certain jobs.

By contrast, *manpower reduction* means promptly changing staff assignments at each process in the factory to reflect the latest market changes. Once it is known what the current client orders are, the factory produces exactly that volume of products while using only the smallest required number of staff. Obviously, this system requires a flexible staff assignment system instead of a rigid system. Thus, the basic principle of JIT manpower reduction is prompt and flexible adaptation of factory operations and staff assignments to incorporate current market trends. As such, JIT manpower reduction goes hand-in-hand with a flexible production system and contingency management.

The following essential items enable such manpower reduction and market adaptability.

Flow manufacturing—One-piece flow manufacturing in pace with market demands is essential for JIT manpower reduction. Instead of allowing materials and products to pile up, one-piece flow manufacturing turns out just what is needed, just when it is needed, and in just the required amount.

Multi-process handling—This means linking production equipment in lines that suit the flow of products, and having each operator handle several processes within the flow manufacturing system. This requires that operators stand (and walk) while they work, and that they be trained in various equipment-operating skills.

Separating human work and machine work—This process begins by grouping all the little "islands" of operators and their equipment into a flow-oriented line (or manufacturing cell), thus placing together both people and machines. Next, the operators get trained in multi-process handling and are taught how to separate their work from the machine's work. Finally, they work out ways to reduce human work (such as in setting up and removing workpieces) by changing conveyor configurations or other means.

Movable machines—No matter how brilliant an improvement plan is, it may end up in the trash can if machines are unable to be moved to positions specified by the plan. Needless to say, such obstacles can put a damper on enthusiasm for improvement. The worst offenders are the machines that have been bolted to the floor, seemingly stuck there for eternity. Since the market is always changing and improvements make progress from day to day, it only makes sense that equipment



Figure 2.12 Attaching Casters to Make Equipment Movable.

should be movable enough to enable equipment layout changes when switching production over to different product models. Figure 2.12 shows an example of how immovable equipment can be made movable.

Standard operations—Operations that vary from person to person create big problems. Instead, we need to standardize operations and develop *jidoka* to make the operations standard and simple enough for anyone to learn easily. We begin by standardizing current operations and then proceed to make improvements.

Flexible staff assignment system—Instead of the traditional fixed staff assignment system, we should be using a system that is flexible enough to accommodate staff assignment changes in accordance with labor requirements set by market demand.

Mutual aid system—Even the best-laid plans for balanced workloads can run into trouble when the production pitch gets too high or when some other problem causes an imbalance in workloads. To prepare for such eventualities, workers should be able to temporarily lend a hand to adjacent upstream or downstream workers. Such "mutual aid systems" are especially helpful during that tricky phase when process improvements are being worked out. As such, the mutual aid system should be considered a prerequisite for improvement programs. Lesson 7. Move from Labor Reduction to Worker Hour Minimization

Individual Efficiency and Overall Efficiency

Imagine a home electronics manufacturing plant, in which 20 or 30 female assembly workers are standing along an assembly line conveyor, busily building TVs or VCRs. Those not familiar with this kind of work find such an arrangement quite amazing. They also wonder exactly what all those assembly workers are doing.

Almost all of the workers on such assembly lines perform work that includes five or six simple screw turns or wire bonds, and they perform this task over and over all day long. (See Figure 2.13.)

In such cases as this, we set a pitch time of 30 or 40 seconds, then the workers work together trying to keep up the pace. To the ordinary observer, it appears that all of the workers are doing just this. However, someone trained in JIT who has a sharp eye for identifying waste would cite this as a prime example of "idle time waste."



The fact is, if you have 30 people working on a line, their actual production pitch will vary significantly from person to

Figure 2.13 Component Efficiency and Overall Efficiency.

person. Some people may always finish in 10 seconds while others struggle and sometimes take longer. Once a worker has finished assembling a unit in 10 seconds, she should have nothing to do but start in on the next unit. This is where conveyors come in handy. They keep the flow moving at one unit per pitch increment. But when a worker finishes early, she must wait out the remainder of that pitch increment until the conveyor brings the next unit. There is nothing she can do for her neighboring workers during this time.

Although everyone claims to be working precisely at the pitch time, faster workers have their work slowed down by slower workers. This kind of "coordinated work" is actually quite susceptible to "idle time waste."

The conveyor's disadvantage is that it tends to hide idle time waste and its advantage is that it keeps things moving at the pitch time. This means that no matter how much improved an individual's efficiency becomes, that improvement can still do nothing to raise the line's overall efficiency. Obviously, it would be quite valuable to have individual efficiency improvements reflected in the line's overall efficiency. But we can see that there is a clear difference between individual efficiency and overall efficiency.

If we take the same assembly line, remove the electric conveyor, and instead have the assembly workers lined up beside one long workbench, the units will gradually begin to pile up next to certain workers due to individual differences in pitch. The piles of work-in-process reveal all those hidden individual differences in pitch.

If we break up the long workbench into individual workbenches for each worker, then the piles of work-in-process become even more obvious.

If we separate the individual workbenches by some distance, it would leave room for work-in-process to pile up indefinitely. The line would soon lose all signs of having a production flow. So you can see why JIT professionals have so little interest in the "coordinated work" arrangement. This example also underscores the fact that efficiency improvement has nothing to do with upstream or downstream processes and has everything to do with raising efficiency at individual processes. To do this, sometimes factories "automate" a task that is being performed either manually or by a simple machine by installing a high-speed machine, computer-controlled machine, or other absurdly expensive machine.

I sympathize with such factories, and there are a lot of them. In fact, I would say that the vast majority of the world's factories are guilty of these kinds of mistakes.

I am not denying that individual improvements in efficiency can add up to an overall improvement throughout the company. But the improvements have to start with individual people, machines, and processes, and only then should they be developed into improvements in line efficiency, factory-wide efficiency, and company-wide efficiency, including the sales and distribution arms. It is very important to maintain this kind of comprehensive view of efficiency improvement.

Once management installs and activates highly sophisticated and ultra-expensive machinery on the production line to improve efficiency at certain processes, it is naturally concerned about getting its money's worth. This leads it to press for higher and higher capacity utilization rates. In the meantime, the idea of letting client orders determine production output gets put on the back burner.

In this day and age, the comfortable notion that if a product is made, it will sell one way or another, no longer holds true. The smart idea for today is, "Let's make only what will sell, but make it more efficiently." Once we take this perspective, pushing up capacity utilization for its own sake is clearly a mistake.

Pressing and forging processes are prime targets for managers who limit their view to process-specific efficiency improvements. Both of these processes require die changeover, which tends to take a long time. The managers try to minimize this time consumption by minimizing the number of necessary die changes. The way to do that is by making fewer models in larger lots. Soon the factory is back to the old large-lot orientation. The problem is the managers' belief that the fewer the die changes, the higher the efficiency.

These managers have forgotten that production includes more than pressing and forging processes. *Unless production is made level throughout all processes, the overall result may well be a loss in efficiency.*

The JIT production system not only includes techniques for thoroughly eliminating waste, it also includes techniques for creating and maintaining a level production flow. We need to stand firmly behind both of these principles.

Lesson 8. Where Muddy Streams Appear, Floods May Follow

Approach to Waste: Just-In-Time and Cost Reduction

"We've found it! Now let's get rid of it!" Words such as these are often used by improvement teams that finally pinpoint a true cause of waste, inconsistency, or irrationality and set about making the improvement to eliminate it.

The Just-In-Time concept is a very effective tool for eliminating these three evils. It is especially useful for eradicating waste in such common manifestations as "overproduction waste," "idle time waste," "conveyance waste," and "warehouse waste."

Figure 2.14 illustrates some of the essential ingredients in any well-organized effort to eliminate waste and cut costs.



Figure 2.14 Just-In-Time and Cost Reduction.

These ingredients are described below.

1. *Cycle time is determined by the required amount*

Usually, factory managers use equipment capacity and/or manpower resources as a basis for determining the cycle time or pitch. That is a big mistake. If, for instance, we know that our equipment can handle a 20-second pitch, but our client orders are not enough to cover the resulting amount of production volume, we are going to have a product glut. Conversely, if we select a pitch that is too slow to keep up with client orders, we will have a product shortage.

Obviously, the right thing to do is make client orders the basis for setting the cycle time or pitch.

2. Production is "pulled" by downstream processes

Unlike the flow of rivers, the impetus for the production flow should not be upstream processes "pushing" the work-in-process to downstream processes, but rather downstream processes "pulling" the work-in-process from upstream processes. In other words, the worker at the next process is truly the customer in that he or she goes to the "store" (the previous process) and "buys" what is needed. This effectively prevents unneeded work-in-process from being passed downstream.

3. Implement flow manufacturing

Just-In-Time production is impossible as long as work-inprocess is grouped into lots, which we call "shish-kabob" production. Instead, work-in-process must move in single units all along the "flow manufacturing" line.

4. Use kanban and conveyors between appropriate processes Flow manufacturing stands at the very core of Just-In-Time production and is therefore essential to the JIT production system. However, the current level of technology for certain processes that involve heat treatment or gilding still require the lot production method (or subcontracting). It is therefore appropriate to use *kanban* and conveyors between these processes.

5. Level production is a prerequisite

In order to make all of the factory's processes flow as level as possible, we need to have a thoroughly even distribution of product models and volumes. Once we have leveled the assembly lines, we can synchronize them and level them with the subassembly lines, and finally the parts processing lines.

Lesson 9. The Amount of Cost Reduction Achieved Is Proportionate to the Amount of Effort Invested

When Economical Lot Sizes Are Not Economical

As mentioned earlier, pressing and forging processes require metal dies. Drilling processes need bits, and cutting processes need blades. As for the assembly processes, they need to deal with multiple components. None of these facts pose any problems as long as the factory produces only one product model. But single-product factories are an endangered species.

In today's manufacturing world, factories must always be switching their production from one product model to the next. Naturally, this means that metal dies must be changed at pressing and forging processes. Drill bits and blades need to be changed at drilling and cutting processes. And component sets need to be changed at assembly processes. We use the term "changeover" in reference to all of these types of equipment set-up work.

Not surprisingly, workers tend to dislike changeover and would much prefer to avoid product model changes by sticking with single-model large-lot production. Large lots are naturally more popular at factories than small ones. But anyone responsible for managing the company's operating capital will be quick to point out that there must be limits to



Figure 2.15 Changeover Improvement for Smaller Lots and Lower Costs.

lot sizes. The need to balance these opposite interests gave rise to the "economical lot sizes" concept.

As shown in Figure 2.15, the economical lot size is the lot size that achieves the best balance between (that is, the lowest total for) inventory maintenance costs and changeover costs.

It is not too difficult to understand how economical lot sizes can be determined based on process-specific cost measures. However, this method of determination may not work so easily on a larger scale, such as an entire production line or an entire factory.

On such larger scales, it becomes apparent that making lot sizes even just a little smaller will benefit such economical considerations as lower warehouse investment costs, turnover of operating assets, profit ratio, and cash flow.

We also need to remember that production lead-time is not simply the sum of process-specific operation times. Lead-time is actually proportionate to production lot size, which is to say the amount of work-in-process. Therefore, a long lead-time means that a great deal of work-in-process must still be manufactured before the product can be shipped. If production schedule changes are made after a production run has already begun, the flow of materials and information in the factory—and the flow of management processes—will all fall into disorder. Production cannot be made that flexible.

In JIT, we use "factory graveyards" as a nickname for the kind of warehouse inventories factories accumulate when they stick to large-lot production. Such factories may seem impressive in the huge array of materials they contain, but their true "insides"—full of concealed waste and other problems—are in pretty bad shape.

Today, factories should not resemble those large, awesome, but hopelessly outdated beasts known as dinosaurs. Rather, they should be more like small, agile, and alert mice.

Once we have managed to shorten the manufacturing lead-time, we can responsibly shorten the main schedules, such as for sales and production, and can be more flexible toward schedule changes. As a result, we can help minimize "lost opportunities" in marketing.

In dealing with today's fast-paced technological advances, we can also help minimize the impact of all-too-frequent design changes. In other words, having a shorter lead-time is a key factor enabling adaptability to changing sales figures. It also saves time. And since time is money, it saves money.

Thus, smaller lots do not necessarily mean higher costs.

When we look at the various components of warehouse maintenance costs, we find: *interest, insurance, taxes, storage costs, and obsolescence costs.*

How do these costs compare with higher changeover costs incurred by small-lot production? Such costs include: *manufacturing-related clerical costs, mechanical changeover costs, loss of materials, and set-up and removal (labor) costs.*

Let us take a close look at these two sets of component costs. It should be easy enough to spot which set is most conducive to improvements.

In the first set of component costs, almost all of them resist improvement, no matter how hard the company employees might try to attack them. For instance, the only way to reduce warehouse maintenance costs is by decreasing lot sizes. By contrast, the component costs for changeover—such as the manufacturing-related clerical costs, mechanical changeover costs, and loss of materials—are all amenable to improvement if people get together and brainstorm some improvement ideas. In short, these costs are prime targets for JIT improvement activities.

In fact, JIT shows us how we can even get rid of our fixed idea of "lots" by changing factories into a level system where products are built in short production runs without disturbing the overall flow of the factory.

Lesson 10. Do Not Neglect the Economic Forest by Focusing on Economic Trees

Motion and Work

One of the things factory workers tend to mumble on their way out the gate at the end of the day is something along the lines of, "Man, I worked my tail off today."

Ordinarily, we take such expressions at face value. But if we look beneath the surface, we will find that different people have widely different understandings of the meaning of "work." Some people feel that simply being at the company for eight hours is work. These people make time their measure of work, in that every minute or even every second they spend at the company is regarded as work. They watch the clock and keep careful track of their overtime as defined in the employee's manual.

Other people evaluate work in terms of "sweat." There is a long tradition in Japan and in the West of regarding a person's perspiration as irrefutable evidence that he or she is hard at work. People are suspicious of work that does not cause the worker to sweat. In fact, given a choice between two equally productive work methods—one that produces sweat and one that does not—they will usually pick the sweat-producing method. Then there are people who derive their sense of work satisfaction from the "added value" their work produces. These are just a few of the different ways people understand the meaning of work.

I would suggest that the people I first described—the "time" workers—are actually more "not working" than working. The "sweat work" people perform more motion than work. It is the "added value" people that come closest of the three to actually working. For simplicity's sake, we will include the "not working" people in with the "moving" people.

As I mentioned earlier, people have different perceptions of work. Even within a single day's work time, we can recognize such differences between the "moving" people and the "working" people.

Equipment operators ordinarily work an eight-hour day. Obviously, not all of that eight-hour time is spent working. In fact, the great majority of that time is spent "moving" rather than "working." (See Figure 2.16.)

As noted in Figure 2.16, "work" is only the part of the operations that actually adds value. Every other part of the



Figure 2.16 Motion and Work.

operations is called "motion" rather than "work." In everyday work operations, there is rarely a clear distinction between actions that actually are "working" and those that merely are "moving." The two just mix together in our overall actions. What seems to be "working" at one instant may turn into "moving" at another, and vice versa.

It is not easy for an untrained eye to distinguish between the two. Many factories make the careless mistake of starting out their improvement campaigns with the general notion that whatever moves is work and what does not is waste. Obviously, their improvement campaigns are not going to be very successful until they learn to make the distinction between "work" and "motion."

Waste that is not recognizable as such is the most insidious kind of waste. If we can learn to recognize this kind of waste, we are well on our way to success in eradicating waste.

The following is a list of some of the things we might encounter as we stroll through a typical factory. Odds are that we would not be able to recognize these motions as 10 examples of waste.

- 1. Workers grunting and groaning as they carry a heavy load.
- 2. Workers counting parts once the operation is done.
- 3. Workers moving stacks of parts from the floor to a cart.
- 4. Workers inserting parts into plastic bags before sending them downstream.
- 5. Workers removing the plastic bags from parts received.
- 6. Workers who have finished today's work and are proudly starting in early on tomorrow's.
- 7. Workers securing parts to be processed.
- 8. Workers repeating the cycle of picking up parts, processing them, and setting them down elsewhere.
- 9. Workers watching out for defects while their machines are operating.
- 10. Workers searching for parts, tools, or jigs.

The above are 10 typical examples of waste in factories. I could list more. In fact, I could fill this entire book with typical examples of waste. That is how much waste exists in factories.

Imagine standing with the president of the company that owns the factory and watching such a waste-filled factory in operation. What do you suppose the president might say if you remarked, "Boy, your workers are really moving around a lot, aren't they?"

Unfortunately, a large number of company presidents would respond with something like, "Yeah, our factory people really work hard for us."

Personally, I would not blame you if you responded to that by making a sour bulldog face and stomping out of the factory. When people fail to recognize the difference between "motion" and "work," you can be sure their eyes are blind to waste. Let us see just how different "motion" and "work" really are.

The only result of motion is higher costs. Well, actually, it has one other result: eating up profits. Now you see why we call "motion" waste. In sharp contrast to this, the result of "work" is to fulfill a function. This function is generally a value-adding function.

Motion and work are mixed together within the typical equipment operator's activities. But motion (waste) is clearly the main ingredient. As a result, the equipment operator's activities actually add very little value.

Consider the example of a press operator illustrated in Figure 2.17.

1. *The first step in the press operator's activity: picking up and moving an unprocessed workpiece.*

This movement adds absolutely no value to the workpiece. Therefore, it is an example of waste. The waste can be reduced by shortening the distance of this movement. Of course, the best thing would be to eliminate the movement (and the waste) altogether.



Figure 2.17 Activity of a Press Operator.

2. The second step: moving a hand to push a button.

A complete waste. The worker's hand is not holding anything and is moving through empty air.

3. The third step: pushing the button.

During the instant it takes to push the button, the worker is adding value to the workpiece. To be precise, this button-pushing operation takes about one second, assuming the press is a relatively small one weighing about 100 tons. And while we are being precise, we should note that even that one-second button-pushing operation includes some waste. The time it takes the upper die to reach the workpiece—the time the upper die spends pressing nothing but air—is waste. And that accounts for almost all of the time it takes to press the workpiece. And we should also note that in this process, it is the machine—not the worker—that adds the value.

- 4. *The fourth step: moving a hand to remove the workpiece.* Again, the worker moves his hand through empty air. All waste.
- 5. *The fifth step: removing the processed workpiece, moving it, and setting it down nearby.*

Moving the workpiece is just handling time. All waste.

6. The sixth step: moving to pickup the next unprocessed workpiece.

All motion, no work. All waste.

In this example, the easiest way to reduce waste is to reduce the distance the worker must move in order to pickup unprocessed workpieces and set down processed ones.

As just described, almost everything that happened in this example was a form of waste. We should remember that anytime "working" means taking workpieces down from shelves, setting them down, or carrying them somewhere, it is not actually "work," but "motion." And *motion means waste*.

Recently, companies have started to rationalize their conveyance and improve their material handling procedures, in many cases by introducing Automated Guided Vehicles (AGVs) or other automatic material handling vehicles. These devices are generally very well received in factories, since they spare workers the chore of having to lug materials around. But they should not be viewed so optimistically.

Generally, these automatic transport systems do little or nothing to speed up material handling or shorten the distance involved therein. The best approach is to think, "Let's cut off transport-related waste at the root."

I call this kind of automation "skin-deep automation" or "make-believe automation," since in the final analysis it just creates conveyance-related, equipment-related, and energy-related waste. The genuine solution is to begin by organizing and regulating the factory to improve the equipment layout to the point where they no longer need conveyors of any kind. The idea is to proceed with caution before adopting any simple "automation" plan.

> Lesson 11. Operations Should Flow Like a Clear Stream

Inherited Waste and Inherent Waste

No matter how good a factory is at manufacturing products, you can bet that it stands knee-deep in waste. Starting with the most obvious, we could cite a typical factory for having too wide a "green belt" around it, having too large a building, having management functions that no one seems to understand, and so on.

Waste can be found hiding in even the most magnificent factories. And in factories at the other end of the quality spectrum, just about everything we see is waste.

I remember when, during one factory inspection tour, the company president first led me into what appeared to be a warehouse. Everywhere I looked I saw parts, products, and boxes stacked almost to the ceiling. I advised that we look at the factory and then come back to the warehouse. Then the company president's smile dropped into a frown as he said, "This *is* the factory."

In an attempt to lessen his embarrassment, I offered, "Oh, I thought it was a warehouse since there aren't any workers here."

But my host's face only turned a brighter shade of red. "No, they're over there, behind those boxes," he said.

He was right. There they were, hidden from view by stacks of boxes, as if playing hide-and-seek.

The situation was so bad in that factory that I saw a worker stretching to place more parts boxes on top of a stack that was already too high. Like a stack of pennies, the stack reached the point of instability and I began to wonder if it would fall.

Just as I saw the stack swaying dangerously to one side, another worker appeared out of nowhere just in time to help set the stack even. The company president and I applauded their fast-thinking teamwork.

Then I thought to myself, "It's amazing that such a spirit of cooperation survives in a place like this!"

This whole affair makes for a humorous anecdote, but there is nothing funny about it as far as the company's future is concerned. In fact, there are a great number of factories that are just as comical and just as pitiful. It is no exaggeration to say that, in most cases, it is not a matter of finding waste in the factory, but of finding the factory in the waste. These days, I often hear of factories that, barely turning a profit, suddenly decide to "rationalize" and "modernize" by installing computer-based management and robot systems. Meanwhile, waste lives on as a nonendangered species. The waste lives on in new forms as the factory is reorganized, computerized, and automated. JIT improvement experts call this "systematic waste-making" and regard it with unmitigated disgust.

Let us take an example of "waste-making computerization."

Once a factory introduces a new production system, the managers need to make up a new bill of materials. Such bills of materials are used to indicate which parts are needed to build which products. (See Figure 2.18.)

The various steps (or "layers") in the production system from the materials stage to the final product stage is called the "depth" of the bill of materials. Generally, more complex products have deeper bills of materials.

Consequently, some manufacturers are proud of having very deep bills of materials, since this is seen as evidence of how complex and sophisticated their products are. In most cases, though, the depth of a bill of materials is much more a function of how complicated the production system is than a function of product complexity.

The reason why a part or assembly part gets established as an item in the bill of materials is that the part requires some kind of "management." Generally, these kinds of items include:

- Materials: ordering and delivery management (order management).
- Parts (group 1): work instructions (operation management).
- Parts (group 2): work-in-process planning (*work-in-process management*).
- Parts (group 3): supplies for outside vendors (*supplies management*).
- Assembly parts: feed assembly parts to assembly lines (assembly feed management).



Figure 2.18 Depth of Parts List and the Factory's Production Method.

In the factory, where work-in-process stocks tend to pile up, work-in-process management, as well as operation management aimed at preventing defects and improving efficiency, are important enough to warrant inclusion as items in the bill of materials.

However, we should also regard including these items in the bill of materials as evidence that work-in-process tends to pile up and that the flow of goods does not always flow in a level manner. Perhaps the work-in-process piles up precisely because the flow of goods is not level. The piling up of work-in-process creates the need for management. The managers then want to have a computer to help them manage the flow of goods.

Once they bring a computer in, a waste-filled flow of goods gets augmented by a waste-filled flow of information. The end result is a waste-filled production management system.

Naturally, any system that creates so much waste is bound to have a deep bill of materials. And as the bill of materials gets deeper, more and more things get included as items to be handled at the factory. The vast numbers of items to be handled and accounted for create a need for an expensive, sophisticated computer system.

The factory now includes a whole new task: entering the long (and still growing) list of bill of materials items into the computer system. And then there is the additional big task of revising the computerized bill of materials whenever the bill is changed, due to things like the installation of new equipment. A third computer-related task is the lengthy processing required to calculate the required material orders for such a deep bill of materials. All those computer-related tasks create the need for a staff of trained computer programmers and operators. As you can see, waste creates more waste.

The same kind of self-perpetuating growth of waste can occur when factories hastily introduce industrial robots or other automated equipment. A waste-filled factory becomes an automated waste-filled factory. The waste gets processed automatically by systems such as AGVs, automated warehouses, and other automatic material handling lines.

The worst part of this phenomenon is that waste that would have been relatively easy to identify and remove becomes much more firmly embedded and hidden in the manufacturing system after it is carried over into sophisticated systems such as automated production lines. Waste gets harder and harder to remove. Eventually, it gets to the point where the entire factory, or even the entire company, must be torn apart to be improved.

Lesson 12. Remove Waste Before It Sinks Deeper

Improving the Intensity and Density of Labor

Generally, we tend to think of improvements, rationalization, and removing waste as means of intensifying labor. In factories where workers have strong unions, there has sometimes been a great deal of resistance to such changes. Naturally, the changes have to be worked out in negotiations with the union leadership.

Union leaders have sometimes expressed opinions such as: "We're already working as hard as we can! There's just no room for improvement."

Not surprisingly, such narrow-minded thinking usually comes from companies that are operating in the red. Such thinking also shows just how little the employees understand about the waste hidden in work operations.

As explained earlier, each work operation consists of two parts: "motion," which is action that does not directly add value to the workpiece and is therefore waste, and "work" which does add value. Motion—the wasteful part—is usually by far the larger of the two parts.

JIT improvement is a program for thoroughly removing the enormous amount of waste hidden in work operations. Figure 2.19 illustrates the waste elimination technique that forms the basis of JIT improvement.



Figure 2.19 Improvement of Labor Intensity and Labor Density.

If we were to simply increase the amount of work without removing waste, the workers would have a very good reason to complain. Such a change would be nothing more than intensifying their labor.

We need to make a large and important distinction between the *intensity* and the *density* of labor. Intensifying labor without removing waste aims solely to increase production output. For instance, we can require the workers to work faster, which would raise the production output. This is what intensified labor alone means.

This is *not* the right way to go about improving things. We need to take a very different approach—improving labor density. We start by finding and removing waste from within work processes. More specifically, this waste elimination stage includes:

- Understanding the entire work process.
- Quickly recognizing the actual value-adding function of the process.

- Applying the concepts of "motion" and "work" to study the work process.
- Distinguishing clearly between wasteful "motion" and value-adding "work."
- Immediately doing whatever is possible to remove wasteful "motion" from the work process.

Let us consider an example. A certain press worker's work process starts with fetching a workpiece from a site about eight feet away and pressing it. The first improvement is to have the workpieces set close enough so that the worker does not need to take any steps to reach them. That one improvement removes 16 feet (round trip) of "walking waste" or about six seconds of "time waste."

Now, what shall the worker do with these six seconds of freed-up time? Ideally, they should be used for value-adding actions. If this can be done, we can "naturally" (that is, without strain) translate that much more labor time into higher production output. In other words, we can increase the production output *without intensifying labor*. The worker will work at the same speed as before, but will "naturally" have greater output.

The more we can increase the ratio of "work" to "motion" within a work process, the greater the density of labor becomes. By definition, higher labor density means more value is added to the product per unit of labor cost.

Now you can see why we call removing waste the very basis of JIT improvement. The thing that JIT improvement team members need to be most careful in checking is whether or not their improvements actually remove waste.

In view of the above, it is fair to say that *JIT improvement does not in any way require intensification of labor.*

Any worker in any factory should be able to confirm this for him or herself. If the worker feels that an improvement has sped up the work or has made it more *difficult, it can only be a sign of errors in the improvement.* Lesson 13. Removing Waste Means Turning Wasteful Motions into Productive Work

Approach to Inventory and Lead-Time: Inventory and Lead-Time

Everyone—the manufacturers and their clients—face a highly competitive business environment. In the economic jungle as in the real jungle—you either eat or are eaten. This harsh business environment has led to rising client demands for lower costs and shorter delivery deadlines. For their part, factories seek "compressed delivery deadlines."

Imagine some company managers who, faced with tough market competition, come to you for advice on how to shorten delivery deadline periods by as much as 50 percent. Let us also assume that the factory managers have already tried installing new equipment and implementing a TQC program, but without the expected results. They are getting desperate for answers.

Now imagine how surprised they would be if you were to simply suggest, "That's easy enough, just reduce your current inventory 50 percent." No doubt, they would probably appear mystified and wonder how the subject of conversation got switched from delivery deadlines to inventory. Again, you need only explain, "What's the mystery? It's really very simple. Just cut the current production lot sizes in half."

Now watch what happens. Their minds, already bewildered by your connection of delivery deadlines and less inventory, collapse into total confusion as they consider yet a third apparently unrelated factor: lot size.

Maybe someone will seek to clarify things by asking, "Let me get this straight. We cut delivery deadlines in half by cutting inventory in half, which means cutting lot sizes in half. But doesn't that mean we'll also be cutting our production output in half?"

Now they are getting somewhere. You can continue by adding, "Cut output in half? Yes, I suppose it does. But you

can fix that by doubling the number of production runs." Again, mass confusion. "Wait a minute. We cut inventory and lots in half and then we double the production run?"

By now, their brains' logic circuits have probably shorted out and their ears are about ready to start spurting fireworks. That might be a good point to end the consulting session, and just leave them to think about it.

It is truly amazing how many top managers at manufacturing companies are ignorant of basic production principles. They should at least be able to immediately recognize the relationship between lead-time and inventory.

Let us look at the line chart shown in Figure 2.20 below.



Figure 2.20 Line Chart.

The vertical axis in this chart represents "quantity" while the horizontal axis stands for "time." The broken line shows the "amount received" and the solid line the "amount sent." Manufacturing lead-time is what fills any gap between the amount received and the amount sent. Wider gaps mean longer lead-times. Moreover, longer lead-times mean larger amounts of in-process inventory.

In other words, the relationship between manufacturing lead-time and in-process inventory can be described using the following two equations.

Manufacturing lead-time = in-process inventory expressed in day units

Amount of in-process inventory = manufacturing lead-time × daily production output

Although our example refers to in-process inventory, it can be applied similarly to inventories of products or materials. If we cut our product inventory in half, we need to cut our lead-time in half, too. The same goes for our material inventory. If we cut that in half, we need to cut the delivered lots in half and double the number of deliveries.

In the factory, problems crop up in all kind of areas, including delivery deadlines, quality, and inventories. None of these problems exist independently of the others. They are all interrelated, and we must learn how they connect.

Factories having trouble meeting delivery deadlines are probably also suffering from excess inventory, difficulty in switching to wide-variety and small lots, and ongoing missing parts and other defects. All of this relates to what we call "the character of the factory." The most visible aspect of this "character" is inventory. The inventory situation is so visible that a JIT consultant can generally appraise it immediately upon entering the factory.

Inventory is the JIT consultant's best teacher.

Lesson 14. Inventory Tells the Whole Story

Why Is Inventory Bad?

Many of us think of inventory as a "necessary evil."

During times of booming markets and brisk sales, we appreciate the necessity of inventory as the "ammunition" for doing business. But when the market boom fizzles out and sales slump, we suddenly feel the "evil" of inventory, too. Inventory is thus a two-faced entity, sometimes an angel and sometimes a devil. In JIT production, inventory always has only one face: the Devil's.

If you were to ask me why inventory is a bad thing, I could give you the following general reasons.

1. Inventory adds weight to the interest payment burden

Anytime we need to procure capital, we must pay the cost of such capital. The general term for this cost is "interest." For whatever amount of time the materials purchased with such capital sit "idle" as inventory, the invested capital does nothing except incur interest debt and is therefore a pure and simple addition to the company's interest payment burden.

2. Inventory takes up space

Obviously, inventory has some bulk and therefore needs space. If we allow inventory to accumulate, we soon must either put up with cramped factory floors or must invest further capital in new shelves or new warehouse facilities.

- 3. *Inventory creates the need to convey and handle waste* Stopping something to keep it in one place implies movement before and after the stopping. Moving things to intermediate locations from where they will need to be moved again, and loading and unloading these things from the conveyors are all forms of waste.
- 4. Inventory invites defects

If left idle long enough, "nonperishable" items will begin to rust or otherwise suffer time-related deterioration. Simple logic also dictates that the more times a thing is handled, the greater its chance of receiving dents or other damage-related defects through mishandling.

- 5. *Inventory creates unnecessary management costs* We incur storage costs whenever we stop the flow of goods and we incur transportation management costs whenever we move those goods. The more defects we have, the more we must put out for QC. A poorly-run factory eventually finds itself up to its ears in management costs.
- 6. *Inventory eats up valuable stocks of materials and parts* We cannot make products out of thin air. We must have the materials and parts to make them. If we use our current inventory of materials and parts to make products that cannot be sold immediately, and therefore sit idly as product warehouse inventory, we have eaten up stock of materials and parts—the value of which will become painfully clear if a big order comes in for a different product that we now lack the components to make.

7. Inventory gobbles up costly energy

Unnecessary inventory means unnecessary consumption of energy. Whether that be electricity, pneumatic or hydraulic power, or whatever, the company has to pay for it.

These are just some of the "evils" of inventory. And I have not even mentioned the real reason why inventory is bad. When you get right down to it, *inventory is bad because it conceals the factory's problems.*

All factories have problems. Problems pile up in even the very best factories. Inventory casts a sort of camouflaging shroud over these problems, and this makes the problems that much harder to analyze and solve.

For instance, workers at a process that turns out defective products by the dozens may choose to pile up a "buffer" stock of products for inspection. The inspectors can identify and


Figure 2.21 How Inventory Conceals Problems in the Factory.

pull out the defective products and thereby prevent "passing along trouble" to the next process. But this solution only covers up the real problem, which is the process's tendency to turn out defective goods. The inspection stock (inventory) solves the superficial problem of "passing along trouble" but does nothing to address the real problem. (See Figure 2.21.)

The more a factory uses inventory to escape its peripheral problems and avoid dealing with its real problems, the more the real problems will grow, sending roots deeper and deeper into the manufacturing system. Eventually, they begin to weaken the very "character" of the factory. In this way, it is fair to call inventory "the opium of the factory." Like an opium habit, the inventory habit is best never started.

Lesson 15. Inventory Is the Opium of the Factory

Inventory and Finance

Just about everything under the sun has some sort of function. One gizmo's function is to take in coins and dole out refreshments, while another's is to conduct electricity and convert it into light. Everything that has a function requires some kind of input and produces some kind of output. In many cases, that output becomes some other thing's input.

The same principle can be seen at work in companies. In the case of manufacturing companies, they acquire capital, lay in stocks of materials, turn these materials into products, and then sell the products to acquire, among other things, recyclable capital.

We find a similar situation when we switch from managing materials to managing money—which many regard as the pivotal aspect of company management. Put very briefly, the function of finance management is to procure and operate capital. Capital procurement is the input and capital operation is the output.

Now we are ready to ask, "What is inventory's role within the context of this money-recycling activity we call finance management?"

Please look at the balance sheet shown in Figure 2.22. The right side of the balance sheet is the credit side, which lists liabilities and shareholders' equity. The left side is the assets side. Usually, the capital procurement figures are listed in the liabilities section while the operating figures are listed in the assets section.

In the balance sheet shown in the figure, the assets and liabilities are listed in ascending order of "fluidity." To make this fluidity a little easier to grasp, we added a downward arrow and the term "cash-convertible" next to the credit side. This cash-convertible arrow indicates that the lower an item is positioned on the assets list, the easier that item is to convert into cash.

As we can see in the balance sheet, inventory items such as finished goods, work-in-process, and materials are positioned within the more cash-convertible category of "current assets." However, they are not as cash-convertible as other items in that category, such as cash, notes receivable, and

	Balance Sheet Summary (As of [date])					
ion	Assets Liabilities		rocui			
Cash-convertible	I. Current Assets Cash XX Notes receivable XX Accounts receivable—trade XX Finished goods XX Work-in-process XX Materials XX II. Fixed Assets Property, plant, equipment Buildings XX Machinery and equipment XX Land XX Intangible fixed assets Good will XX Patent rights XX Investment and other assets Investments in securities XX Investments XX Investments XX III. Deferred Charges XX	I. Current Liabilities Notes payable x x Accounts payable—trade x x Short-term loans payable x x Accrued amount payable x x and accrued expense Allowance for taxes x x Allowance for taxes x x Long-term loans payable x x Long-term loans payable x x Allowance for employee x x Allowance for employee x x Allowance for employee x x Shareholders' Equity X I. Capital stock x x Retained Earnings X III. Legal Reserve of x x Retained Earnings X Unappropriated retained x x earnings at end of term (Earnings at end of term)				
۲	Total Assets x x x	Total shareholder's equity) X X X Total Liabilities and Shareholders' Equity X X X	•			

Figure 2.22 Position of Inventory in a Corporate Balance Sheet.

trade-related accounts receivable. In fact, they are the least cash-convertible of all of the current assets.

The task of managing a company's activities begins with procuring capital. If this procured capital can be recycled within a year, it is considered a "current liability." If recycling takes a year or more, it becomes a "fixed liability." In either case, having use of the capital incurs a capital cost known as interest.

As mentioned earlier, the company uses this interestbearing capital to lay in stocks of parts and other materials, add value to the materials through manufacturing, then sell the finished goods for a profit, part of which can be recycled into further capital.

The gist of the problem is that people in these companies work so hard to earn the profit used to recycle capital, only to waste that capital by "putting it to sleep" in raw materials, work-in-process (in which some value has already been added), and products that do not "move" but just sit there as inventory.

Capital costs "move" with the clock and thus never sleep. The company must keep paying these costs while its inventory snores away.

It should be apparent by now just how much inventory betrays the whole principle of finance, which is to "procure and operate capital." Although businesspeople make use of the term "inventory investment," the truth is that inventory alone offers no return on investment and therefore should not be considered an investment at all. How helpful it would be if everyone kept this simple fact in mind.

Lesson 16. Inventory Is Not an Investment

When "Appropriate" Inventory Is Not Appropriate

People in training for the job of inventory management often run into texts with titles along the lines of, "Inventory: Not Too Much and Not Too Little Keeps Production Running Smoothly." "Not Too Much" foreshadows the text's admonitions to drastically reduce inventory.

But what does "Not Too Little" refer to? It refers to a common piece of advice: Make sure you have at least some excess inventory. It does not mean "minimize" inventory. It says that we are supposed to maintain a little "fat" in the inventory, but not too much.

The philosophy behind this "keep a little fat" approach to inventory is that having a little extra inventory on hand as a sort of "buffer" will enable the factory to respond quickly to surprise sell-outs or shortages of materials and products. However, in view of the wide range of products demanded of factories by today's diversifying market needs, how little can "a little fat" really be and still serve as a buffer? We have to face the fact that, in today's marketplace, surprise sell-outs and parts shortages are still bound to happen when we maintain a slightly (or even seriously) overweight inventory. Planning a little fat into our inventory in preparation for or in response to product sell-outs is a sure-fire way to end up with lots of excess inventory.

Inventory managers find themselves between a rock and a hard place: Too little inventory results in parts shortages and too much puts a heavy load on business management. This uncomfortable situation has helped give rise to a wonderful concept: "appropriate inventory."

Appropriate inventory means enough inventory to avoid a strain on capital while also avoiding loss of sales due to shortages. It sounds great in theory, but how can appropriate inventory be realized?

There are even some formulas we can use to determine appropriate inventory levels. In one formula, the calculation is based on the sales target. The other is based on cash flow. There are many different formulas expressing different inventory management perspectives.

For example, the following formula is common for sales target-based calculations.

$\frac{\text{APPROPRIATE}}{\text{INVENTORY}} = \frac{\text{ANNUAL SALES TARGET (VALUE)}}{\text{MERCHANDISE TURNOVER}}$

Let's insert some actual figures into this formula by saying that annual sales target (value) equals \$32 million and merchandise turnover is 16 times per year.

$$\frac{\text{APPROPRIATE}}{\text{INVENTORY}} = \frac{\$32 \text{ Million}}{16 \text{ times (per year)}} = \$2 \text{ Million}$$

We can also use these figures to calculate the inventory per merchandise turnover time as follows:

This means a turnover cycle of about 23 days. But is this theory going to work in practice?

In today's wildly erratic markets, how likely is it that any manufacturing company's \$32 million sales target will really be that accurate? And how many manufacturers can afford to ignore the considerable impact seasons and climactic changes have on sales? Sales levels are easily influenced by the strategic actions of competitors. And then there is the unpredictability of raw material prices, currency exchange rates, and so on.

Understandably once a company's sales division sets its annual sales target, the sales managers must come up with all sorts of *ad hoc* strategies to actually reach the target. We also need to ask exactly how managers determine the merchandise turnover rate that serves as the denominator in the above formula.

Ordinarily, they use past merchandise turnover rates as their basis for calculation. They then apply various business performance indices as well as the company's current goals in determining the current year's merchandise turnover. These factors change according to the production lead-time and the yield, but they do not change as easily as the sales levels.

So, we can already see that the appropriate inventory is determined using a formula in which both the denominator and the numerator are prone to instability.

Using a formula that divides one unstable factor by another unstable factor to obtain what is treated as a stable value is like trying to divide one negative number by another negative number to obtain a positive number. To put it another way, the appropriate inventory value obtained using the above formula is only as reliable as the unreliable figures used in the formula. (See Figure 2.23.)

Better that we should face the facts: Even if we take the unreliable figures for annual sales and product turnover and temper them with adjustments for estimated seasonal changes, lead-time, and profit ratios, we can still end up with an inventory level that is way off from what turns out to be actually needed.



Figure 2.23 Estimated Appropriateness and Real Appropriateness.

Certainly, it is very important that companies set targets for sales totals, inventory turnover, and other important business performance measures. However, when companies start entrusting these figures to provide them with a prescription for appropriate inventory, it is very easy for them to adopt an attitude of trying to uphold the validity of the figures for the sake of "stability" and at the expense of actual conditions.

Rather than hoping to banish the term "appropriate inventory," I would only hope everyone remembers that *the only really appropriate inventory is zero inventory.*

Lesson 17. The Appropriate Inventory is Zero Inventory

Estimated Lead-Time and Real Lead-Time

Customers are very picky people. They tend to suddenly want products that they never even bothered to look at before. And when they want them, they want them now.

Fashion wear is a prime example of this. Fashion boutiques regularly report cases where some outfit that has stood virtually unnoticed in the window for weeks suddenly starts catching shoppers' interest. Even in the world of food, there is the old saying, "The food that tastes best is whatever you want to eat at the time." These days, customers are like people who suddenly fall ill in the middle of the night. They may not have seen a doctor in years, but now they need one. Right now, in the middle of the night. There is no time to wait.

A factory's customers rush to order suddenly vital products and want them shipped ASAP. If the factory doesn't fill their needs, they will probably try a different factory next time.

Today, very few factory managers can still afford to tell such customers, "Look, these are all the models we make," or "We'll need at least three months before we can ship it." In a sense, customers have already embraced the Just-In-Time concept: "What I want, when I want it, and in just the amount I want."

Customers end up asking for products to be manufactured and shipped immediately, and factories can only reply, "Sorry, but it takes time to make those things." This creates a gap between customers and manufacturers. Manufacturers have come to regard inventory as something that fills this gap.

We call the period between the customer's placement of an order and the customer's receipt of the product the "customer lead-time." Even if we assume that the factory can begin manufacturing the ordered item right away, this customer lead-time must still include the time needed to make the order. This period is called the manufacturing lead-time. The customer lead-time also includes the time needed to deliver the product, which is called the "transportation lead-time." Let's stop there, omitting any consideration of time needed for clerical work in processing the order, and construct the simple formula:

Customer lead-time = manufacturing lead-time + transportation lead-time

Figure 2.24 shows two illustrations based on this formula. However, this lead-time is not short enough to meet the customer's delivery deadline. So let us suppose that the



Figure 2.24 Estimated Lead-Time and Real Lead-Time.

company decides to put up a warehouse between its factory and its customers in order to do away with the manufacturing lead-time and enable a shorter "estimated lead-time," whose formula would simply be:

Customer lead-time = transportation lead-time

Here, the warehouse is supposed to make up for the disadvantage of having a manufacturing lead-time. It also means the factory managers can more comfortably plan their production schedules, since they only need to stock that thick wall (the warehouse) between itself and its customers. There is a downside to this scheme, though. The thicker the warehouse wall becomes, the less able the factory is to respond quickly to market changes. That slow response becomes a serious flaw in the factory's character. Production gets stuck in a slow, predictable rut.

It reminds me of the difference we can see between animals who are raised in a zoo and those who never left the wilderness.

Once a factory pursues the inventory option, they do not stop with product inventories. Inventories start piling up between processes or in the assembly line, and then there are the inventories of materials and subcontracted parts.

At each of these inventory sites, a power struggle takes place between the "users" and "providers" of the stocked items. This power struggle is described in the first table.

	User		Provider
Product inventory	Market needs	>	Factory's responsiveness
In-process inventory	Capacity of downstream process	<	Capacity of upstream
Materials inventory	Negotiating power and leadership of buyers and outside vendors	<	Resilience of manufacturers

How can we get rid of these inventories? The second table lists different methods to use for different types of inventories.

If manufacturers hope to survive in today's harshly competitive markets, they must learn how to rid themselves of these inventory "buffers" and become more responsive to meeting their customers' short-term demand for everchanging products. Companies make a very big mistake when they depend on something like the above estimated lead-time to meet their customers' needs. A strong, healthy factory is one that can meet needs for prompt delivery based on a real lead-time.

Product inventories	Since market needs cannot be weakened, we have to strengthen the factory's responsiveness to those needs.
In-process inventories	Raise the capacity and flexibility of downstream processes. Do this by thoroughly implementing the "next customer is the customer" concept.
Materials inventories	Strengthen the negotiating power and leadership of buyers and contractors coordinators.

Lesson 18. The Slow-but-Safe Approach Robs Factories of Their Brilliance

Approach to Equipment: Automation and Human Automation (*Jidoka*)

The world is full of automatic machines. As their name implies, almost all of these automatic machines are "self-moving." We just flip the ON switch, and leave the rest up to the machine. Today, there are even automatic machines busy making other automatic machines.

Still, not everything is perfect in robotland. For instance, very few automatic machines have the ability to stop upon detecting defects caused by worn or missing components. Automatic machines that seem to be the ultimate in convenience at one moment can suddenly become mass producers of junk at the next moment.

Obviously, this will not do. The natural response is to put a human inspector on the job to watch out for such sudden quality changes. But the need for a human dilutes the meaning of automatic machines as labor-saving devices, even though this is what has to be done to maintain product quality.

This paradoxical situation gave rise to the idea of *jidoka*, or human automation. *Jidoka* is what enables the machine to be stopped the moment a defect occurs, a machine component breaks, the production flow backs up, or a mistake-proofing alarm goes off. People apply their own human wisdom and



Figure 2.25 Automation and Human Automation (Jidoka).

experience-based "know-how" to equip the machine with devices that are able to detect any of the above conditions and bring it to an immediate stop.

In JIT production, we use the term "automated machine" to refer to machines that, once activated, will run on their own regardless of defects. We use "human automated machine" or "*jidoka* machine" to refer to machines that include "wisdom-based" defect detection improvements, such as those just described. We must always make a clear distinction between these two types of machines. It may be helpful to remember that *jidoka* machines include more value-adding "work" in their operations than do automated machines. (See Figure 2.25.)

Lesson 19. Let's Make Jidoka Machines That Do All the Human Work

Improve Work Operations before Improving Equipment

There are basically three types of improvement methods used in JIT improvements. The first is the awareness revolution, the second is improving operations, and the third is improving equipment.

Many people get confused over which method to start with. Some companies are too anxious to exhibit the success of improvement activities and hastily pursue the improvements



Figure 2.26 Sequences for Carrying Out JIT Production.

that promise the most obvious results. Other companies, under pressure from parent companies to lower costs, go after improvements aimed at drastically lowering prices within a very short time frame, such as two or three months.

There are many ways to approach making improvements, but there is a recommended sequence for carrying out improvements, as shown in Figure 2.26.

The first step is the awareness revolution. The reasons for this can be summed up in two words: people and money.

Production is rooted in people. People build in the defects. People go over the delivery deadline. People push up costs. The starting point for manufacturing is always people. Therefore, we begin by revolutionizing people's awareness.

Building from the ground up, we begin with improving what is most basic—people's perceptions and attitudes before going on to improve operations and equipment. If we can change people's awareness, we can change their operation habits centered on shish-kabob lot production and can avoid having to waste money on high-priced advanced equipment. But none of these things will change unless we lay the groundwork through the awareness revolution.

Of these three types of improvements—awareness revolution, operations improvements, and equipment improvements—which tends to cost the most money? The answer is obvious: equipment improvements. After that comes operations improvement, and then the awareness revolution, which doesn't need to cost anything at all. The awareness revolution means helping others realize that conventional lot production no longer makes sense and helping them reach the heartfelt resolution that it is high time to switch to one-piece flow manufacturing. Resolution and determination are free.

Thus, there are two very good reasons for starting with the awareness revolution: people and money.

The term "awareness revolution" is not at all an exaggeration. What we are really talking about here is *revolutionizing* our perceptions and attitudes about manufacturing. JIT improvement is not about finding and correcting errors and misperceptions in our current way of thinking. JIT improvement is plainly radical and revolutionary; it demands that we wholeheartedly discard the conventional wisdom that we have gradually developed over the past two or three decades.

Some people may object, "It'll take too long to revolutionize everyone's awareness." That is a valid objection. It could easily take years to "brainwash" everyone into supporting JIT production.

That is why we begin at the top of the company. If we can get the managers, including the improvement team leaders, to start saying, "Right! Let's get to it!" that will do for starters. Go on to improving operations, and while that is happening, the hands-on experience of making actual improvements will ignite the spark of JIT revolutionary thinking in the participating factory workers.

The second step, as mentioned above, is improving work procedures.

Why put improving work procedures ahead of improving equipment? Again, there are two reasons: money and what we might call "industrial fundamentalism."

By making it perfectly clear where each thing is to be placed during the flow of production, by having clearly defined work methods and advancement methods, and by thoroughly eliminating waste, we can make improvements that will ably serve as the basis for standardized operations.

By contrast, improving equipment consists mainly of introducing new machines and redesigning production lines toward the goal of "workerless automation."

Back to the first reason: money. Which kind of improvement costs more, operations or equipment? Again, the answer is obvious: Improving equipment costs more.

One trap companies barely in the black tend to fall into is jumping into equipment improvements before getting very far with operations improvements. Enthusiastic suggestions such as, "Hey, we really need an NC drilling machine!" or "Let's get a computer to help us automate this line!" are often acted upon prematurely.

I have seen many cases where an improvement team was such only in name. What it really had become was a bunch of equipment procurement consultants! I must admit, it is fun to buy things. Especially if the things you buy are interesting. Everyone naturally gets excited at the chance to follow their interests and buy or build the kind of "toy" they always wanted. It is also a great way to avoid having to "hang in there," putting all your experience and know-how to work in brainstorming improvements.

I have often been asked, "What makes JIT improvements succeed?" There is only one answer: "Going into the red." What I mean by this is that the best approach to making improvements is the poor man's approach—do not spend any money. Once everyone realizes that there is no money to throw at problems, they will start getting serious about using their smarts to improve operations. Money is best kept a forbidden option when improving work procedures.

As mentioned above, the other reason for putting work procedure improvements ahead of equipment improvements is "industrial fundamentalism."

The process of production is a flow that begins with gathering materials and ends with shipping finished products. The ways in which things are built and advanced along this flow determines the flow itself. These various means within the production flow are called "devices." Improving operations means improving these "flow devices" within the production system.

People are production's main asset and flow devices make up its foundation. Machines and other equipment are just one of the elements that make up the flow devices. They are simply tools that facilitate production.

When we look at production in this manner, how can we possibly justify ignoring the flow devices—the very foundation of production—and instead focus on improving the production tools known as the equipment? But people often make the big mistake of failing to take this "fundamentalist" perspective. Instead, they consider improving the equipment the basic point and then try to adjust the flow devices to suit the improved equipment.

I call this erroneous reasoning the "company cop-out." People realize that to change production's flow devices, they first must change people's attitudes. But changing people's attitudes is much easier said than done. After all, those attitudes are deeply intertwined in the complex web of interdependency that forms part of the company's "character" or "culture."

How much easier it seems to avoid all that awareness revolution hassle and solve the problem with money. This "quick fix" temptation is a major stumbling block, leading to the endless pit known as "plant investment." Quite a few U.S. and European companies have stumbled into that pit. The world's largest automaker and Europe's oldest automaker are among the stumblers.

JIT improvement faces a more hostile environment in Europe and America, where the workers are less motivated and the labor unions more powerful than they are in Japan, which means that Western managers find it harder to influence the corporate character or culture. Pressured by an emphasis on short-term evaluations of their company's business performance, Western managers are even more sorely tempted to use the "company cop-out" and prematurely invest in new equipment.

Japan is more fortunate in that Japanese companies regard their employees as their basic asset. And that is the way it should be: Go straight to employees to improve flow devices. We need to understand that equipment improvements are appropriate only as a secondary development built upon a solid foundation of improved flow devices.

Lesson 20. Don't Jump to the Equipment Conclusion!

Five Problems Typically Encountered When Improving Equipment

To sum things up from the previous section, production is rooted in people. We start by focusing on people and on their work as it relates to flow devices for production.

In doing their work related to production flow devices, people invent and introduce tools to facilitate production. Production equipment is among these tools. Remember: First comes the flow devices and next comes the tools. No one would even dream of chartering an airplane for a trip across the street to the neighborhood market. A pair of shoes on your feet will do just fine for that.

The tools change only after the work-related flow devices change. If we have a shish-kabob, large-lot production system, we will want to have equipment suitable for that kind of system. The product's parts may be tiny, but when you put them together into lots of 10, 100, or even 1,000 they can get rather bulky. Such huge production lots require big equipment in order to reach a similarly large scale. Soon we start putting a greater emphasis on how big and fast a machine is rather than on how well it performs its function. Likewise, we start concentrating on the speed of specific processes and lose sight of the overall production flow. Before we know it, we are investing absurd amounts of money in big, advanced equipment. The basic concept for production flow devices is that *we build using only what we need for one-piece flow manufacturing.* This is the idea that we must keep in mind when deciding what equipment to use.

Admittedly, this idea is not much fun compared to the thought of customizing the production equipment to suit your own fancy and buying new equipment that comes equipped with interesting technologies. I suppose we never really lose that childhood desire to playfully take toys apart or to show off new toys to our friends.

Production engineers and equipment technicians often get together to ask equipment-loving managers for new toys. Managers should be forewarned never to buy equipment just because some people think it would be nifty. It would even be a mistake for managers to pay for the equipment out of their own pockets.

There is something that poses even greater production problems than money: what to do about the production flow once one or more new pieces of equipment have been brought in. And if the new equipment really messes up the production flow, who is going to take responsibility for correcting the situation? Often, the whole factory has to be redesigned in order to find a production flow that can include the new equipment.

Figure 2.27 illustrates five types of problems one can run into when making equipment improvements.

Problem 1: Equipment improvements cost money— A woodworking plant was having trouble with a production bottleneck in its plywood fabrication process. Specifically, pressing the boards was taking too long and the company management decided to scrape the money together to buy a high-frequency press to speed up the pressing time. However, it was only after the press was delivered that they discovered that the previous process (frame-making), which used metal tacks to hold the frames *together, was not compatible with the*



Figure 2.27 Five Types of Equipment Improvement Problems.

high frequency press. As a result, the company was unable to use its expensive new toy.

It is amazing how common these kinds of mistakes are. People tend to think only of specific processes (workers think only of their own) and they do not give much thought to what effects a new piece of equipment's characteristics or design might have on other processes. They also tend to bring new equipment into the production line without first considering what it will mean for the overall line. The result is that expensive equipment gets abandoned because it is difficult, and sometimes impossible, to make it work as part of the production line. Need we be reminded that the point of improvements is to remove waste, not add to it?

Problem 2: Unless operation improvements have been made, equipment improvements will only reinforce waste—This tale comes from a factory that builds control components. Management had decided to shoot for the goal of a completely automated, "workerless" factory, and had instructed equipment engineers and technicians to analyze the current situation. The plan was to automate the entire factory—from receiving materials to shipping finished products. The company came up with the mega-money needed for this ambitious project, and within six months the equipment was installed and running. The automated equipment churned out products similar in quality to what they had had before. The factory was able to cut its workforce drastically and both the company president and factor superintendent were pleased as punch.

But they overlooked a few things. In order to include five value-adding processes, they needed to lengthen the production line several hundred meters. Most of the new line was occupied by industrial robots that pickup, set down, and otherwise arrange parts. Although it would have been quite possible to have parts soldered in a one-piece flow, the robot system required that parts be arranged into batches of about 20, which the robots dip into a soldering vat. Since the soldering is done in batches, it is hard to achieve consistency. Therefore, management brought in a computer-controlled robot to inspect the soldering.

As you can see, the company neglected removing waste from their old operations, and therefore simply incorporated that invisible waste into the automated system. When waste is due to human operations, it can almost always be removed by improvements in operations. But once the waste is embedded in a complicated set of equipment, it may well be stuck there forever. This automated production line is accompanied by several hundred meters of in-process inventory The company has also tied up its money in an unmanned material handling system that has absolutely nothing to do with adding value to its products. Suddenly control parts have become a very expensive product to make!

Problem 3: The equipment improvement cannot be started over again—At a diecasting plant, an increase in production volume resulted in a bottleneck at the shotblasting process. The company's solution was to buy a much larger shotblasting machine that could handle several times the current production volume. It was so big and bulky, however, that it had to be placed in another room for use whenever a bottleneck occurred.

Sure, the new shotblasting machine could handle several times the processing load, but to do so required shotblasting diecastings in batches. The diecastings banged into each other while being deburred by the shotblasts, resulting in a great number of damaged, defective diecastings. The factory managers then decided to station two people as quality inspectors responsible for sorting the defective diecastings from the nondefective ones. The amount of stock-on-hand doubled and the big machine's placement in another room required a forklift for conveyance.

Without bothering to first improve the operations, this factory saw its problem simply in terms of insufficient capacity and jumped to the conclusion of installing a larger machine. Waste created more waste because, after installing the large machine, the shotblasting process included more waste (in inspection, conveyance, etc.) than before.

In such cases as this, even when the people concerned realize their mistake and start gnashing their teeth in regret, it is too late: The equipment has been bought and the improvement cannot be started over again.

Problem 4: Production is becoming more equipmentoriented than people-oriented—Even in smaller factories, it is not hard to find such things as large, expensive production machinery and equipment, and multimillion-dollar automated production lines. There are numerically controlled (NC) machines for functions ranging from coating to drying, rinsing, shotblasting, vat soldering, lathing and drilling, and some factories line these advanced machines up in fully automated machining lines or assembly lines. Some companies invest a mint in automated conveyance systems and sophisticated automated warehouses until their factories begin to appear more like conveyance and warehousing centers than manufacturing centers.

These types of equipment improvements cost lots of money, only further embed waste into the production system, and in many cases cannot be rejected as a bad idea once they are installed. Soon, the worst possible thing happens: The factory employees take the attitude, "Well, we bought all this expensive stuff, now we'd better get maximum use out of it." This is an attitude that changes the orientation of factory work away from the workers and places it on the equipment.

Let us imagine, for instance, a factory where the workers have dug a large pit to accommodate a big new machine. Once the machine is installed, there it sits, stuck in one place, as if to proclaim, "No matter what kind of product we switch to, I have to do my work right here."

I am amazed at how inflexible some "flexible automated production lines" actually are. They generally cannot handle a wide range of product models. Consequently, the lots on these lines gradually grow larger and larger.

Problem 5: Factories lose all concern for customer needs—When factory managers grow attached to fixed ideas, such as: "That machine has to stay where it's bolted," "Frequent changeovers reduce efficiency," and, "We've got to increase capacity utilization," the factory's "character" seems to lose all concern for customer needs.

The high cost and irreversibility of equipment improvements are serious problems indeed, yet they are nothing compared to the problem of a company that has become more concerned with its equipment than with its customers' needs.

Lesson 21. Use the Manufacturing Flow to Design the Equipment

Twelve Conditions for Introducing New Equipment

As mentioned earlier, some factories have rushed into buying and installing new equipment in the name of "improvement" or "rationalization" before thinking of how their current operations and methods might first be improved. The managers at these factories bring in new equipment as something separate from the factory's work operations and then, when things do not work out as well as planned, they believe the factory workers are at fault.

This tendency is especially prevalent among the equipment engineering staff at corporate head offices. Knowing precious little about how things are actually made at the factory, these engineers instead study up on the "elegant" functions and advanced technological features of state-of-the-art equipment, and are lured by their interest into encouraging the purchase of large, expensive new machines. Later, when product model changes, quality problems, operational snags, and other problems start cropping up, these engineers typically write a report to their superiors with the verdict that "the factory workers have not yet learned to use the equipment correctly." Guilt invariably lies on the factory floor, not in the engineering department.

Meanwhile, at the factory, the foremen and workers have had no choice but to try their hardest to "get the hang" of using equipment that is in many ways ill-suited for their manufacturing needs. And still it is the factory people, not the engineers, who come under fire from top management. This shows how little the top managers understand the situation.

To help enlighten everyone in this regard, I have put together the following list of 12 guidelines for introducing new equipment. I hope that all equipment engineers at corporate headquarters will read this list, and especially hope that top managers take these guidelines to heart.

Guideline 1: Use today's sale's figures, not next year's forecast figures—Many companies opt to buy new equipment based on one- or two-year projections of how much they can expect to reap in sales revenues. In other words, these companies are counting their chickens before they are hatched. Once they have installed and start using the new equipment, the companies find they have much more production capacity than they need, and have bought into an "overkill" solution for their previous capacity shortages. Yet despite their new capacity for much larger production volume, the volume stays about the same.

In recent years, it has become more difficult for manufacturing companies to forecast sales figures. We are no longer in an era where steady, rapid growth can be taken for granted.

That is why it is imperative that companies be more conservative by introducing only the equipment they need to support profitability based on today's figures. If the volume of orders starts expanding, the company can respond prudently by gradually adding to its small manufacturing cells. Market needs can vary widely, so it is best to introduce equipment conservatively, and only when warranted by current market needs.

Guideline 2: Remain fully committed to one-piece flow manufacturing—Some processes, such as pressing, cleaning, and soldering, naturally lend themselves to processing workpieces in batches. The tendency is to design such processing equipment to handle increasingly larger lots. But this is a mistake.

It seems more rational and easier to opt for batch processing whenever possible, and it seems a sure-fire productivity booster. But we need to remember that presses, rinsers, and such do not manufacture products on their own. Certainly, we can raise the capacity of each of these processes by using them for batch processing, but the result will be an uneven flow and a net *lowering* of production capacity for the overall manufacturing system. Once we begin devoting some equipment to batch processing, we also will find ourselves soon moving toward bigger and bigger machines with ever larger and larger capacities.

No matter how much a particular process can handle and how quickly it can handle it, it will not add to overall profitability if it exceeds the pitch specified by the order shipment schedule. It is far better to have equipment that will reliably turn out quality products one piece at a time in pace with the shipment pitch than to have even the most impressive batch-processing equipment. (One-piece production flow is described further in Chapter 5.)

Guideline 3: Emphasize cycle time over speed—The speed at which the line moves should be directly tied to the specified production volume for that day. Obviously faster production speeds mean higher daily output levels. That fact alone leads many engineers toward faster machines. There are even engineers who virtually equate increased speed with more advance technology.

The amounts specified in customer orders should determine how many minutes or seconds it should take to process parts or quasi products. We call this amount of time the "cycle time" or "pitch" of production, and we should gear our equipment to keep pace with that pitch. (Cycle time is described further in Chapter 10.)

Guideline 4: Make the equipment both versatile and specialized—How many managers have shouted the battle cry "From now on, we're going to have wide variety production!" while rushing out to spend a fortune on expensive general purpose machines? Once the factory actually starts using one of these do-it-all machines, it finds that changeovers do not go very smoothly and that the machine has various other restrictions, so that the productivity gain is not what everyone had expected. Often, these general purpose



Figure 2.28 Specialized Lines to Meet Wide Variety Production Needs.

machines, which are supposed to do everything, do not do anything particularly well.

But suppose, for instance, that we have a manufacturing line staffed by 20 workers. If we are running four product types through this line, we can split the line in half, with each half operated by 10 workers and specializing in two of the four product models. Alternatively, we could even split the original line into four lines with five workers apiece, and each line could specialize in just one product model. This is a much better way to meet the need for wide variety production. (See Figure 2.28.)

This principle works the same way for individual machines. Get rid of the general purpose machines with their wasteridden hodgepodge of functions. Instead, stick to inexpensive machines that can be used as specialized machines but can also be made versatile enough to handle product model changes.

Guideline 5: Keep equipment compact and readily movable—With any hope, the days are numbered for huge machines that get plopped down for eternity in one place as if to say, "This is where I stay no matter what product we switch to!" New products are being developed all the time, and the product diversification trend is still gaining momentum. Factories are learning that the most efficient equipment layout is the one that suits the current product models. The grouping of equipment into in-line patterns requires equipment that is both compact and furnished with casters or other devices for easy movability.

Guideline 6: Make equipment easy to operate and keep machine work and human work separate—We can never get far in training workers in the various skills needed to handle several machines if the machines are so "user hostile" that it takes a "an old hand" to handle them correctly. Likewise, machines that require constant nursing and supervision are hardly conducive to production efficiency.

Instead, the machines should be easily operable by any worker and the workers should be able to physically separate themselves from the machines while the machines are running. Only then are the machines appropriate for multiprocess handling. The basic rule for workers being trained in multi-process handling is that this work is chair-free. They must stand (or walk) while working.

Guideline 7: Workpieces should enter and exit each machine at the same spot—Often, machines—especially woodworking machines—take unprocessed workpieces in one side of the machine, process them, and expel them on the other side. Such an arrangement stands in the way of both single-worker handling and multi-process handling by usually requiring a worker on one side to feed workpieces into the machine, and a second worker on the other side to take out the processed workpieces.

To avoid this situation, the workpiece must either be processed in a fixed position or must be automatically returned to the entry point after processing. The best-designed machines are those that support "set-up, set-up work" or "remove, remove work" (in which the worker either sets up or removes a series of workpieces at a series of machines) by expelling each processed workpiece or leaving it where it is, if it is easily extractable. **Guideline 8: Build in inspection functions**—Automated machines that are simply automated—meaning they just move by themselves—will keep on moving even after they begin turning out defective products. Before long, there is a large pile of defective junk in front of the machine. To avoid this, we need to turn machines that simply "move" on their own into machines that really "work" on their own.

We can do this by installing *poka-yoke* (mistake-proofing) devices that can "inspect" (detect) when the first defective product has been made or can sometimes even detect when the first one is about to be made. Once these devices detect a defect, they shut off the machine. (*Poka-yoke* is described further in Chapter 12.)

Guideline 9: Keep defective and nondefective products easily countable—In the case of inspection devices for semiconductors and other high-precision products, it is especially helpful to keep defective and nondefective units clearly separated and countable at a glance.

Guideline 10: Make equipment easy to maintain— Regrettably, there are many engineers who seem to only care about how well machines build or process products. Obviously, that is a good thing to care about, but if the machine is going to be a reliable workhorse over time, it needs to be user friendly for maintenance workers. The idea is to give full consideration to both the machine's work functions and its maintainability.

Guideline 11: Keep a clean machine—One does not need to visit too many factories to find machines that are oozing oil or that are surrounded by scattered processing debris. Aside from frequent sweeping and cleaning in line with the "5S" doctrine, shop floor workers need to pinpoint what things are causing the mess and improve them. After all, the 5S's are much easier to maintain if the equipment barely makes a mess to begin with!

Guideline 12: Make sure the equipment keeps you informed—*Poka-yoke* devices are not enough: After detecting

a defect and shutting down, each machine should also be able to light an *andon* (alarm lamp) and/or sound a buzzer to let the operators know something has happened. Together, *poka-yoke* and *andon* enable both visual and auditory control.

Lesson 22. Think of Machines as Living Things

Approach to Inspection and Management: Sampling Inspection and Full Lot Inspection

The following describes something that happened at a QC meeting held in a certain factory.

The company was having no luck reducing the steady stream of defect claims and other complaints from its customers. It had tried hanging big banners with QC slogans such as "Quality First" and "This Month Is Quality Assurance Month," but to no avail. Its whole QC effort was just one big defeat. The customer complaints had even *increased* since beginning its QC campaigns.

The factory superintendent spoke out loudly. "We must double our inspection staff and approach this thing more rationally!" he said.

Perhaps the superintendent had grown cynical about the whole affair. But his suggestion was serious, although fundamentally flawed.

Already, we can identify two misunderstandings held by the group. The first is the notion that inspection somehow eliminates defects. No matter how many quality inspectors you put in the factory, the defects are already built into the products long before the inspectors spot them. Defects are results. Clamping down on these "defect" results will not reduce them. At best, such a move will succeed only in screening out the major defects and marginally reducing customer complaints. The point they missed is that defects must not be built into the products in the first place.

Their second misunderstanding concerns the real meaning of "rational." Each product passes through the care of many people on its journey from factory to market and finally to the customer. Each of these people may have a different idea of what is rational.

Some may reason that full lot inspection just takes too much time and statistical studies have shown that sampling inspections do the job well enough. This belief about inspections is especially popular in factories. Many factory workers will vehemently assert that sampling inspection is by far the most rational way to inspect products.

The truth is that they do not know the truth.

The truth is that "rational" is a very treacherous term. It means "compatible with reason." But, as alluded to above, perceptions of reason differ from person to person. In fact, it is nearly impossible to find a common perception of reason shared by everyone. So the problem is that one person's reason might be another person's folly. There is no way to satisfy both of them.

What kinds of people are likely to find sampling inspection a reasonable idea? For starters, the people in the factory are bound to find it reasonable. After all, who in a factory likes the job of rooting out defective products? They would much rather have to apologize now and then for shipped defects than to take all the time and trouble to perform full lot inspections.

Figure 2.29 illustrates a common situation: a factory that has decided it could live with an Acceptable Quality Level (AQL) of 0.1 percent, which means an average of one defective product per 1,000 products.

Production people are proud to report an AQL of "only" 0.1 percent. But from the customer's perspective, that means that the company is happy to sell a lemon to one unlucky customer per thousand! The unlucky customers will not start smiling again when they consider the company's 99.9 percent nondefective rate. He or she is too busy regretting the purchase of a 100 percent defective product.



Figure 2.29 Estimated Quality.

Remember this: One little "oops" by the maker brings one big "ouch" to the buyer. Sampling inspections go with the odds. The odds are good, but not nearly good enough to avoid having losers. Factories that are market-oriented never stray from taking the customers' perspective in their approach to manufacturing their products.

The so-called rational approach works great in general. But we need to consider how rational our approach seems to the individual customer.

Naturally, countless factory managers counter the above with, "Yeah, but do you know what switching to full-lot inspection would do to our costs?" Yes, I know. But then again, 100 percent quality—more than anything else—separates the manufacturing amateurs from the true professionals. After all, what are all those "expert" production engineers for? What is the whole field of industrial engineering for if not 100 percent quality?

Lesson 23. Quality is Built into Products at Each Process

Monitoring and Managing

I cannot recall how many times I have had discussions such as the following with top managers at manufacturing companies.

- "We don't know what to do. We can't seem to increase our control level at all. We can't even get a handle on all the in-process inventory between the process stations."
- "Hmmm. Tell me more."
- "It's just that we want to gain a better understanding of what is going on and somehow manage to control it in a more timely way. But how can we start doing that?"
- "Well, sounds like I'd better teach you the best way to do that." (This last remark always ignites an eager sparkle in their eyes.) "Let's totally eliminate inventory between processes. Down to zero."

The managers invariably greet that last remark by dropping their jaw and staring in wide-eyed amazement. It is not what they expect to hear—not even close, in fact. They expect me to say things like, "Let's make better use of computers. We'll install network monitors all over the factory so we can immediately enter data to keep track of how operations are going and where the inventory is moving."

But the real solution is simply not that complicated.

When managers express the desire to "have better control," they are admitting a failure to understand how factory operations proceed and why they slow down at times. They are also admitting that they have not clearly identified the causes of various shop floor problems, such as product defects and excess between-process inventory. To solve these problems, they imagine it necessary to build a new, more sophisticated factory management and control system, even though building and maintaining such a system will cost a fortune and take untold months or years of effort. Ironically, the end result will be a production system that has become even more complicated and thus more difficult to understand.

Take a look around any large factory and see how many signs include the word "control" or "management." Such signs are everywhere. There is "production management" to manage the entire production system, "financial management" to manage the money, "personnel management" for the employees, "sales management" to keep an eye on the market, and various other self-explanatory types of management or control, such as "client order management," "process control," "delivery management," "quality control," "subcontract management," "cost management," "inventory control," "in-process inventory control," "shipment management," and so on.

One could easily gain the impression that people in manufacturing are embracing the concepts of "control" and "management" like some kind of security blanket.

Some deliveries have been late. What does the company do? It creates a "delivery management" system, replete with a "deadline monitoring system" to monitor whether or not current delivery deadlines are kept.

Some defects occur. Quality is the lifeblood of the company, so the managers make a big fuss about developing a "QC organization," again replete with a "quality monitoring system" to continually keep track of defect occurrences.

What? Too much inventory? Time to set-up an inventory control organization, replete with...

And so it goes. Figure 2.30 provides an amusing illustration of how "monitoring" gets mixed up with "managing" (especially in Japanese, where both words are pronounced *kanri*).

In other words, when factory managers (monitors?) find a problem, they tend to respond by adding the word "management" or "control" to the name of the problem. They put off for later the idea of looking into what actually caused the problem to occur and what can be done to correct the situation.



Figure 2.30 Monitoring (kanri) and Management (kanri).

Still, almost all managers have this proclivity toward attaching the security-blanket words "management" and "control." The more "management" and "control" systems they create in response to problems, the higher costs rise. I suppose we could call such costs "security-blanket costs."

If these managers would instead channel that same energy toward repeatedly asking, "Why did that problem occur?" until they reach the real root of the problem, they would already be halfway toward implementing improvements to correct the situation.

In most factories, inventory (warehouse inventory, in-process inventory, and between-process inventory) is like a huge, thick blanket that covers up a panorama of causes for problems. If they could only pull that blanket away, all sorts of causes would suddenly become visible. Yank away the cover of in-process and between-process inventory, and suddenly it is obvious how poorly organized the production system is and what can be done to start preventing defects.

Therefore, the first thing to do is reduce inventory to zero. Next, make improvements to solve the most serious problems that suddenly appear. Then redesign the entire production system so that materials fed into the system can be sent through it smoothly-without any retention-to become finished products.

Some people who still have not completely caught on to this idea might still be wondering, "Once we've gotten all that inventory out of there, don't we need to set-up a management system to control the timely flow of inventory?"

To those people, I simply say, "If you have inventory, you need inventory control. If you don't have inventory, you don't need inventory control."

Another way to put this is: The best type of management removes the need for management. We might observe just as accurately that management systems and organizations, once established, have a life of their own.

I could cite case after case in which companies whose scope and volume of business were steadily shrinking still kept their management divisions as big as ever. Management organizations know how to grow, but do not know how to shrink.

Parkinson's Law is alive and well.

Lesson 24. Keep Monitoring Out of Managing

Approach to Promoting Improvements: Pseudo Improvement and Real Improvement

Here is an exchange I once had with a factory employee while starting to implement JIT improvements:

"Hey, what's all this?" I asked, pointing to a pile of cardboard. "Oh, that's the cardboard we use to box up Product A."

I knew right away what kind of beginner's mind-set I was dealing with. Did this person really think I didn't know what cardboard was? Did he think that I was touring the factory to learn about the products they were making? A JIT-minded person would recognize immediately that I was really asking, "Why is this pile of inventory here?" I turned and left that workshop. The people there did not have the slightest idea what JIT improvements meant. It was a waste of time at that point. This person was a rank beginner, a "white belt" in the martial art of JIT improvement.

At other workshops, people had a somewhat better understanding of JIT. When I asked the same question to one worker, he said, "We don't have anywhere to put that stuff right now, so we're keeping it there just for now."

He was beginning to get the idea. But he should have realized I was not interested in hearing excuses. I wanted to know what they were going to do to remove the pile of inventory.

A somewhat more advanced beginning JIT student would say something like, "Right. We'll get right to it," and then make a note of it. The attitude is correct: Acknowledge the problem, then write a memo. Now we are getting somewhere. I would give that person a beginner's black belt.

A still more advanced JIT beginner would get out the memo pad and make a note of it while acknowledging the problem with a simple "Right" or "Got it." Then he would issue an improvement instruction and have the improvement made as soon as possible. Then he would check up on the improvement and make any overlooked items the next items for improvement. Acknowledge, act, and follow up. That puts this person in the second rank of black belts.

Unlike the JIT white belts, the JIT black belts knew how to go about making improvements as soon as the inventory pile was pointed out to them. This makes the difference between "pseudo improvement" and "real improvement." Let us take another look at this important distinction.

Improvement item pointed out—"What's with this pile of stuff here?" (points toward in-process inventory).

Pseudo improvement

The worker seems confused at first when the problem is pointed out. He would not be so confused if he knew what he was doing. But since he does not understand what JIT improvements really are, he feels a vague sense of guilt as if he were
lazy or not doing things right. Still ignorant of how to make real JIT improvements, he starts making pseudo improvements.

He scans the walls for a large enough space, where he puts together some shelves. He then moves the pile of stuff from the floor to the shelves. A look of pride appears on his face as he claps the dust off his hands. This man is clearly a "white belt." If possible, he should be downgraded to an even lower rank should he have the inclination to tell a JIT inspector, "I made an improvement."

Real improvement

As soon as the problem is pointed out, the factory employee gets right on it. During the next two or three minutes, he asks a series of "Why?" questions to get to the root cause of the problem. This questioning process is *a must* for making real improvements. We call the process the 5W1H method, in which we need to ask "Why?" at least five times to get to the real cause, then we ask "How?" in order to make the improvement.

The pseudo improvement, in which my question, "What's with this pile of stuff here?" prompted the worker to build shelves and move the stuff to the shelves, the worker's "improvement" made the workshop appear neater but it also grants approval to the pile of inventory by "enshrining" it on specially-built shelves. Instead of removing inventory-related waste, this approach only adds permanence to it.

The 5W1H method is a radically different approach that brings real improvements. We begin this approach by simply asking "Why?" as in, "Why did that pile of inventory accumulate there?" This brings a response, such as, "The people at the previous process have been putting their deliveries there."

At this point, some people might rush into a pseudo improvement, saying," Well, let's build some shelves and get that stuff off the floor!" as a simple (actually, simplistic) solution to the problem.

But that is not the right approach. Instead, we need to ask "Why?" again, as in, "Why do the people at the previous

process put their deliveries there?" Let us suppose the response this time is, "Because they're done with it." Now one important fact has surfaced: The factory is using the "push" production method. We have found the basis for an improvement plan: The factory needs to switch from "push" to "pull" production.

But we are still not done asking "Why?" at least five times. The third "Why?" might be, "Why is the previous process producing so much stuff?" The response to that could be, "They can't send the workpieces downstream one at a time," or "They have to process batches for economy's sake."

Each of these responses should be addressed by a fourth "Why"? To the first response, we can ask, "Why can't they send them one at a time?" and, to the second response, "Why is it uneconomical to get rid of batch processing?" Let us suppose the response to both of these questions is, "Because the changeovers take so much time." This brings another problem to the surface: the need to improve changeovers at the previous process. (See Figure 2.31.)

While this and the "shelving solution" are both improvements, one is just a pseudo improvement and the other is real improvement. No matter how much thought, action, time, and expense go into a pseudo improvement, it will not improve the workplace a bit. Only by getting to the bottom



Figure 2.31 **Pseudo Improvement and Real Improvement.**

of the problem through the 5W1H method can we make sure our improvements are real ones.

The "white belt" workers who do not know how to make *real* improvements need to be handed a 5W1H sheet and told what to do with it. (See Figure 2.32.)

Lesson 25. 5W1H

"Mental" Improvements and "Physical" Improvements

This JIT manual includes explanations of the things most essential to JIT improvements in factories:

- JIT's basic concepts
- Improvement techniques and their functions
- Improvement "know-how" and case studies

JIT improvement consultants make use of know-how that they have accumulated over many years.

Some aspiring students of JIT may imagine that if they read this manual cover-to-cover without overlooking a single word or phrase, they can expect to be full-fledged JIT improvement consultants when they close the back cover. The same thing may happen in companies with industrial engineers. They may read this manual and then fancy themselves veteran JIT/IE professionals. As soon as these people put this book down, they will be off preaching the JIT gospel to others.

Let us nip this potential disaster in the bud right now. *JIT improvement is not a theory or technique*. JIT improvement is a discipline, one might even say an art, that is based at first on faith and then, gradually, on accumulated experience, wisdom, and intuitive "gut feelings." JIT improvement is a process, a path leading toward revolutionary progress in manufacturing, and this manual is nothing more than an entry and basic guide to that path.



Figure 2.32 Example of How to Use the 5W1H Sheet.

JIT improvement expertise cannot be garnered from books. Neither can it be learned by talking about it or by listening to others talk about it.

Several years ago, TQC was all the rage in Japanese manufacturing circles. In fact, the TQC movement spread from factories to hospitals and even government offices.

Its application scope seemed boundless.

TQC had a lot going for it. After all, there is nothing at all wrong with asking everyone in the company to brainstorm solutions to problems and make improvements. However, the result was often long on form and short on substance. It became obvious that people were aiming their improvement efforts toward a impressive announcement meeting rather than toward substantial changes in the workplace.

JIT improvement eliminates all emphasis on formalities and announcement meetings.

Factories that have embraced TQC often become wall-towall displays of advocatory posters, signboards, and banners emblazoned with such popular TQC slogans as "Orderliness and Cleanliness," "Let's Raise Productivity," "Let's Reduce Inventory," and "The Next Process Is Your Customer."

Nothing gets improved in factories full of TQC posters. Or perhaps I should say that factories get filled up with TQC posters because nothing gets improved.

I remember seeing a factory floor where a "Let's Reduce Inventory" banner that hung from the ceiling was partially hidden by a huge heap of inventory. That is what happens when form becomes more important than substance.

JIT improvements are not a set of slogans to be written here and there.

TQC makes use of the "Seven QC Tools." One of these tools is the Pareto chart, which is often used to analyze defects. These charts quite legibly indicate the type and number of defects and are drawn very neatly Then they are posted in the factory so everyone can read them. This is all fine and good, but it is unfortunate indeed what often happens afterward. People start reading the charts as if they were lottery results or TV game-show competitions, saying, "Hey, look who scored number one in defects this week!" After a while, it gets hard to tell the best from the worst.

People also tend to get distracted from the real point of the charts by their natural tendency to admire the craftsmanship of its carefully drawn illustrations. This unfortunate tendency to channel the seven QC tools toward making impressive statistical displays for people to admire instead of making full-fledged improvement efforts has prompted the invention of a nickname for QC's seven tools: QC fireworks.

JIT improvement gets rid of the flash and bang of TQC and keeps things pure and simple. JIT improvement is not about seeing, reading, talking, listening, mathematizing, announcing, or writing. It is about *improving*.

So how can we properly define JIT improvement? My suggestion is that JIT improvement is factory-based improvement toward the realization of JIT production. These factory-based improvements are not primarily based on reading, writing, or even seeing. As their name implies, they are about improving factories.

JIT improvement emphasizes only one verb: doing. (See Figure 2.33.)



Figure 2.33 "Mental" Improvement and "Factory" Improvement.

In JIT improvements, we just show up at the factory and get cracking. Everyone immediately starts using their wits and their bodies to make improvements.

Everything involved in making the improvement happens right there at the factory. Each person is on his or her feet and stays standing for hours, if necessary. If we stay on our feet and remain focused on the factory itself, the factory will be the teacher, providing the ideas and clues needed to start making improvements.

The factory itself will softly whisper into our ears such invaluable teachings as the movement of the machines, the flow of goods, the items in need of improvement. To be able to hear these barely audible whispers, we need to stand very calmly and explore the factory with deep interest. As we do this, we gradually and naturally acquire skill in identifying such things. We need to do what we can to foster this skill.

Nothing could be more foolish than launching improvement campaigns from desks and blackboards. In study rooms, we have to rely on our mental pictures of the factory. That leaves too much of a gap between what we remember and what conditions actually exist in the factory. When improvements are based on such mental images instead of the factory itself, the result can only be disappointment and despair.

People who have had more than the average number of years in academia tend to fall into the bad habit of making such "mental" improvements. In seeking to make improvements, we must use the body—not the mind—as the main perceptive instrument. We need to feel as if we had cut off our own heads and sent them home for a while.

Lesson 26. The Factory Is the Best Teacher of Improvements

Bottom-up Improvements and Top-down Improvements

Generally, there are two ways to make things better.

One way is to meticulously research current conditions and methods, analyze the research results, then improve the problem points. This is the inductive method. The other way is to state the ideal conditions and methods, and gradually improve current conditions until they approximate the ideal. This is the deductive method. Whenever people speak of "improvement," they are speaking of at least one of these two methods. The inductive method is the conventional industrial engineering (IE) method. The deductive method is the JIT improvement method.

The conventional IE method is an attempt to raise the level of quality based on a thorough analysis of current conditions. It is thus a "bottom-up improvement" method.

By contrast, the JIT improvement method takes the ideal of "JIT production" as the basis or final cause for making improvements. It is thus a "top-down improvement" method. Actually, the ideal at the top does not go down in any way but is used to pull conditions upward, and so it would be more precise to call JIT a "top-up improvement" method. For simplicity's sake, it is better to keep a sharp contrast with IE's bottom-up approach by calling the JIT approach "top-down improvement."

The same contrast in methods can be seen in other fields, too. For instance, in budgetary accounting there is the "build-up method" and the "zero-base method." In price setting, there is the "cost-based method" and the "market value method." In systems design, there is the "analytical system design" method and the "work design" method.

Perhaps the closest analogy to factory improvement is child rearing. Here, the two methods are the "faultfinding" method, in which the child is scolded for everything he or she does wrong, and the "dream-instilling" method, in which the vision of achieving a future goal or hope is deeply instilled in the child.

It is not always easy to say which factory improvement method is better—the IE method or the JIT method. It depends very much on the company. However, we must not lose sight of the critical need for companies to root out bad habits and make fundamental changes to survive in today's world of trade friction, fluctuating exchange rates, and severe competition.

Such radical change does not come from "improvements" in the ordinary sense of the word, that is, in small, incremental improvements. Instead, such companies require innovation and revolutionary changes. And for making those kinds of changes, the conventional IE method is difficult indeed.

What makes the IE method so difficult is that, as a method based on analysis of current conditions, it must begin with "recognizing" and therefore to some degree "accepting" current conditions. We study the status quo in order to make it a little bit better, but we never ask the radical question, "Why are things the way they are?"

For example, consider a factory that has a conveyance system. To make just one improvement in this system, we must take totally different approaches depending upon whether we use the IE method or the JIT method.

If we use the conventional IE method, we begin by carefully analyzing the conveyors and the way things are distributed by them. We can then note that the conveyors place some items in sites from where they can easily be removed and other items in less accessible sites. We can graphically analyze this phenomenon in a "conveyor use index" chart. The chart plots items that are left piled on the floor as the lowest value in optimum conveyor use and items that are still being moved on the conveyor as the highest value in optimum conveyor use. As shown in the graph in Figure 2.34, there are five levels of conveyor use including the lowest and highest just described.

Using the IE method, we identify the low points on the analyzed use index and seek to improve them to have higher use levels (therefore easier to convey), so that the overall average use index becomes higher.



Figure 2.34 Conveyor Use Index (IE Method).

To be sure, this sort of improvement should help goods flow more smoothly, and if they actually do flow more smoothly, that itself can be expected to have positive effects.

However, this improvement method falls short of asking the radical "Why?" question: Why does this conveyor system have to exist? Therefore, it is not a revolutionary method. Instead, it accepts the conveyance system as a *fait accompli* and goes directly to attempting improvements in it.

I know of many factories that have thoroughly implemented this conventional IE approach. In every one of these factories, roller conveyors have been installed between every process. Conveyors cover these factories like so many cold, black carpets. In-process inventory is set upon these narrow conveyors. The utmost goal of the IE method for improving these conveyors is to raise their average use index to the highest use level. Beyond that, the IE method envisions nothing in the way of further improvements.

Now let us examine how we might apply the JIT method in one of these factories. We would begin by getting rid of all of the roller conveyors. Why? Because, as mentioned earlier, the JIT method regards improvements to an existing conveyor system as "pseudo improvements," which JIT professionals avoid like the plague.

After getting rid of the roller conveyors, the JIT method calls for the creation of a new factory layout and new work methods that allow production to proceed without any conveyance system at all. If such improvements are made, the factory will be rendered free of any need for conveyance and its attendant problems.

As you can see, both of these methods (IE and JIT) are called "improvement methods," but that is about all they have in common.

JIT is so revolutionary that some people have half-seriously suggested it is a religion. Perhaps it is. Like most religions, JIT offers an ideal state of being (for factories, at least) and challenges the factories to try to attain that state. But there is nothing evangelical about JIT. If anything, JIT is an inner-directed, contemplative "religion" that asks its followers to focus on their own companies, factories, workplaces, and selves. JIT begins with a quiet introspection into all of these things. If it has any close cousin in the field of religion, it would probably be the Japanese Zen sect that sprang from contemplative Buddhist sects in India and China.

JIT has no set organizational structure or "how to" manual. No doubt this makes the goal of approximating JIT production all the more difficult. When people hear this, they often ask, "So what is the best way to carry out JIT improvements?" To this frequent question, I have two answers up my sleeve. One is, "Go into the red." In other words, take the poor man's approach to making improvements and spend as little money as possible.

The other answer is, "Believe in JIT." This answer goes especially to top managers, for it is they who must first believe in JIT in order to get middle managers and their subordinates to believe. Although belief in JIT must start with top managers, its most essential believers are the factory employees. If they truly believe in JIT, they will make big improvements in their factories.

I should also add that the goal of JIT production should never be far from the hearts and minds of everyone. Getting there requires faith.

> Lesson 27. Keep JIT in Mind and Apply Improvements to Yourself

"Yes" and "Yes, I'll Do It Right Away"

Day-to-day life is awash in information, provided via such media as newspapers, books, radio, television, and so on. As a result, we all have second-hand knowledge about a wide variety of subjects.

For example, you or I may not be athletic in the least, but if we watch sports programs on television, we come to understand a lot about certain sports without having to actually go out and run, jump, or sweat. Likewise, some people develop a strong sense of affinity and familiarity with foreign lands and peoples based solely on what they have read in travel literature or have seen on TV.

We can find the same kind of people in the field of JIT improvements. People who have never even set foot in a factory will confidently explain such things as flow production to their friends. Such people have achieved some skill at "mental improvements," but have no experience at all in "physical improvements."

I do not know how many times I have heard discussions and debates on JIT improvement that include nothing but "mental improvements." Mental improvements, no matter how skillful and eloquent they may be, are of no help at all in the real world of physical improvements. Mental improvements are devoid of value unless they are followed up by a trip to the factory, long and diligent efforts, and results that are seen and felt physically.

Second-hand knowledge is useless for JIT improvements. JIT improvements need hands-on learning.

Let us take an imaginary trip through a factory that is currently undergoing some improvements. Right now we are standing in front of a manufacturing cell where an important improvement—switching to flow production—has just been made.

"You have a U-shaped cell now, so you've got to stop working with lots."

Even a simple instruction such as this one spurs different reactions at different workplaces. The reaction is a good indication of how fully the JIT improvement method has been accepted and incorporated. I have been able to delineate seven stages of JIT acceptance, as illustrated in Figure 2.35.



Figure 2.35 Seven Stages in the Acceptance of the JIT Improvement Method.

Stage 1: "But, blah, blah, blah..."

Excuse-making is the worst possible response. It would be better not to say anything than to try to make excuses. During a factory visit, I can tolerate about three excuse-makers if I am in an exceptionally good mood, but if my mood is not so expansive, even one excuse-maker is enough to convince me that the factory is not worth any more of my time. I'm not at all interested in visiting factories where the people are only pretending to be carrying out JIT improvements.

Stage 2: [silence]

There are actually two types of silent responses. One is when the person is too wrapped up in trying to figure out how to make the improvement to say anything, and the other is when the person is just plain put off by the instruction.

The first kind of silence is OK, though not exactly polite, but the second kind is very bad indeed. The person who responds this way usually lacks perseverance and patience, resists change, and harbors resentment against those who propose changes. JIT leaders are always being "stabbed in the back" by this type of person. Rather than feel the chill wind blowing through the knife holes in his or her back, it is better that the JIT leader just find the nearest exit.

Stage 3: "Yes, I'll look into it."

This can be seen as the total opposite to the silent response at the second stage. The respondent sounds upbeat and attentive. But the chances are that he or she is making an empty promise. I have learned that you can trust a factory worker who says, "I'll look into it," about as much as you can trust a typical politician who says, "I'll be sure to address that problem." They might as well be saying, "OK, I won't do a thing."

On my next visit, I usually voice a short, sarcastic remark such as, "My, you folks are really doing a lengthy study of this problem," before moving directly to the next workshop. To sum things up so far, the three bad responses are: "But *blab*, *blab*, *blab*," "[silence]," and "Yes, I'll look into it." Factories where such responses are common are on the fast track to Nowhere as far as JIT improvement is concerned. To get back on the right track and survive as a business, they need to launch a company-wide campaign to abolish such counterproductive attitudes to make room for JIT improvement to firmly take root.

Stage 4: "OK."

Like a silent response, a simple "OK" can have more than one meaning. It may seem like a simple and total acceptance of the instruction, but it is not very good communication. One cannot tell, for instance, whether the meaning is, "Yes, the current way is wrong," or "Yes, you're right." A more precise answer that reflects the respondent's meaning would be better.

Stage 5: "Yes, I understand."

While not as bad as a too simple and too vague "OK," this response still suffers from vagueness.

Improvements are not primarily something to be "understood" intellectually. They are things to be *done* in the factory. Understanding them without doing them means nothing. In fact, it is *only by doing them* that we can really understand them. So, I usually meet this response with something like, "After you've made the improvement, I'll be able to see whether you understood it or not."

Stage 6: "Yes, I'll do it."

When the person immediately gives this response, you know he or she has cleared a big hurdle. It is very big step indeed to get from a simple "Yes" to an energetic, "Yes, I'll do it."

There is only one hurdle left: the question of when it will get done. Obviously, if the respondent's intention is to get it done about six months from now, he or she has not really made it to Stage 6 after all.

Stage 7: "Yes, I'll do it right away."

During a factory visit, when I give even the mildest kind of instruction and hear this sincere response, I know I am dealing with a JIT champion who has taken the JIT improvement method to heart.

When the typical type of response in a factory improves from "Yes," to, "Yes, I'll do it," and finally, "Yes, I'll do it right away," I can tell just how far the people have come in understanding JIT. After all, JIT is almost synonymous with "doing it right away."

> Lesson 28. Attitude Adjustment: From "Yes" to "Yes, I'll Do It Right Away"

A Passion for Improvement

JIT improvement includes more than building a few custommade jigs and removing waste from operations. Obviously, these small improvements can add up to something big and are a key part of JIT improvement. But the real gist of JIT improvement is the discarding of old ideas and habits, changing over to flow production, and otherwise overhauling the entire factory until it becomes a factory that efficiently serves the current needs of the marketplace. This amounts to nothing short of a factory revolution and a major innovation in the way to conduct business.

JIT improvement rightfully stands among the ranks of other movements that have resulted in major business innovations. JIT turns factory improvements into innovations. The most important prerequisite for innovation is *enthusiasm*. The ability to remain constantly enthusiastic—something we admire in young people—is a vital part of the JIT improvement approach.

But what about the over-30 set? How are they supposed to keep up their enthusiasm?

One good way is to put some psychological distance between ourselves and our workplace. When a series of



Figure 2.36 JIT Improvement (Innovation) Cycle.

problems occurs in the workplace and cause disorder, we need to be detached and objective enough to look at the situation with a child's eyes and ask the typical child's question: "Why?" The more we lose this ability to wonder and ask "Why?" the harder it becomes to revolutionize the factory and its long-established traditions.

After we learn to keep wondering and asking "Why?" we come to the next hurdle: dealing with difficult problems. This is the time for brainstorming. It is also the time when conflicts begin.

If we rub two objects together, we get friction. Likewise, friction also may occur in the human mind when improvement ideas rub up against current habits. It gets people's dander up, but by the same token, it can also get their enthusiasm up. If we can keep fanning the flames of this enthusiasm, all we need after that is the determination and strength to revolutionize the factory. Then we just do it.

This entire process moves in cycles: First we go to the workplace, then we look around with a child's eyes and ask, "Why?" Next, we confront conflict and fire up our hearts with youthful enthusiasm, then we pour our energy into making the improvements. This cycle is called "the JIT Improvement (Innovation) Cycle." (See Figure 2.36.)

Lesson 29. Improvement Is Enthusiasm

Index

1973 oil crisis, 8 3 Mu's, 643 eliminating, 151 5 Whys and 1 How, 24, 128, 129, 130-134 waste discovery by, 208-210 5MQS waste, 152-153 conveyor waste, 155-156 disaster prevention measures waste, 159 large machines waste, 154-155 materials waste, 157 parts waste, 157 searching waste, 154 shish-kabob production waste, 158 walking waste, 153-154 waste in air-processing machines, 156-157 waste in defective goods production, 159 waste in meetings, 158 watching waste, 154 workpiece motion waste, 158-159 5S approach, xii, 230, 237-238, 455, 689, 721 as bridge to other improvements, 264 as prerequisite for flow production, 344 benefits, 238-243 changeover 5S checklist, 512 for factory improvement, 15-17 in changeover procedure improvement, 502 keys to success, 262-264 meaning, 243-249, 250 orderliness applied to jigs and tools, 307-319 red tag strategy for visual control, 268-293 red tags and signboards, 265–268 role in changeover improvement, 533 seiketsu (cleaned up), 246-247 seiri (proper arrangement), 243-245 seiso (cleanliness), 246 seiton (orderliness), 245-246 shitsuke (discipline), 247-249 signboard strategy for visual orderliness, 293-306 visible 5Ss, 249-262 5S badges, 255, 257

5S checklists, 258, 259 for changeover, 818-819 5S contests, 258 5S implementation memo, case study, 286 58 maps, 261–262 58 memos, 755-757 58 mini motto boards, 255, 257 5S patrol score sheet, 258-259, 260 5S photo exhibit, 260 5S radar chart, 754 5S stickers, 257, 258 5S-related forms, 747 5S checklists for factories, 747-749 5S checklists for offices, 753 5S checklists for workshops, 750-752 58 memos, 755-757 5S radar chart, 764 cleaning checklist, 768-770 display boards, 775-776 five-point checklist to assess cleaned-up status, 771-774 lists of unneeded inventory and equipment, 764-767 red tag campaign reports, 761-763 red tags, 758-760 5W1H Sheet, 131, 744-746 and on-site experience, 233, 235 first Why guidelines, 233 follow-up after line stops, 234 three 5W1H essentials, 233 waste prevention with, 232-233 7 Ms plus E&I, 551, 552

Α

A-B control, 676, 677 Acceptable Quality Level (AQL), 121, 122

Accident-prevention devices, 698 poka-yoke, 699-709 Accidents plywood gluing process, 696 reasons for, 685-687 Actual work environment. See On-site experience Added-value work, 75 Address signboards, 299 Adjustment errors, 560 Adjustment waste, 510 Administrative waste, 173 and clerical standardization, 229 disposal case study, 291 After-sales service part requests, 162 Air-processing machines, waste in, 156–157 Airplane andon, 466 Alerts, 672 Aluminum casting deburring operation, operations analysis table, 192 Amplifier-equipped proximity switches, 578 Andon systems, xiii, 11, 129, 231, 676, 679, 680, 682 hire method for using, 465-466 illuminating factory problems with, 464 operation andon, 468-469 paging andon, 465-466 progress andon, 469-470 types of, 465 warning andon, 466-468 waste prevention using, 232 Anticipatory buying, 162 Anticipatory large lot production, 286–287 Anticipatory manufacturing, 162 Apparent minor defects, 680 Appropriate inventory, 96 Arm motions, 220-221 Arrow diagrams, 187-188, 211, 347, 730 applications, 730 examples, 731-732 printed circuit board assembly shop, 189 tutorial. 187-190 ASEAN countries, xi Assembly line applying *jidoka* to, 660 extending jidoka to, 676-682 jidoka o prevent oversights in parts assembly, 680-681 stopping at preset position, 69, 678-680 Assembly method error, 678 Assembly parts, exchange of, 499

Assembly processes changeover example, 495 changing to meet client needs, 20 establishing specialized lines for, 371-373 kanban in, 447-448, 448 management of, 81 manpower reduction example, 428 multi-process operations in, 363 standing while working in, 355-359 warning andon for long, 468 warning andon for short, 467 Assembly step omission, 592 Attitude adjustment, 143-144 Auditory control, 120, 231 waste prevention with, 230-232 Auto feed time, 635 Auto parts machining line, 400 Auto-extract devices, 657 Auto-input devices, 657 Automatic shut-off, 672 Automation, 102-103, 111 limitations of, 79 reinforcement of waste by, 111 vs. Jidoka (human automation), 656, 657-658 Automobile assembly plant, parts shelves, 460, 461 Awareness revolution, 103, 104, 105, 159, 176, 199, 344, 641, 721 as premise for JIT production, 46, 344 as prerequisite for factory improvement, 13 - 15

В

Back-door approach, to waste discovery, 181–183 Back-to-the-source inspection, 168, 170–172 Backsliding, 229 Basic Spirit principles, 203, 204 Baton touch zone method, 359, 368, 491, 492 Bills of materials, 81, 83 Blade exchange, 498 Board insertion errors, 594 Body movement principles, 220–221, 220–223 Body, as main perceptive instrument, 134 Bolt removal, eliminating need for, 521, 536 Bolt tightening reductions, 520 Boltless approach, 535 Boltless die exchange, 523 Bolts as enemies, 509, 535 making shorter, 535 Bottlenecked processes, 364 Bottom-up improvements, 134-139 Bracket attachment errors, 603 Brainstorming, 208 factory problems as opportunities for, 208 Breakdowns for standard operations charts, 638 reducing through 5Ss, 241 Bridge defects, 598 Brush omission errors, 609 Buyer's market, 18 Bypass method, as leveling technique, 491-492

С

Capacity imbalances, 161–162 between processes, 214-215 overcoming through 5Ss, 239 retention and, 161-162 Capacity leveling, 21 Capacity requirements planning (CRP), 442 Capacity utilization rates, 68, 331, 341, 684 and variety of product models, 504 Capacity-load imbalances, 151 Capital procurement, 93 Caravan style operations, 407, 423 Case studies drilling machine worker separation, 669-672 factory revolution, 287-289 red tag strategy at Company S, 285-289 Cash-convertible assets, 93 Caster strategy, 349-350, 420. See also Movable machines Chair-free operations, 19 Change, resistance to, 40, 201 Changeover 5S checklist, 512 Changeover costs, 73 component costs, 73, 74 variation in, 597 Changeover improvement list, 505, 810-811 time graph analysis, 513

Changeover improvement procedures, 500-502 applying 5Ss to eliminate waste, 502 changeover improvement list, 505 changeover kaizen teams for, 503-506 changeover operations analysis, 501-502, 506-508 changeover operations analysis charge, 508 changeover results table, 507 eliminating waste with 5Ss, 508-511 external changeover procedures, 501 identifying wasteful operations, 508-511 improving external changeover, 502 improving internal changeover, 502 injection molding process case study, 515-517 internal changeover procedures, 500 kaizen team, 501 public changeover timetable, 505 transforming internal changeover to external changeover, 502 waste, 501 Changeover improvement rules, 532-533 role of 5Ss, 533-534 Changeover kaizen teams, 501, 503-506 Changeover operations, 71, 347, 723 adjustment waste in, 510 and introduction of synchronization, 373 approach to changeover times, 499-500 assembly line improvement example, 495 avoidance of, and retention, 162 balancing costs with inventory maintenance costs, 72 changing standard parameters, 499 exchange of dies and blades, 498 exchanging assembly parts, 499 external changeover time, 500 general set-up, 499 in JIT production system, 11 internal changeover time, 500 minimizing number, 216 procedures for improvement, 500-532 production leveling strategies for, 494-495 rationale for improvement, 497-498 reducing through 5Ss, 242 replacement waste in, 509-510 seven rules for improving, 532–539 shortening time for, 494 standardizing, 538-539 time-consuming nature of, 216, 219

types of, 498-499 within cycle time, 514 Changeover operations analysis, 501-502, 506-508, 535 chart, 508 Changeover results table, 507, 815-817 Changeover standards, standardizing, 537 Changeover times, 499-500 Changeover work procedure analysis charts, 812-814 Checking, 691 Cleaned up checklist, detail, 256 Cleaned up, visibly, 253 Cleaning checklist, 768-770 Cleanliness, 16, 246, 690-691 five-point checklist, 772 of machinery, 119 visible, 253 Cleanliness check cards, 692 Cleanliness control board, 691 Cleanliness inspection checklist, 254, 690, 692 Cleanliness, Checking, and Oiling (CCO), 689-693 training in, 708 Cleanup, 16, 246-247 Cleanup waste, in external changeover procedures, 511 Clerical standardization, 229 Client needs, as determinant of capacity, 22 Client orders, as basis for cycle time/pitch, 70 Color coding, 253 for maintenance, 693 for oil containers, 319 in changeover improvements, 534 in kaizen boards, 462 Color mark sensors, 574, 580 applications, 582 Combination charts, 224 clarifying human work vs. machine work with, 664 for standard operations, 223-226 steps in creating, 630-632 wood products manufacturer example, 226, 227 Communication about 5S approach, 263 errors in, and defects, 555-556, 558 Compact equipment, 19, 117-118, 340-341, 427, 484 as condition for flow production, 340-341, 342

building flexibility through, 419 compact shotblaster, 354 compact washing unit, 356 cost savings from, 354 diecast factory case study, 375-376, 377 for multi-process operations, 398-399 separating human and machine work with, 431 Company cop-out, 107, 108 Company-wide efficiency, 68 Company-wide involvement, with 5S approach, 262 Complexity and waste, 648 in moving parts, 694 Component efficiency, 66 Computer-based management, 81 Computerization and waste, 83 expendable material created by, 157 waste-making, 81 Computers failure to shorten physical lead-time, 5 red tagging, 278-281 Confirmed production schedule, 439 Constant demand, products vs. parts, 475-476 Contact devices, 570 differential transformers, 572 limit switches, 570 microswitches, 570 Container organization, for deliveries, 385 Continuous flow production time, 19 Continuous improvement, 211 Control devices, 567 Control standardization, 228 Control/management waste, 149 Conveyance liveliness index, 304 Conveyance waste, 69, 149, 163-166, 173, 176, 180, 187, 336, 355-356, 392 links to retention, 164 Conveyor systems appropriate use of, 70-71 improving equipment layout to eliminate, 79 waste hidden in, 67 Conveyor use index, 137 Conveyor waste, 155-156 Cooperative operation confirmation chart, 788-790 Cooperative operations, 367-371, 419 improvement steps for, 369 labor cost reduction through, 427-430

placing parts in front of workers for, 370 VCR assembly line example, 429 Cooperative operations zones, 370–371 Coordinated work, waste in, 67 Corporate balance sheet, inventory in, 94 Corporate culture, 15 Corporate survival, xii Corrective maintenance, 688 Cost reduction, 69-71 and effort invested, 71-74 and profit, 36 resistance arguments, 200-201 through 5Ss, 239 through *jidoka*, 659 Cost, in PQCDS approach, 3 Cost-up method, 35 Countable products, 119 Craft unions, vs. enterprise unions, 393-394 Crane operations, safety *poka-yoke*, 706 Cube improvements, 27 Current assets, 93 Current conditions, analysis to discover waste, 185-198 Current liabilities, 94 Current operating conditions, 24 Customer complaints, vs. defects, 547-548 Customer lead-time, 99 Customer needs, loss of concern for, 113-114 Customers, role in efficiency improvement, 62-65 Cutting tools layout, 317 orderliness applied to, 316–319 placement, 317 storage, 318 types of, 317 Cycle list method, 487-489 reserved seats and, 489-490 Cycle tables, 485 Cycle time, 19, 22, 332, 337, 363, 433, 630, 634, 637, 647. See also Pitch and production leveling, 421-422 and standard operations, 625 as leveling technique, 485-487 calculating, 487 completing operations within, 636 factors determining, 70 for standard operations charts, 637 overproduction and, 677 smaller equipment for maintaining, 398 vs. speed, 116

D

Deburring omissions, 589 Defect identification, 546 and causes of defects, 558-561 and factors behind defects, 550-558 defects as people-made catastrophes, 546-547 inspection misunderstandings, 547-550 Defect prevention, 168, 177 assembly step omission, 592 board insertion errors, 594 bracket attachment errors, 603 bridge defects, 598 brush omission errors, 609 deburring omissions, 589 defective-nondefective part mixing errors, 613 drilling defects, 600, 675-676 E-ring omission errors, 611 equipment improvements for, 640 gear assembly errors, 614 grinding process omission, 591 hole count errors, 588 hole drilling omission, 593 hose cut length variations, 597 incorrect drill position, 601 left-right attachment errors, 615 mold burr defects, 674-675 nameplate omission errors, 608 packing omission errors, 610 part omission errors, 607 pin dimension errors, 595 press die alignment errors, 596 product set-up errors, 602 spindle hole punch process omission, 590 tap processing errors, 606 tapping operations, 673-674 through 5Ss, 241 through automatic machine detection, 403 through jidoka through simplified production operations, 549 torque tightening errors, 599 with kanban, 441-442 with multi-process operations, 392 workpiece direction errors, 605 workpiece positioning errors, 605 wrong part assembly errors, 612 Defect production waste, 176-177, 180

Defect reduction, 168, 544 with compact machinery, 399 Defect signals, 567 Defect-prevention devices, 659, 669, 673 Defective assembly parts, 678 Defective item display, 457, 458 Defective products and inventory, 92 counting, 119 ending downstream processing of, 544-545 factories shipping, 542 increases with shish-kabob production, 158 increasing inspectors to avoid, 542-544 inventory and, 90-91 noncreation of, 545-546 waste in making, 159 Defective/nondefective part mixing errors, 613 Defects and communication errors, 555-556, 557, 558 and inspection, 548 and production method errors, 555, 557 and surplus products, 549 as human-caused catastrophes, 546-547 causes, 558-561 due to human errors, 551, 553, 557, 558 due to machine errors, 554-555, 557 factors behind, 550-558 in materials, 553-554, 557 relationship with errors and inspection, 543 stoppages for, 567 ten worst causes, 561 vs. customer complaints, 547-548 Delays, reducing through 5Ss, 242 Delivery and loading methods, 379 and transport routes, 380-382 and visible organization of containers, 385 applying flow concept to, 378-382 color coding strategy, 384 FIFO strategy, 384-385 frequency of, 380 in PQCDS approach, 3 self-management by delivery companies, 383 Delivery company evaluation table, 382, 791-793 Delivery schedules, shortening of, 2

Delivery sites applying flow concepts to, 382-385 establishment of, 383 product-specific, 384 Detach movement, automation of, 671-672, 673 Deterioration, 686 and accidents, 685 preventive measures, 688 reversing, 688 Die exchange, 498 improvement for boltless, 523 minimizing, 497 Die height standardization, 526-527 Die storage sites, proper arrangement and orderliness applied to, 530-531 Diecast deburring line, 351 Diecast factory, flow production case study, 373-378 Differential transformers, 572 Dimensional tolerances, 686 Dimensions, enlarging, 311 Disaster prevention measures, waste in, 159 Discipline, 16, 247–249 JIT Improvements as, 130 visible, 254-255 Displacement sensors, 574 applications, 579-580 Display boards, 775–776 Distribution, applying JIT to, 47 Diversification, 2, 117, 415, 416 of consumer needs, 62 through 5Ss, 242 Do it now attitude, 236 Doing, as heart of JIT improvement, 133 Dot it now attitude, 236 Double-feed sensors, 576 applications, 584 Downstream process control inspection method, 169, 170 Drill bit replacement, external changeover improvement, 532, 533 Drill bit storage method, improvements, 235 Drill operation, before improvement, 670 Drill position errors, 601 Drilling defects, 600 avoiding downstream passing of, 675-676 Drilling machine, 662 detach movement, 671-672 hold motion automation, 671 jidoka case study, 669-672

safety plate for, 703, 704 separating human from machine work on, 402

Ε

E-ring omission errors, 611 Economical lot sizes, 72 Economy of motion, 642 Economy of scale, 45 Efficiency and production leveling, 69 approaches to, 59-61 customer as driver of, 62 estimated vs. true, 59-61 individual and overall, 66-69 maximizing at specific processes, 484 overall, 484, 492 raising in individual processes, 68 shish-kabob vs. level production approaches, 484, 486 Electric screwdrivers, combining, 315 Emergency andon, 464 Employees, as basic asset, 108 End-of-month rush, 162 Energy waste due to inventory, 325 through inventory, 91 Engineering technologies, applying JIT improvement to, 334 Engineering-related forms, 777 5S checklist for changeover, 818-819 changeover improvement lists, 810-811 changeover results tables, 815-817 changeover work procedure analysis charts, 812-814 cooperative operation confirmation chart, 788-790 delivery company evaluation charts, 791-793 JIT delivery efficiency list, 794-796 line balance analysis charts, 785-787 model and operating rate trend charts, 805-807 multiple skills evaluation chart, 799-801 multiple skills training schedule, 797-798 P-Q analysis lists/charts, 777-781 parts-production capacity work table, 822-824

poka-yoke/zero defects checklist, 820-821 process route diagrams, 782 production management boards, 802-804 public changeover timetables, 808-809 standard operations combination chart, 825-826 standard operations form, 831-833 summary table of standard operations, 827-828 work methods table, 829-830 Enterprise unions, vs. craft unionis, 393-394 Enthusiasm, as prerequisite for innovation, 143, 144 Equal-sign manufacturing cells, 362 Equipment applying jidoka to, 660 automation and human automation, 102 - 103compact, 19, 117-118 ease of maintenance, 119 ease of operation, 118 ergonomics recommendations, 222 for flow production, 389 improvements facilitating standard operations, 640 modification for multi-process operations, 406 movability, 64-65, 117-118 obtaining information from, 119-120 shish-kabob vs. flow production approaches, 331 standardization in Japanese factories, 395 versatility and specialization, 116-117 vs. work operations improvements, 103-108 Equipment breakdown, 708 acceptance of, 683 apparent minor defects, 680 below-expectation performance, 686 breakdown stage, 686 intermittent stoppage stage, 686 latent minor defects stage, 680 preventing, 693-695 stages, 685, 687 Equipment constitution, 694 Equipment costs and jidoka, 666 vs. labor costs, 658 Equipment improvement, 103, 104, 106 and company cop-out, 108 based on manufacturing flow, 114-120

cost of, 104, 109-111 irreversibility of, 112, 113-114 not spending money on, 207-208 reinforcement of waste by, 111-112 twelve conditions for, 114-120 typical problems, 108-114 Equipment improvement problems, 110 Equipment layout applying jidoka to, 662 as condition for flow production, 336-337, 342 for flow production, 389 in order of processing, 353-355 shish-kabob vs. flow production approaches, 330 Equipment signboards, 295 Equipment simplification, 400 Equipment waste, 149 Error control, 567 Error prevention boards, 457, 458 Errors, relationships with defects and inspection, 543 Estimate-based leveling, 23 Estimated efficiency, 59-61 Estimated lead-time, 98-99 Estimated production schedule, 439 Estimated quality, 122 Excess capacity, 174 Excuses, 202, 205 Expensive improvements, failure of, 206 Experiential wisdom, 210-211 External changeover improvements, 529-532 carts reserved for changeover, 531-532 drill bit replacement example, 532 proper arrangement and orderliness in die storage sites, 530-531 External changeover procedures, 501 cleanup waste in, 511 improving, 502 preparation waste in, 510 waste in, 510-511 External changeover time, 500

F

Factory as best teacher of improvements, 134–139 as living organism, 230 Factory bath, 270

Factory graveyards, 73 Factory improvement 5Ss for, 15–17 awareness revolution prerequisite, 13-15 shortening physical lead-times through, 6 vs. JIT improvements, 13 Factory layout diagram, 188 Factory myths anti-JIT production arguments, 40-44 fixed ideas and JIT production approach, 44 - 47sales price/cost/profit relations, 35-40 Factory problems, 326 as brainstorming opportunity, 208 illuminating with andon, 464 stopgap responses to, 150 ubiquitousness of, 251 Factory revolution, 287-289 Factory-based innovation, xiii, 133 Factory-wide efficiency, 68 Feed motion, 664 applying jidoka to, 665 jidoka, 670, 671 Feet, effective use of, 221-222, 223 Fiber optic switches, 575, 579 Finance, inventory and, 92–95 Fine-tuning waste, 537 removal, 523-527 Fingernail clipping debris, device preventing, 247 First-in/First-Out (FIFO), 302-303, 461, 462 as delivery strategy, 384-385 Five levels of quality assurance achievement, 542-546 Five whys, 24, 130-134, 183, 184, 210, 236 applying to changeover improvements, 535 waste discovery through, 208-210 Five-point checklist, 771 for cleanliness, 772 for proper arrangement, 772 Five-point cleaned up checklist, 255, 257-258, 773, 774 Fixed ideas, 235 about conveyors, 156 avoiding for waste prevention, 235-236 direct challenge to, 43 eliminating for waste removal, 204 kanban, 447 large lot production, 417 wall of. 210 Fixed liabilities, 94

Flexibility in baton touch zone method, 491 mental origins of, 420 Flexible production, 419 Flexible staff assignment system, 63, 65, 417, 419 Flow analysis, 188 summary chart, 189, 190 Flow components, 56 Flow control, 567 Flow devices, 108, 109 Flow manufacturing, xii, 9-10, 49, 64, 70, 79-84. See also One-piece flow and line improvements, 25 making waste visible by, 17 role in JIT introduction, 17-19 seven requirements, 19 Flow of goods, 159–160, 641, 646 device improvements facilitating, 638–640 Flow production, 50, 321, 564–565 and evils of inventory, 324-328 and inventory accumulation, 321-324 applying to delivery sites, 382-385 approach to processing, 329-330 at diecast factory, 374, 376 between factories, 332-333, 378-385 caster strategy, 349-350 defect prevention with, 721 diecast factory case study, 373-378 eight conditions for, 333–341 equipment approach, 331 equipment layout in, 330 for production leveling, 492-494 in medical equipment industry, 423 in multi-process operations, 388 in-process inventory approach, 331 interrelationship of factors, 343 lead time approach, 331 operator approaches, 330-331 preparation for, 344-350 procedure for, 350-373 rational production approach in, 330 reducing labor cost through, 422-424 sink cabinet factory example, 493 steps in introducing, 343-373 straight-line method, 340 U-shaped manufacturing cell method, 340 vs. shish-kabob production, 328-332 waste elimination techniques, 341-342 within-factory, 332–333, 333–341 Flow shop layout, 395 Flow unit improvement, 639

Forms, 711–714
5S-related, 747–776
engineering-related, 777–833
for standard operations, 626–628
JIT introduction-related, 834–850
overall management, 716–729
waste-related, 730–746
Free-floating assembly line, 356, 357
Full lot inspection, 120–122
Full parallel operations, 225
Full work system, 175, 365, 676–677
A-B control, 677
devices enabling, 368
pull production using, 367
Function-specific inventory management, 305

G

Gear assembly errors, 614 General flow analysis charts, 733–734 General purpose machines, 331, 340 Golf ball *kanban* systems, 450–451 Graph time, 633 Gravity, *vs.* muscle power, 221 Grinding process omission, 591 Groove processing lifter, separating human/machine work, 649 Group Technology (GT) lines, 347 for line balancing, 491

Η

Hand delivery, 365 Hand-transferred one-piece flow, 337, 338 pull production using, 366 Handles/knobs, 223 Hands-on improvements, 9, 140 Height adjustments, avoiding, 538 Hirano, Hiroyuki, xiii Hold motion, automation of, 671 Hole count errors, 588 Hole drilling omission, 593 Horizontal development, 24–25, 391 Hose cut length variations, 597 Household electronics assembly, labor cost reduction example, 428 Human automation, 12, 62, 102–103, 159, 554, 655. See also Jidoka (human automation) and removal of processed workpieces, 668 and setup of unprocessed workpieces/startup, 669 applying to feeding workpieces, 665 applying to return to starting positions, 667 for multi-process operations, 402 Human error waste, 173, 674 and defect prevention, 551-553 basic training to prevent, 562-563 defects and, 546-547 eliminating by multiple skills training, 563 minimizing, 177 Human movement body movement principles, 220-223 removing wasteful, 217-223 Human work, 658 clarifying with combination charts, 664 compact PCB washer example, 431 procedure for separating from machines, 682-689 separating from machine work, 64, 118, 400-402, 406, 430-432, 640, 649-650, 660-662, 702, 703 Humanity, coexistence with productivity, 387-388

Idle time waste, 66, 67, 69, 156, 173, 178–179, 180, 682 cooperative operations as solution to, 367–371 Impact wrench, 680, 681 Implementation, 139–144 of multi-process operations, 405 Implementation rate, for waste removal, 205–206 Improvement and enthusiasm, 143, 144 intensive, 266–268 making immediate, 538 poor man's approach, 106 spending on, 284

spirit of, 43 with visual control systems, 453-454 Improvement days, weekly, 32 Improvement goals, 191 Improvement lists, 33-34 Improvement meetings, 32-33, 33 Improvement promotion office, 31–32 Improvement results chart, 462, 844-845 Improvement teams, 31, 32 Improvements bottom-up vs. top-down, 134-139 factory as best teacher, 134-139 implementing, 24 mental vs. physical, 130–134 passion for, 143-144 promoting, 126-130 pseudo, 126-130 Improving actions, 220 In Time concept, 48 In-factory kanban, 443, 444-445 In-line layout, 364, 376 compact shotblaster for, 377 washing units, 365 In-process inventory, 101, 102, 161, 175, 447, 484 and standard operations, 625-626 for standard operations charts, 637 production kanban for, 445 reduction of, 647, 649 relationship to kanban, 435 shish-kabob vs. flow production approaches, 331 symbols for standard operations charts, 637 Inconsistency, 152, 643 eliminating, 151 Independent improvement, 688-689 Independent maintenance, 688–689 Independent process production, 53 inflexibility in, 54 Independent quality control inspection method, 169, 170 Individual efficiency, 66-69 Industrial engineering (IE), xii and conveyor use index, 137 motion study in, 642 vs. JIT method, 136 Industrial fundamentalism, 105, 106 Industrial robots, 668 Inexpensive machines, versatility of, 117 Information inspection, 168, 169 Inherent waste, 79-84

Injection molding process burr defect prevention, 674 internal changeover improvement case study, 515-517 Injuries reasons for. 695-697 reducing through 5Ss, 241 Innovation, 13, 37 and JIT production, 47-49 enthusiasm as prerequisite for, 143 factory-based, xiii in JIT production, 47-49 JIT production as, 27 Inspection, 56, 160, 187 back-to-the-source inspection, 170-172 eliminating need through jidoka, 674 failure to add value, 168 failure to eliminate defects, 120 increasing to avoid defective products, 542-544 information inspection, 169 preventive, 564 relationship to defects, 543, 547-550 sorting inspection, 169 Inspection buzzers, waste prevention with, 232 Inspection functions building into JIT system, 119 full lot inspection, 120-122 sampling inspection, 120–122 Inspection waste, 149 Inspection-related waste, 167-168 Integrated tool functions, 223 Intensive improvement, 266–268 timing, 268 Interest payment burden, 324, 326 inventory and, 90 Intermittent stoppage stage, in equipment breakdown, 686 Internal changeover improvements, 518, 534-535 bolt tightening reductions, 520 boltless die exchange, 523 die height standardization, 526-527 eliminating need to remove bolts, 521 eliminating nuts and washers, 521 eliminating replacement waste, 518-523 eliminating serial operations, 527-529 establishing parallel operations, 528 one-touch tool bit exchange, 522 protruding jigs vs. manual position setting, 524

removing fine-tuning waste, 523-527 spacer blocks and need for manual dial positioning, 526 spacer blocks and need for manual positioning, 524–525 tool elimination, 519-520 Internal changeover procedures changing to external changeover, 511-518, 534 improving, 500, 502 PCB assembly plant case study, 513-514 transforming to external, 502 turning into external changeover, 511-518 waste in, 509-510 wire harness molding process case study, 517-518 Internal changeover time, 500 Inventory advance procurement requirements, 325 and conveyance needs, 90 and defects, 90-91, 92 and energy waste, 91 and finance, 92-95 and interest-payment burden, 90 and lead-time, 87-89, 88 and losses due to hoarded surpluses, 325 and materials/parts stocks, 91 and price cutting losses, 325 and ROI, 95 and unnecessary management costs, 91 and waste, 48 as cause of wasteful operations, 325 as evasion of problems, 176 as false buffer, 95, 101 as JIT consultant's best teacher, 89 as opium of factory, 92-95 as poor investment, 95-98 breakdown by type, 161 concealment of factory problems by, 91, 92, 326, 327 evasion of problems with, 163 evils of, 90-92, 324-328 FIFO storage method, 303 in corporate balance sheet, 94 incursion of maintenance costs by, 325 interest payment burden due to, 324 management requirements, 325 product, in-process, materials, 101, 102 red tagging, 281-282 reducing with once-a-day production scheduling, 480-481

shish-kabob vs. level production approaches, 484-485 space waste through, 90, 325 unbalanced, 161 wasteful energy consumption due to, 325 with shish-kabob production, 158 zero-based, 98-102 Inventory accumulation and caravan operations, 322 and changeover resistance, 322 and distribution waits, 322 and end-of-month rushes, 323 and faulty production scheduling, 323 and just-in-case inventory, 323 and obsolete inventory flow, 321 and operator delays, 322 and resistance to change, 322 and seasonal adjustments, 323-324 and standards revision, 323 and unbalanced capacity, 322 multiple-process sources of, 322 reasons for, 321 Inventory assets, 715 Inventory control, 126 Inventory flow, obsolete, 321 Inventory graveyard, 324 Inventory liveliness index, 303-304 Inventory maintenance costs, 72 Inventory management function-specific method, 305 product-specific method, 305 with kanban, 436 Inventory reduction, 87, 89, 125 case study, 288, 289, 377 Inventory stacks, 303 Inventory waste, 175–176, 180 Irrationality, 152, 643 eliminating, 151 Item characteristics method, 568, 569 Item names, for signboards, 299–300 Ivory tower syndrome, 22

J

Japanese industrial structure, 1980s transformation of, xi Jidoka (human automation), 12, 62, 102–103, 103–108, 655, 724 applying to feeding workpieces, 665

automation vs., 656, 657-658 cost considerations, 667, 669 defect prevention through, 672-676 detach movement, 671-672 drilling machine case study, 669-672 extension to assembly line, 676-682 feed motion, 670 full work system, 676-677 manual labor vs., 655, 656 mechanization vs., 656 preventing oversights in nameplate attachments, 681-682 steps toward, 655-657 three functions, 658-660 Jigs 5-point check for orderliness, 256 applying orderliness to, 307 color-coded orderliness, 368-369 combining, 314 easy-to-maintain orderliness for, 307 eliminating through orderliness strategies, 313-316 indicators for, 308 outlined orderliness, 309 JIT delivery efficiency list, 794-796 JIT improvement cycle, 144 roles of visual control tools in, 473 JIT improvement items, 837-840 JIT improvement memo, 836 JIT improvements, 12, 13 "doing" as heart of, 133 and changeover costs, 74 and parts list depth, 82 as discipline, 130 as religion, 138 as top-down improvement method, 135 basis in ideals, 12 case study, 288 cube improvements, 27 factory as true location of, 34 from within, 139-143 hostile environment in U.S. and Europe, 107 improvement lists, 33-34 improvement meetings, 32-33 improvement promotion office, 31–32 lack of faith in, 41 line improvements, 25-26 plane improvements, 26-27 point improvements, 25 promoting and carrying out, 30-34 requirement of faith, 139

sequence for introducing, 21 seven stages in acceptance of, 140-144 ten arguments against, 299 vs. JIT production management, 7 vs. labor intensification, 86 weekly improvement days for, 32 JIT innovation, 13 JIT introduction steps, 12-13 5Ss for factory improvement, 15-17 awareness revolution step, 13-15 department chiefs' duties, 28-29, 30 division chiefs' duties, 28 equipment operators" duties, 30 factory superintendents' duties, 28-29 flow manufacturing, 17-19 foremens' duties, 30 leveling, 20-22 president's duties, 28 section chiefs' duties, 30 standard operations, 23-24 JIT introduction-related forms, 834 improvement memo, 836 improvement results chart, 844-845 JIT leader's report, 849-850 JIT Ten Commandments, 834-835 list of JIT improvement items, 837-840 weekly report on JIT improvements, 846-848 JIT leader's report, 849-850 JIT Management Diagnostic List, 715–718 JIT production adopting external trappings of, 472 as new field of industrial engineering, xii company-wide promotion, 28, 29 elimination of waste through, xi five stages of, 719, 721, 726, 728 guidance, education and training in, 30 hands-on experience, 30 in-house seminar, 343 innovation in, 47-49 linked technologies in, 334 promotional organization, 31 radar chart, 727 setting goals for, 28 structure, 720 JIT production management distinguishing from JIT improvements, 7 vs. conventional production management, 1 - 3JIT production system as total elimination of waste, 145 changeover, 11

flow manufacturing, 9-10 from vertical to horizontal development, 24 - 27human automation, 12 introduction procedure, 12-14 jidoka, 12 kanban system, 10 leveling, 11 maintenance and safety, 12 manpower reduction, 10 multi-process handling, 10 organizing for introduction of, 27-30 overview, 7-9 quality assurance, 11 standard operations, 11-12 steps in establishing, 14 view of waste, 152 visual control, 10-11 JIT radar charts, 719, 727, 729 JIT study groups, 15 JIT Ten Commandments, 834-835 Job shop layout, 395 Just-in-case inventory, 323 Just-In-Time anatomy of, 8-9 and cost reduction, 69-71 as consciousness improvement, 139-143 functions and five stages of development, 728 innovation and, 47-49 view of inspection work, 168

Κ

Kaizen boards, 462
visual control and, 471–473
with improvement results displays, 463 *Kanban* systems, xii, xiii, 7, 8, 10, 11, 52, 54, 174, 231, 365, 692, 722
administration, 447–451
and defect prevention, 441–442
and downstream process flow, 441
and in-process inventory, 435
applying to oiling, 693
appropriate use of, 70–71
as autonomic nervous system for JIT production, 440
as tool for promoting improvements, 441
as workshop indicators, 442

differences from conventional systems, 435 - 437factory improvements through, 440-441 fixed ideas about, 447 functions, 440-441 in processing and assembly lines, 447-448 in-factory kanban, 444-445 novel types, 450-451 production kanban, 445 production leveling through, 442 purchasing-related, 449-450 quantity required, 445-447 rules, 441-442 signal kanban, 445 supplier kanban, 443 types of, 442-447 visual control with, 457 vs. conventional production work orders, 437-439 vs. reordering point method, 435-437 waste prevention with, 232

L

L-shaped line production, 360 Labor cost reduction, 415, 418, 722 and elimination of processing islands, 421 and mental flexibility, 420 and movable equipment, 420-421 and multi-process operations, 421 and production leveling, 421-422 and standardized equipment and operations, 421 approach to, 415-418 display board for, 433-434 flow production for, 422-424 multi-process operations for, 424-426 multiple skills training schedule for, 432-433 steps, 419-422 strategies for achieving, 422–432 through cooperative operations, 427-430 through group work, 426–427 through separating human and machine work, 430-432 visible, 432-434 vs. labor reduction, 417-418 Labor cost reduction display board, 433-434

Labor intensity/density, 84-86 vs. production output, 86 Labor per unit, 649 Labor reduction, 63, 418, 647 vs. labor cost reduction, 417-418 vs. worker hour minimization, 66-69 Labor savings, 418 Labor unions, 107. See also Craft unions; Enterprise unions and multi-process operations, 393-394 Labor-intensive assembly processes, 217 Large lot sizes, 18, 62, 73, 278, 321, 398, 483, 598 and changeover times, 216 and machine waste, 155 as basis of production schedules, 476 case study, 286-287 fixed ideas about, 417 switching to small-lot flow from, 639 Large machines waste, 154-155, 331 Large-scale container deliveries, 381 Latent minor defects, 680 Latent waste, 198 Lateral development, 27, 378, 505, 506 Lateral improvement makers, 167 Lathes, 682 three kinds of motion, 663 worker separation from, 702 Layout improvement, 638 Lead-time and inventory, 88 and lot sizes, 498 and production lot size, 72 and work stoppage, 59-61 estimated vs. real, 98-99 inventory and, 87-89 lengthened with shish-kabob production, 158 paper, 4, 5 physical, 5 product, 4 reduction with multi-process operations, 393 shish-kabob vs. flow production approaches, 331, 486 shish-kabob vs. level production approaches, 484-485 shortening by reducing processing time, 55 Leadership, for multi-process operations, 404-405 Left-right attachment errors, 615

Leg motion, minimizing, 221 Level production, 475, 723. See also Leveling as market-in approach, 482 vs. once-a-day production, 481 vs. shish-kabob production, 482–485, 486 Leveling, 50, 476. See also Level production; Production leveling and production schedule strategies, 477-482 approach to, 476-477 capacity and load, 21 estimate-based, 23 reality-based, 23 role in JIT introduction, 20-22 role in JIT production system, 11 techniques, 482-492 Leveling techniques, 485 baton touch zone method, 491 bypass method, 491–492 cycle list method, 487-489 cycle tables, 485 cycle time, 485-487 nonreserved seat method, 487-489 reserved seat method, 489-490 Limit switches, 403, 470, 570, 676, 677, 706, 708 Line balance analysis charts, 785-787 Line balancing at PCB assembly plant, 514 SOS system for, 217 strategies for, 491 Line balancing analysis tables, 358 Line design, based on P-Q analysis, 346, 347 Line efficiency, 68 Line improvements, 25–26 Line stops, 470 5W1H follow-up after, 234 at preset positions, 678-680 with poka-yoke devices, 675 Lined up inventory placement, 304-306 Linked technologies, in JIT production, 334 Litter-preventive device, for drill press, 248 Load leveling, 21 Loading methods, 379 Long-term storage, case study, 291 Lot sizes, 45, 87 and lead time, 72 large vs. small, 71-74 Lot waiting waste, 215-216, 219 waste removal, 219 Low morale, 16

Μ

Machine errors and defect prevention, 554-555 poka-yoke to prevent, 564 Machine operating status, andon notification of, 466 Machine placement, waste and, 185 Machine signboards, 295 Machine standardization, 228 Machine start-up, applying *jidoka* to, 663, 668 Machine work clarifying with combination charts, 664 compact PCB washer example, 431 separating from human work, 64, 118, 400-402, 406, 430-432, 640, 649-650, 660-662 Machine/people waiting, 214 Machines as living things, 120-122 shish-kabob vs. level production approaches, 484, 486 with strong constitution, 708 Machining line, full work system, 677 Maintenance, 683, 725 and accidents, 685-687 and possible utilization rate, 684-685 breakdown prevention, 693-695 Cleanliness, Checking, and Oiling (CCO) approach, 689-693 defined, 684-689 existing conditions, 683–684 full-fledged, 708-709 improving through 5Ss, 241 in JIT production system, 12 of equipment, 119 Maintenance campaigns, 687-689 Maintenance errors, 560 Maintenance prevention, 688 Maintenance technicians, 689 Make-believe automation, 79 Man, material, machine, method, and management (5Ms), 152, 153 Management-related forms, 715 five stages of JIT production, 719, 721-725 JIT Management Diagnostic List, 715–718 JIT radar charts, 719 Manpower flexibility, 338 Manpower needs, based on cycle time, 22

Manpower reduction, 10, 62-65, 63, 337, 392 household electronics assembly line example, 428 improving efficiency through, 61 through flow production, 422-424 Manual dial positioning, eliminating with spacer blocks, 526 Manual labor, 655, 656 Manual operations, two-handed start/stop, 220 Manual position setting, eliminating need for, 524 Manual work time, 635 Manual-conveyance assembly lines, progress andon in, 469 Manufacturing as service industry, 1 five essential elements, 553 nine basic elements (7Ms plus E&I), 552 purpose of, 1 Manufacturing flow, as basis for equipment improvements, 114-120 Manufacturing process, components, 56 Manufacturing waste, 149 Market demand fluctuations, unsuitability of kanban for, 436 Market price, as basis of sales price, 35 Market-in production, xii, 416, 555 level production as, 482 Marshaling, 306 Mass production equipment, 216, 219 Material handling building flexibility into, 419 minimizing, 176 vs. conveyance, 164 Material handling costs, 159, 163 Material requirements planning (MRP), 52 Materials flow device improvements facilitating, 638-640 standard operations improvements, 641 Materials inventory, 101, 102 Materials waiting, 215, 218 Materials waste, 157 Materials, and defect prevention, 553-554 Measuring tools orderliness for, 318 types, 319 Mechanization, 656 Medical equipment manufacturing, manpower reduction example, 423 Meetings, waste in, 158

Mental improvements vs. implementation, 140 vs. real improvements, 130-134 Metal passage sensors, 574 applications, 581 Microswitch actuators, 571 Microswitches, 570, 674 Milling machine, safety poka-yoke for, 705-706 Minimum labor cost, 62 Missing item errors, 587, 607–611, 678 Mistake-proofing, 119 Mistakes, correcting immediately, 207 Mixed loads, 379 Mixed-model flow production, 492 Mizusumashi (whirligig beetle), 465 Model and operating rate trend charts, 805-807 Model lines, analyzing for flow production, 348 Mold burr defects, prevention, 674-675 Monitoring, vs. managing, 123-126, 126-130 Motion and work, 74-79 as waste, 76, 78, 79, 84 costs incurred through, 77 economy of, 642 lathes and, 663 vs. work, 657, 659 Motion study, 642 Motion waste, 639 improvements with standard operations, 639 Motor-driven chain, 694 Movable machines, 64–65, 65, 117–118, 165, 354, 420 and caster strategy, 349-350 building flexibility through, 419 Movement as waste, 178 improving operational efficiency, 642-649 non-added value in, 190 Muda (waste), 643 Multi-process operations, 10, 19, 64, 330, 359, 362-363, 387-388, 417, 722 abolishing processing islands for, 396-398 and labor unions, 393-394 as condition for flow production, 337-338 basis for pay raises in, 394 compact equipment for, 398-399 effective leadership for, 404-405 equipment layout for, 389

equipment modification for, 406 factory-wide implementation, 405 human assets, 389 human automation for, 402-403 human work vs. machine work in, 400-402 in wood products factory, 425 key points, 395-404 labor cost reduction through, 424-426 multiple skills training for, 400 one-piece flow using, 338 operational procedures for, 389 poka-yoke for, 402-403 precautions, 404-406 promoting perseverance with, 406 questions from western workers, 393-395 safety priorities, 403-404, 406 simplified work procedures for, 404 standard operations improvements, 639 standing while working for, 399-400 training costs for, 394-395 training for, 421 training procedures, 407-413 transparent operations in, 405 U-shaped manufacturing cells for, 395-396 vs. horizontal multi-unit operations, 388-393 Multi-process workers, 331 as condition for flow production, 339 at diecast factory, 377 Multi-skilled workers, 19, 390 and standard operations, 650-651 building flexibility through, 419 Multi-unit operations, 338, 391 vs. multi-process operations, 388–393 Multi-unit process stations, 390 Multiple skills contests, 405 Multiple skills evaluation chart, 799-801 Multiple skills maps, 432 Multiple skills score sheet, 410, 432 Multiple skills training, 425, 651 defect prevention with, 563 for multi-process operations, 400 schedule for, 432-434 Multiple skills training schedule, 797–798 Multiple-skills training, 407 demonstration by workshop leaders, 412 during overtime hours, 409 five-level skills evaluation for, 408 hands-on practice, 412 importance of praise, 413 in U-shaped manufacturing cells, 410 schedule, 409

team building for, 408 trainer roles, 413 workshop leader roles, 411 *Mura* (inconsistency), 643 *Muri* (irrationality), 643 Mutual aid system, 65

Ν

Nameplate omission errors, 608 preventing with *jidoka*, 681-682 Needed items, separating from unneeded items, 266 Net time, for standard operations charts, 637 Newly Industrialized Economic Societies (NIES), xi Next process is your customer, 51, 54, 132 Non-value-added steps as waste, 147, 171 in inspection, 170 in retention, 163 Noncontact switches, 572 color mark sensors, 574 displacement sensors, 574 double-feed sensors, 576 metal passage sensors, 574 outer diameter/width sensors, 574 photoelectric switches, 572, 574 positioning sensors, 574 proximity switches, 574 vibration switches, 574 Nondefective products, counting, 119 Nonreserved seat method, 487-489 Nonunion labor, 394 Nuts and washers, eliminating as internal changeover improvement, 521

0

Oil containers, color-coded orderliness, 319 Oil, orderliness for, 318–319 Oiling, 691–693 *kanban* for, 693 On-site experience, 190 and 5W1H method, 233, 235 by supervisors, 230, 233, 235 Once-a-day production scheduling, 480-482 Once-a-month production scheduling, 478-479 Once-a-week production scheduling, 479-480 One how, 24, 128, 130-134, 183 One-piece flow, 19, 64, 115–116, 165, 185, 419, 639. See also Flow manufacturing as condition for flow production, 335-336 discovering waste with, 183-185 hand-transferred, 338 in multi-process operations, 388 maintaining to avoid creating waste, 351-353, 353 revealing waste with, 350-351, 352 switching to, under current conditions, 184 using current equipment layout and procedures, 336 One-touch tool bit exchange, 522 Operation andon, 464, 468-469 Operation errors, 560 Operation management, 81 Operation method waiting, 215, 218 Operation methods, conditions for flow production, 342 Operation step method, 568, 569 Operation-related waste, 173, 178, 180 Operational combinations, 193 Operational device improvements, 640 Operational rules, standard operations improvements, 639-640 Operations analysis charts, 735-736 Operations analysis table, 190–192, 735, 736 aluminum casting deburring operation example, 192 Operations balancing, 219 Operations improvements, 103, 104, 105, 217 Operations manuals, 405 Operations standardization, 228 Operations, improving point of, 220 Operators conditions for flow production, 342 diecast factory case study, 377 maintenance routines, 691 reducing gaps between, 370 shish-kabob vs. flow production approaches, 330-331 Opportunistic buying, 162 Optical displacement sensors, 578 Oral instructions, avoiding, 556 Order management, 81

Orderliness, 16, 157, 245-246, 510 applied ti die storage sites, 530-531 applying to jigs and tools, 307 beyond signboards, 302-306 color-coded, 319, 384 conveyance liveliness index, 304 easy-to-maintain, 307, 310-313 eliminating tools and jigs with, 313–316 for cutting tools, 316-319 for measuring tools, 318 for oil, 318-319 four stages in evolution, 312 habitual, 302 inventory liveliness index, 303-304 just-let-go principle, 313, 314 lined up inventory placement, 304-306 made visible through red tags and signboards, 265-268 obstacles to, 17 visible, 252-253 Outer diameter/width sensors, 574 applications, 578 Outlined orderliness, for jigs and tools, 309-310 Outlining technique, waste prevention with, 231 Overall efficiency, 66 Overkill waste, 173 Overload prevention devices, 706 Overproduction waste, 69, 174-175, 180 beyond cycle time, 677 preventing with A-B control, 676–677 Overseas production shifts, xi

Ρ

P-Q analysis, 188, 345–346
P-Q analysis lists/charts, 777–781
Packing omission errors, 610
Paging *andon*, 464, 465–466
hire method for using, 466
Painting process, reserved seat method example, 490
Paper lead-time, 4, 5
Parallel operations, 224–225, 536
calculations for parts-production capacity work tables, 634

establishing in transfer machine blade replacement, 528 full vs. partial, 225 Pareto chart, 132, 457 Parking lots, well- and poorly-managed, 300 Parkinson's Law, 126 Part omission errors, 607 Partial parallel operations, 225 calculations for parts-production capacity work tables, 633-634 Parts assembly preventing omission of parts tightening, 681 preventing oversights with *jidoka*, 680-681 Parts development, 52 Parts inventories demand trends, 475 strategies for reducing, 475-476 Parts list, depth and production method, 82 Parts placement in cooperative operations, 370 standard operations improvements, 643 Parts tray/box, visible organization, 385 Parts waste, 157 Parts, improvements in picking up, 643-644 Parts-production capacity work table, 626, 629, 822-824 serial operations calculations, 633 steps in creating, 632–634 Pay raises, basis of, 394 PCB assembly plant, internal-external changeover improvements, 513-514 People as root of production, 104, 107, 108 training for multi-process operations, 389 Per-day production total, 487 Per-unit time, 633 Performance below expectations, 686 Personnel costs, and manpower strategies, 63 Photoelectric switches, 572, 574, 682 applications, 572 object, detection method, and function, 573 Physical lead-time, 5 Pickup kanban, 444 Piecemeal approach, failure of, xiii Pin dimension errors, 595 Pinch hitters, 407 Pitch, 66, 67, 337, 433, 469. See also Cycle time adjusting to worker pace, 358-359 approaches to calculating, 485

factors determining, 70 failure to maintain, 678 hourly, 482 individual differences in, 67 myth of conveyor contribution to, 156 Pitch buzzers, waste prevention with, 232 Pitch per unit, 649 Plane improvements, 26-27 Plywood gluing process, accidents, 696 Pneumatic cylinders safety improvement from, 694 workpiece removal with, 667 Pneumatic switches, 680-681 Point improvements, 25 line improvements as accumulation of, 26 Poka-yoke, 119, 159, 177, 675, 680, 682. See also Safety and defect prevention, 566 approaches, 568-570 concept and methodology, 565-568 control devices, 567 defect prevention with, 564 detection devices, 570-585 drilling machine case study, 703 for crane operations, 706 for multi-process operations, 402–403 milling machine example, 705–706 safety applications, 703-709, 709 safety cage on press, 704 safety plate case, 703 stop devices, 566-567 warning devices, 567 Poka-yoke case studies, by defect type, 586-587 Poka-yoke checklists three-point evaluation, 619-620 three-point response, 620-622 using, 616-622 Poka-yoke detection devices, 570 applications, 585 contact devices, 570-572 noncontact switches, 572-575 Poka-yoke/zero defects checklist, 820-821 Policy-based buying, 162 Position adjustments, avoiding, 537-538 Positioning sensors, 574 applications, 577 Positive attitude, 204-205 Possible utilization rate, 684-685, 708 Postural ease, 221 Power, inexpensive types, 222 PQCDS approach, 2, 3
Practical line balancing, 357, 358 Preasembly processes, scheduling, 477 Preparation waste, in external changeover procedures, 510 Preset stop positions, 680 Press die alignment errors, 596 Press operator, waste example, 77–78 Presses safety problems, 702 worker separation, 703 Preventive inspection, 564 Preventive maintenance, 688, 708 Previous process-dependent production, 54 Price cutting, due to inventory, 325 Printed circuit board assembly shop, 211 arrow diagrams, 189, 212 Proactive improvement attitude, 54 Problem-solving, vs. evasive responses, 150 Process display standing signboards, 462–463 Process improvement models, 166, 167 Process route diagrams, 782–784 Process route tables, 347, 348 Process separation, 216, 219 Process waiting waste, 214, 218 Process, transfer, process, transfer system, 59 Process-and-go production, 55-59, 57, 59 Process-related waste, 177-178 Processing, 56, 160, 187 lack of time spent in, 58 shish-kabob vs. flow production approaches, 329-330 Processing errors, 586 Processing islands abolishment of, 396-398 eliminating, 421, 426-427 Processing omissions, 586, 588-600 Processing sequence at diecast factory, 374, 376 equipment layout by, 336-337, 353-355 Processing time, reducing to shorten lead-time, 55 Processing waste, 166-167, 180 Procrastination, 205, 207 Procurement applying JIT to, 47 standardization, 229 Product inventory, 101, 102 demand trends, 475 strategies for reducing, 475–476 Product lead-time, 4 Product model changes and capacity utilization rates, 504

avoidance of, 162 Product set-up errors, 602 Product-out approach, 36, 416, 483, 555 once-a-month production scheduling in, 479 Product-specific delivery sites, 384 Product-specific inventory management, 305 Production equipment- vs. people-oriented, 112-113 roots in people, 104, 108 waste-free, 49 Production analysis, 345-348 Production as music, 29-50, 51-54 three essential elements, 50 Production factor waste, 159–160 conveyance and, 163-166 inspection and, 167-172 processing and, 166-167 retention and, 160–163 Production input, 59, 60 Production kanban, 443, 445 Production leveling, 21, 421–422, 482. See also Leveling as prerequisite for efficiency, 71 flow production development for, 492-494 importance to efficiency, 69 kaizen retooling for, 494-495 strategies for realizing, 492-494 with kanban systems, 442, 445 Production management conventional approach, 3-7 defined. 6 management system, 6 physical system, 6 vs. JIT production management, 1-3 Production management boards, 457, 470-471, 802-804 Production method and defect prevention, 555 shish-kabob vs. level production, 484, 486 Production output, 59, 60 and in-process inventory, 89 and volume of orders, 61 increasing without intensifying labor, 86 Production philosophy, shish-kabob vs. level production, 483-484, 486 Production planning, 52 Production schedules, 4 leveling production, 482 once-a-day production, 480-482 once-a-month production, 478-479

once-a-week production, 479-480 strategies for creating, 477 Production standards, 623. See also Standard operations Production techniques, 715 JIT Management Diagnostic List, 718 Production work orders, vs. kanban systems, 437-439 Productivity, 59-61 and volume of orders, 61 boosting with safety measures, 701 coexisting with humanity, 387-388 volume-oriented approach to, 415 Productivity equation, 415, 416 Products, in PQCDS approach, 3 Profit and cost reduction, 36 losses through motion, 77 Profitable factories, 40 anatomy of, 39 Progress andon, 464, 469-470 Proper arrangement, 16, 157, 243–245, 510 applied to die storage sites, 530-531 five-point checklist, 772 made visible through red tags and signboards, 265-268 obstacles to, 17 visible, 251-252 Proximity switches, 574 applications, 576 Pseudo improvements, 126-130 Public changeover timetable, 505, 808–809 Pull production, 10, 26, 51, 52, 54, 70, 438 flow of information and materials in, 53 relationship to goods, 439 using full work system, 367 using hand delivery, 366 vocal, 371, 372 Punching lathe, worker separation, 702 Purchasing-related kanban, 449-450 Push production, 10, 26, 51, 419, 438, 439 as obstacle to synchronization, 364-365 flow of information and materials in, 53

Q

QCD (quality, cost, delivery) approach, 2 Quality estimated, 122

improving through 5Ss, 241 in PQCDS approach, 3 process-by-process, 123–126 Quality assurance, 724 and defect identification, 546-561 and poka-yoke system, 565-585 as starting point in building products, 541-542 in JIT production system, 11 JIT five levels of QA achievement, 542-546 poka-yoke defect case studies, 586-615 use of poka-yoke and zero defects checklists, 616-622 zero defects plan, 561-565 Quality check points, for standard operations charts, 636-638 Quality control inspection method, 169

R

Radar chart, 727 Rational production, 120-121, 122 shish-kabob vs. flow production approaches, 330 Reality-based leveling, 23 Recession-resistant production system, 8 Red tag campaign reports, 761-763 Red tag criteria, setting, 273-274 Red tag episodes, 281 employee involvement, 284 excess pallets, 283 red tag stickers, 283-284 red tagging people, 282 showing no mercy, 284-285 twenty years of inventory, 281-282 twice red tagged, 282 yellow tag flop, 283 Red tag forms, 271 Red tag items list, 765 Red tag list, computer-operated, 280 Red tag strategy, xii, 17, 265-268, 269-270, 455 campaign timing, 268 case study at Company S, 285-289 criteria setting, 273-274 for visual control, 268-269 implementation case study, 290-293 indicating where, what type, how many, 268

main tasks in, 291 making tags, 274-275 overall procedure, 267 project launch, 271, 273 red tag episodes, 281-285 red tagging computers, 278-281 steps, 270–278, 272 tag attachment, 276 target evaluation, 276-278 target identification, 273 understanding, 282 waste prevention with, 231 Red tag strategy checklist, 292 Red tag strategy report form, 293 Red tag targets evaluating, 276-278 identifying, 273 Red tags, 758, 759, 760 attaching, 276 example, 275 making, 274-275 Reliability, increasing in equipment, 688 Reordering point method, 435–437, 475 Replacement waste, 509-510 eliminating in internal changeover, 518-523 Required volume planning, 52 Research and development, 37 Reserved carts, for changeover, 531–532 Reserved seat method, 489-490 painting process example, 490 Resistance, 42, 43, 199, 201-202 and arguments against JIT improvement, 200 and inventory accumulation, 322 by foremen and equipment operators, 30 from senior management, 15 to change, 41, 84 to multiple-skills training, 407 Responsiveness, 453 Retention, 56, 57, 160, 186, 187 and anticipatory buying, 162 and anticipatory manufacturing, 162 and capacity imbalances, 161-162 in shish-kabob production, 484 process, retention, transfer system, 59 reducing, 59 waste in, 160-163 Retention waste eliminating, 213–214 lot waiting waste, 215-216 process waiting waste, 214

Retooling time, 633 Retooling volume, 633 Return on investment (ROI), inventory and, 95 Return to start position, 663 applying *jidoka* to, 666, 667 Returning waste, 511 Rhythmic motions, 221 Rules, for safety, 696, 697, 699

S

S-shaped manufacturing cells, 362 Safety, 152, 406, 725 basic training for, 698-699 defined, 698-699 for multi-process operations, 403–404 full-fledged, 70-709 in JIT production system, 12 in PQCDS approach, 3 in standard operations chart, 701 poka-yoke applications, 703-703 standard operations goals, 624 through 5Ss, 241 visual assurance, 707-708 Safety cage, 704 Safety check points, for standard operations charts, 637 Safety improvement, pneumatic cylinders to springs, 694 Safety plate, 703 Safety strategies for zero injuries/accidents, 699-709 Salad oil example, 312 Sales figures and equipment improvements, 115 impact of seasons and climatic changes on, 97 Sales price, 36 basis in market price, 35 Sampling inspection, 120-122 Screw-fastening operation, waste in, 148 Searching waste, 154 Seasonal adjustments, 323-324 Seiketsu (cleanup), 16, 239, 246-247 Seiri (proper arrangement), 16, 238, 243-245 photo exhibit, 260 Seiso (cleanliness), 16, 239, 246

Seiton (orderliness), 16, 245-246, 328 photo exhibit, 260 Self-inspection, 392 Senior management approval for 5S approach, 262 ignorance of production principles, 88 need to believe in JIT, 139 on-site inspection by, 264 responsibility for 5S strategy, 263 role in awareness revolution, 14-15 role in production system change, 3 Seniority, as basis of pay raises, 394 Sensor assembly line, multi-process operations on, 363 Sequential mixed loads, 379 Serial operations, 224 calculations for parts-production capacity work tables, 633 eliminating, 527-529 Set-up applying human automation to, 669 pre-manufacturing, 499 unprocessed workpieces, 663, 667 Set-up errors, 560, 586, 601-606 Seven QC tools, 132, 133 Seven types of waste, 172–174 conveyance waste, 176 defect production waste, 176-177 idle time waste, 178-179 inventory waste, 175-176 operation-related waste, 178 overproduction waste, 174-175 process-related waste, 177-178 Shared specifications, 419 Shish-kabob production, 10, 17, 18, 20, 46, 70, 104, 166, 207 approach to processing, 329–330 as large-lot production, 423 as obstacle to synchronization, 371-373 disadvantages, 158 equipment approach, 331 equipment layout in, 330 in-process inventory approach, 331 lead time approach, 331 operator approaches, 330-331 production scheduling for, 476 rational production approach in, 330 vs. flow production, 328-332 vs. level production, 482–485, 486 waste in, 158 Shitsuke (discipline), 16, 239, 247-249 Short-delivery scheduling, 379, 497

Shotblaster at diecast factory, 375 compact, 354, 377, 398-399 Shukan (custom), 689 Signal kanban, 443, 445, 446 Signboard strategy, 442, 455, 464 amount indicators, 301-302 and FIFO, 302-303 defined, 294-296 determining locations, 296 die storage site using, 530 for delivery site management, 383 for visual orderliness, 293-294 habitual orderliness, 302 indicating item names, 299-300 indicating locations, 298 item indicators, 301 location indicators, 299 parking lot item indicator examples, 300 preparing locations, 296-298 procedure, 297 signboard examples, 295 steps, 296-302 Signboards, 43, 44, 265–268 overall procedure, 267 waste prevention with, 231 Simplified work procedures, 404 and defect prevention, 549 Single-process workers, 339, 375, 419 Single-product factories, 71 Single-product load, 379 Sink cabinet factory, flow production example, 493 Skin-deep automation, 79 Slow-but-safe approach, 102-103 Small-volume production, xi, 2, 62, 278, 321, 497 Social waste, 159 Solder printing process, flow of goods improvement, 641 Sorting inspection, 168, 169 Spacer blocks and manual positioning, 524-525 eliminating need for manual dial positioning with, 526 Speaker cabinet processing operations, improvements, 646-647 Special-order production, 2 Specialization in Western vs. Japanese unions, 393-394

vs. multi-process operations, 639

Specialized carts, for changeover operations, 532 Specialized lines, 371-373 Specialized machines, cost advantages, 332 Speed, vs. cycle time, 116 Spindle hole punch processing omission, 590 Spirit of improvement, 43, 44 Staff reduction, 62, 418 Standard operating processes (SOPs), 23 Standard operation forms, 626 parts-production capacity work table, 626 standard operations chart, 627-628, 628 standard operations combination chart, 626, 627 standard operations pointers chart, 626-627, 627 steps in creating, 630-638 work methods chart, 627 Standard operations, 24, 50, 65, 193-194, 224, 623, 708-709, 724 and multi-skilled workers, 650-651 and operation improvements, 638-649 as endless process, 624 combination charts for, 223-226 communicating meaning of, 652 cost goals, 624 cycle time and, 625 defined, 623 delivery goals, 624 eliminating walking waste, 645-649 equipment improvements facilitating, 640 equipment improvements to prevent defects, 640 establishing, 628-630, 629-630, 654 factory-wide establishment, 652 forms, 626-628 goals, 624 implementing for zero injuries/accidents, 699-703 improvement study groups for, 653 improvements to flow of goods/materials, 638 - 640in JIT production system, 11-12 materials flow improvements, 641 motion waste elimination through, 639 movement efficiency improvements, 642-643 multi-process-operations improvements, 639 need for, 623-624 obtaining third-party help, 653

one-handed to two-handed task improvements, 644-645 operational rules improvements, 639-640 parts placement improvements, 643 picking up parts improvements, 643-644 preserving, 650–654 quality goals, 624 rejection of status quo in, 653 reminder postings, 652 role in JIT introduction, 23-24 safety goals, 624, 697 separating human work from machine work for, 640, 649-650 sign postings, 652 spiral of improvement, 629 standard in-process inventory and, 625-626 ten commandments for, 651-654 three basic elements, 625-626 transparent operations and, 628 waste prevention through, 226 wood products manufacturer's combination charts, 227 work sequence and, 625 workshop leader skills, 652, 653 Standard operations chart, 627, 628, 629, 631, 637 safety points, 700, 701 steps in creating, 630-632, 636-638 Standard operations combination chart, 193, 457, 626, 627, 629, 631, 825-826 steps in creating, 634-636 Standard operations form, 831-833 Standard operations pointers chart, 626–627, 627 Standard operations summary table, 827-828 Standard parameters, changeover of, 499 Standardization of equipment, 421 waste prevention by, 228-230 Standby-for-lot inventory, 161 Standby-for-processing inventory, 161 Standing signboards, 462-463 Standing while working, 19, 118, 355, 424, 425, 429 and cooperative operations, 368 as condition for flow production, 339 in assembly lines, 355-359 in multi-process operations, 399-400 in processing lines, 359–360 work table adjustments for, 360 Statistical inventory control methods, 475

Statistical method, 570 poka-yoke, 659 Status quo denying, 205 failure to ensure corporate survival, 15 reluctance to change, 42 Steady-demand inventories, 476 Stockpiling, 160 Stop devices, 566-567 Stop-and-go production, 55-59, 57 Stopgap measures, 150 Storage, cutting tools, 318 Straight-line flow production, 340, 360 Subcontracting, applying JIT to, 47 Subcontractors, bullying of, 378 Sudden-demand inventories, 476 Suggestion systems, 36 Supplier kanban, 443, 444 Supplies management, 81 Surplus production, 323 and defects, 549 Sweat workers, 74, 75 Symmetrical arm motions, 220-221 Synchronization, 363-364 as condition for flow production, 337 bottlenecked process obstacle, 364 changeover difficulties, 373 obstacles to, 364-368 PCB assembly line, 366, 367 push method as obstacle to, 364-365 work procedure variations as obstacle to, 367-371

Т

Taboo phrases, 202 Japanese watch manufacturer, 203 Takt time, 368, 469, 482 Tap processing errors, 606 Tapping operations, defect prevention, 673–674 Temporary storage, 160 Three Ms, in standard operations, 623 Three Ps, 432 Three-station arrangements, 165 Time graph analysis, changeover improvements, 513 Time workers, 75 Tool bit exchange, one-touch, 522 Tool elimination as internal changeover improvement, 519-520 by transferring tool functions, 316 Tool preparation errors, 560, 587, 615 Tools 5-point check for orderliness, 256 applying orderliness to, 307 close storage site, 311 color-coded orderliness, 308-309 combining, 314, 315 easy-to-maintain orderliness for, 307 eliminating through orderliness, 313-316 indicators, 308, 309 machine-specific, 311 outlined orderliness, 309 Tools placement, 222 order of use, 222 Top-down improvements, 134-139 Torque tightening errors, 599 Torso motion, minimizing, 221 Total quality control (TQC), 36, 132 Total value added, 715 Training for basic safety, 698-699 for multi-process operations, 407-413 for multiple skills, 400 in CCO, 708 in Japanese vs. Western factories, 395 Training costs, for multi-process operations, 394-395 Transfer, 56, 57, 58 Transfer machine blade replacement, 528 Transparency, in multi-process operations, 405 Transparent operations, and standard operations, 628 Transport kanban, 443 Transport routes, 380-382 Transportation lead-time, 99 Two-handed task improvements, 644-645 and safety, 704 Two-process flow production lines, 360

U

U-shaped manufacturing cells, 340, 360–362 as condition for flow production, 341 for multi-process operations, 395–396 Unbalanced capacity, 322 Unbalanced inventory, 161, 322 Union leadership, 84 Unmanned processes, 668 Unneeded equipment list, 767 Unneeded inventory list, 765, 766 Unneeded items moving out, 266 separating from needed items, 266 throwing out, 266 types and disposal treatments, 277 unneeded equipment list, 278 unneeded inventory items list, 277 Unprocessed workpieces, set-up, 663, 668 Unprofitable factories, anatomy of, 38 Usability testing, and defect prevention, 549-550 Use points, maximum proximity, 222 Usefulness, and value-added, 147

V

Value analysis (VA), 157 Value engineering (VE), 157 Value-added work, 85, 166 JIT Management Diagnostic List, 717 vs. wasteful motion, 86, 147 VCR assembly line, cooperative operations example, 429 Vertical development, 20, 24-27, 26, 378, 391 Vertical improvement makers, 167 Vibration switches, 574 applications, 583 Visible 5Ss, 249-251, 252 visible cleanliness, 253 visible discipline, 254-255 visible orderliness, 252-253 visible proper arrangement, 251-252 visibly cleaned up, 253 Visible cleanliness, 253 Visible discipline, 254-255 Visible orderliness, 252-253 with signboard strategy, 295 Visible proper arrangement, 251-252 Visibly cleaned up, 253 Visual control, 26, 120, 231, 251, 723 and kaizen, 471-473 andon for, 456, 464-470

as non-guarantee of improvements, 453-454, 472-473 defect prevention with, 563 defective item displays for, 456, 457, 458 error prevention through, 456, 458 for safety, 700 in JIT production, 10-11 in kanban systems, 437 kaizen boards for, 462 kanban for, 456, 457 management flexibility through, 419 preventing communication errors with, 556 process display standing signboards, 462-463 production management boards for, 456, 457, 470-471 red demarcators, 455, 456 red tag strategy for, 268-269, 455, 456 signboard strategy, 455, 456 standard operation charts for, 456, 457 standing signboards for, 462–463 through kanban, 440 types of, 455-459 visual orderliness case study, 459-462 waste prevention with, 230-232 white demarcators, 455, 456 Visual control tools, roles in improvement cycle, 473 Visual orderliness case study, 459-462 in electronics parts storage area, 460 signboard strategy for, 293-306 Visual proper arrangement, 17 Visual safety assurance, 707-708 Vocal pull production, 371, 372 Volume of orders, and production output, 61

W

Walking time, 635
Walking waste, 153–154, 173, 536 eliminating for standard operations, 645–649
Wall of fixed ideas, 210
Warehouse inventories, 161, 175 as factory graveyards, 73 reduction to zero, 20
Warehouse maintenance costs, 73 Warehouse waste, 69 Warning andon, 466-468 Warning devices, 567 Warning signals, 567 Washing unit, 364 compact, 356 in-line layout, 365 Waste, xii, 15, 643 5MQS waste, 152-159 and corresponding responses, 180 and inventory, 48 and motion, 75 and red tag strategy, 269 as everything but work, 182, 184, 191 avoiding creation of, 226-236 concealment by shish-kabob production, 17, 158 conveyance due to inventory, 90 deeply embedded, 18, 150, 151 defined, 146-150 developing intuition for, 198 eliminating with 5Ss, 508-511 elimination by kanban, 440 elimination through JIT production, xi, 8, 341-342 embedding and hiding, 84 examples of motion as, 76 hidden, 179 hiding in conveyor flows, 67 how to discover, 179-181, 179-198 how to remove, 198-226 identifying in changeover procedures, 508-511 in changeover procedures, 501 in external changeover operations, 510-511 in internal changeover operations, 509-510 in screw-fastening operation, 148 inherited vs. inherent, 79-84 invisible, 111 JIT and cost reduction approach to, 69-71 JIT Production System perspective, 152 JIT seven types of, 172–179 JITs seven types of, 172-179 latent, 198 making visible, 147 minimizing through kanban systems, 437 production factor waste, 159-172 reasons behind, 146-150 reinforcing by equipment improvements, 111-112

related to single large cleaning chamber, 155 removing, 84-86, 198-226 severity levels, 171-172 through computerization, 83 total elimination of, 145, 152 types of, 151–179 Waste checklists, 194-198 five levels of magnitude, 195 how to use, 195 negative/positive statements, 197 process-specific, 195, 196, 197, 198 three magnitude levels, 197 workshop-specific, 195 Waste concealment, 454 by inventory, 326, 327 revealing with one-piece flow, 350-351, 352 Waste discovery, 179-181 back-door approach to, 181-183 through current conditions analysis, 185-198 with arrow diagrams, 186-190 with one-piece flow under current conditions, 183-185 with operations analysis tables, 190-192 with standard operations, 193-194 with waste-finding checklists, 194-198 Waste prevention, 226, 228 and do it now attitude, 236 by avoiding fixed thinking, 235–236 by outlining technique, 231 by thorough standardization, 228-230 with 5W1H sheet, 232-236 with andon, 232 with kanban system, 232 with one-piece flow, 353 with pitch and inspection buzzers, 232 with red tagging, 231 with signboards, 231 with visual and auditory control, 230-232 Waste proliferation, 198, 199 Waste removal, 198–199 50% implementation rate, 205-206 and Basic Spirit principles for improvement, 204 and denial of status quo, 205 and eliminating fixed ideas, 204 basic attitude for, 199-211 by correcting mistakes, 207 by cutting spending on improvements, 207 by experiential wisdom, 210-211 by Five Whys approach, 208-210

by using the brain, 208 in wasteful movement, 211-217 lot waiting waste, 219 positive attitude towards, 204-205 process waiting waste, 218 through combination charts for standard operations, 223-226 wasteful human movement, 217-223 Waste transformation, 198 Waste-finding checklists, 737–743 process-specific, 739, 741, 742, 743 workshop-specific, 738, 740 Waste-free production, 49 Waste-related forms, 730 5W1H checklists, 744–746 arrow diagrams, 730-732 general flow analysis charts, 733-734 operations analysis charts, 735-736 waste-finding checklists, 737-743 Wasteful movement and eliminating retention waste, 213-217 by people, 217-223 eliminating, 211, 213 Wastology, 145 Watch stem processes, 397, 398 Watching waste, 154 Weekly JIT improvement report, 846-848 Whirligig beetle (mizusumashi), 465 Wire harness molding process, internal changeover improvement case study, 517-518 Withdrawal kanban, 444 Wood products factory, multi-process operations in, 425 Work as value-added functions, 182 meaning of, 74-75 motion and, 74-79 vs. motion, 657, 659 Work environment, comfort of, 223 Work methods chart, 627, 629, 829-830 Work operations, primacy over equipment improvements, 103-108 Work sequence, 636 and standard operations, 625 arranging equipment according to, 638 for standard operations charts, 636 Work tables, ergonomics, 222 Work-in-process, 8 management, 81, 83 Work-to-motion ratio, 86 Work/material accumulation waste, 173

Worker hour minimization, 62, 66–69 Worker mobility, 19 Worker variations, 367-371 Workerless automation, 106 Workpiece directional errors, 605 Workpiece extraction, 663 Workpiece feeding, applying automation to, 665 Workpiece motion, waste in, 158-159 Workpiece pile-ups, 25, 118 Workpiece positioning errors, 605 Workpiece processing, applying *jidoka* to, 664 Workpiece removal applying human automation to, 668 motor-driven chain for, 695 with processed cylinders, 667 Wrong part errors, 587, 612, 613 Wrong workpiece, 560, 587, 614

Y

Yen appreciation, xi

Ζ

Zero accidents, 699 Zero breakdowns, 684, 685 production maintenance cycle for, 687 with 5S approach, 241 Zero changeovers, with 5S approach, 242 Zero complaints, with 5S approach, 242 Zero defects, 545 5S strategy for, 565 human errors and, 562-563 information strategies, 563 machine cause strategies, 564 material cause strategies, 564 overall plan for achieving, 561-565 production maintenance cycle for, 687 production method causes and strategies, 564-565 with 5S approach, 241 Zero defects checklists three-point evaluation, 619-620

three-point response, 620–622 using, 616–622 Zero delays, with 58 approach, 242 Zero injuries strategies for, 699–709 with 5S approach, 241 Zero inventory, 20, 98–102 importance of faith in, 176 Zero red ink, with 5S approach, 242 Zigzag motions, avoiding, 221

About the Author

Hiroyuki Hirano believes Just-In-Time (JIT) is a theory and technique to thoroughly eliminate waste. He also calls the manufacturing process the equivalent of making music. In Japan, South Korea, and Europe, Mr. Hirano has led the on-site rationalization improvement movement using JIT production methods. The companies Mr. Hirano has worked with include:

Polar Synthetic Chemical Kogyo Corporation Matsushita Denko Corporation Sunwave Kogyo Corporation Olympic Corporation Ube Kyosan Corporation Fujitsu Corporation Yasuda Kogyo Corporation Sharp Corporation and associated industries Nihon Denki Corporation and associated industries Kimura Denki Manufacturing Corporation and associated industries Fukuda ME Kogyo Corporation Akazashina Manufacturing Corporation Runeau Public Corporation (France) Kumho (South Korea) Samsung Electronics (South Korea) Samsung Watch (South Korea) Sani Electric (South Korea)

Mr. Hirano was born in Tokyo, Japan, in 1946. After graduating from Senshu University's School of Economics, Mr. Hirano worked with Japan's largest computer manufacturer in laying the conceptual groundwork for the country's first full-fledged production management system. Using his own interpretation of the JIT philosophy, which emphasizes "ideas and techniques for the complete elimination of waste," Mr. Hirano went on to help bring the JIT Production Revolution to dozens of companies, including Japanese companies as well as major firms abroad, such as a French automobile manufacturer and a Korean consumer electronics company.

The author's many publications in Japanese include: *Seeing Is Understanding: Just-In-Time Production (Me de mite wakaru jasuto in taimu seisanh hoshiki), Encyclopedia of Factory Rationalization (Kojo o gorika suru jiten), 5S Comics (Manga 5S), Graffiti Guide to the JIT Factory Revolution (Gurafiti JIT kojo kakumei),* and a six-part video tape series entitled *JIT Production Revolution, Stages I and II.* All of these titles are available in Japanese from the publisher, Nikkan Kogyo Shimbun, Ltd. (Tokyo).

In 1989, Productivity Press made Mr. Hirano's *JIT Factory Revolution: A Pictorial Guide to Factory Design of the Future* available in English.